

WAR DEPARTMENT TECHNICAL MANUAL

TM 11-620

RADIO SETS
SCR-608-A AND SCR-628-A

WAR DEPARTMENT • 1 JANUARY 1944

War Department Technical Manual

TM 11-620

Radio Sets SCR-608-A and SCR-628-A

War Department

1 January 1944

WAR DEPARTMENT
WASHINGTON 25, D. C., 1 January, 1944.

TM 11-620, Radio Sets SCR-608-A and SCR-628-A, is published for the information and guidance of all concerned.

[A. G. 300.7 (6 August, 1943).]

By order of the Secretary of War:

G. C. MARSHALL,
Chief of Staff.

Official:

J. A. ULIO,
*Major General,
The Adjutant General.*

Distribution:

C and H6(4); Bn 18(4); IC18(2), 11(10).

(For explanation of symbols see FM 21-6.)

TABLE OF CONTENTS

SECTION I. Description.

Paragraph		Page
1.	Purpose	1
2.	Performance Characteristics	1
3.	General Features	1
4.	Associated Items	7
5.	Frequency Modulation	9
6.	Mounting FT-237-(*)	11
7.	Radio Receiver BC-683-A	11
8.	Radio Transmitter BC-684-A	12
9.	Remote Control Unit RM-29-D	25
10.	Dynamotors DM-34-(*), DM-35-(*), DM-36-(*), DM-37-(*)	25
11.	Cabinet CH-74-A	27
12.	Mountings FT-284-(*) and FT-285-(*) and Frame FM-43	27
13.	Mast Bases	27
14.	Mast Base Bracket MP-52	27
15.	Mast Sections	27
16.	Cords and Cordage	27

II. Installation and Operation.

17.	Initial Procedure	29
18.	Installation	29
19.	Preparation for Use	30
20.	Operation	32
21.	Presetting Push Buttons	36
22.	System Operation	41

III. Functioning of Parts.

23.	Functioning of Radio Receiver BC-683-A	43
24.	Functioning of Radio Transmitter BC-684-A	57
25.	Functioning of Remote Control Unit RM-29-D	63
26.	Functioning of Dynamotors DM-34-(*), DM-35-(*), DM-36-(*), DM-37-(*)	63
27.	Functioning of Control Circuits	63

IV. Maintenance.

28.	General Maintenance Information	71
29.	Routine Check of Mounting	73
30.	Routine Check of Radio Receiver BC-683-A	73
31.	Routine Check of Radio Transmitter BC-684-A	77
32.	Routine Check of System	84
33.	Emergency Check of Receiver Output Volume and Circuit Alignment	84
34.	Emergency Alignment of Radio Receiver BC-683-A	86
35.	Emergency Alignment of Radio Transmitter BC-684-A	95
36.	Emergency Sources of Test Tones	100
37.	Precision Alignment of Radio Receiver BC-683-A	100
38.	Precision Alignment of Radio Transmitter BC-684-A	105
39.	Location of Trouble in Radio Receiver BC-683-A	109
40.	Location of Trouble in Radio Transmitter BC-684-A	124
41.	Maintenance of Dynamotors	130

V. Supplementary Data.

42.	Replacement of Parts	133
43.	Modifications During Manufacture	139
44.	Color Codes on Components	149
45.	Table of Replaceable Parts	156

LIST OF ILLUSTRATIONS

grouped according to components

Fig.	Title	Page
General:		
1	Radio Set SCR-608-A: Front View of Cabinet CH-74-A with Associated Components	VIII
2	Radio Set SCR-628-A: Front View of Cabinet CH-74-A with Associated Components	2
3	Radio Set SCR-608-A: Over-all and Unit Dimensions	8
23	Radio Set SCR-608-A: System Block Diagram	41
69	Radio Set SCR-608-A: System Schematic Diagram	189

Radio Receiver BC-683-A:

6	Front View	12
7	Oblique Rear View	13
8	Left-hand Interior View	14
9	Right-hand Interior View	15
10	Push-button Assembly, Right-side View	16
11	Push-button Assembly, Front View	16
24	Block Diagram	43
25	Functional Diagram of R-f Amplifier, Modulator, and R-f Oscillator	44
26	Functional Diagram of I-f Amplifier and Limiter	46
27a	Functional Diagram of Discriminator	48
27b, c, d	Vector Diagrams Showing Phase Relations in the Discriminator	49
28	Functional Diagram of A-f Amplifier	51
29	Functional Diagram of Delayed-automatic-volume-control Circuit	52
30	Functional Diagram of Squelch Circuit	54
31	Functional Diagram of I-f Oscillator	56
32	Functional Diagram of the Heater Circuits	57
43	Wiring Diagram of Front Panel	72
44	Apparatus Location Diagram, Front View of Panel	73
45	Apparatus Location Diagram, Left-side View	74
46	Apparatus Location Diagram, Right-side View	75
51	Location of Alignment and Tuning Controls	93
57	Voltage Diagram	117
58	Resistance Diagram	119
70	Schematic Diagram Showing Modifications During Manufacture	191
71	Schematic Diagram	193
72	Wiring Diagram Without Front Panel	195

Radio Transmitter BC-684-A:

12	Front View With Crystal Compartment Open	17
13	Assembly and Exploded View of Crystals	18
14	Right-hand End View with Cover Plate Removed	19
15	Interior View with Top Cover and Dynamotor Removed	20
16	Push-button Assembly, Left-side View	21
17	Push-button Assembly, Right-side View	21
18	Interior View with Bottom Cover Removed	21
33	Block Diagram	22
34	Functional Diagram of Oscillator and First R-f Amplifier	58
35	Functional Diagram of Modulator and Rectifier	58
36	Method of Modulation	59
37	Functional Diagram of Tripler, Doubler, Power Amplifier, and Antenna Coupling Circuits	60
38	Functional Diagram of A-f Amplifier	61
47	Apparatus Location Diagram, End View and Detail Through Section A-A	62
48	Apparatus Location Diagram, Top View	78
		79

LIST OF ILLUSTRATIONS—Continued

Fig.	Title	Page
49	Apparatus Location Diagram, Front View	80
50	Apparatus Location Diagram, Bottom View	82
52	Location of Alignment and Tuning Controls	97
59	Voltage Diagram	125
60	Resistance Diagram	127
73	Schematic Diagram Showing Modifications During Manufacture	197
74	Schematic Diagram	199
75	Wiring Diagram	201
77	Artificial Antenna Used for Testing	205
 Mounting FT-237-(*):		
4	Oblique Front View	10
5	Details	10
61	Schematic Diagram	133
62	Wiring Diagram	135
 Remote Control Unit RM-29-D:		
19	Front View	23
20	Interior View	23
76	Schematic and Wiring Diagram	203
 Dynamotors DM-34-(*), DM-35-(*), DM-36-(*), DM-37-(*):		
21a	Dynamotor DM-34-(*) or Dynamotor DM-36-(*)	24
21b	Dynamotor DM-34-(*) or Dynamotor DM-36-(*) : Sub-base View	24
22a	Dynamotor DM-35-(*) or Dynamotor DM-37-(*)	26
22b	Dynamotor DM-35-(*) or Dynamotor DM-37-(*) : Sub-base View	26
39	Schematic and Wiring Diagrams	64-65
40	Apparatus Location Diagrams	66
41	Dynamotor DM-34-(*) or Dynamotor DM-36-(*) : Exploded View	67
42	Dynamotor DM-35-(*) or Dynamotor DM-37-(*) : Exploded View	68
 Adapter FT-384-(*):		
53	Front View	101
54	Back View	101
55	Application to Radio Receiver BC-683-A	102
56	Schematic and Wiring Diagram	103
 Capacitors and Resistors:		
63	Types of Capacitors and Resistors	146
64	Molded Mica Capacitors: Three-dot Color Code	150
65	Molded Mica Capacitors: RMA Six-dot Color Code	151
66a	Molded Mica Capacitors: AWS Six-dot Color Code	152
66b	Molded Paper Capacitors: AWS Six-dot Color Code	153
67	Tubular Ceramic Capacitors: RMA Color Code	153
68	Fixed Resistors: RMA and AWS Color Codes	154
 Artificial Antenna:		
77	For Testing Radio Transmitter BC-684-A	205

LIST OF TABLES AND CHARTS

<i>Table</i>	<i>Title</i>	<i>Page</i>
I	List of Components and Other Items Required	3
II	Channel and Crystal Frequencies	6
III	Battery Currents	9
IV	Selection of Dynamotors	29
V	Meter Switch Readings (RECEIVER TUNE-OPERATE switch at OPERATE)	32
VI	Meter Switch Readings (RECEIVER TUNE-OPERATE switch at RECEIVER TUNE)	129
VII	Capacitor Characteristics	147
VIII	Table of Replaceable Parts	156
IX	List of Manufacturers	187
 <i>Chart</i>		
I	Equipment Required for Servicing of Radio Receiver BC-683-A	121
II	Servicing Procedure for Radio Receivers BC-683-A Not Mounted in a Vehicle	122
III	Servicing Procedure for Radio Receivers BC-683-A Mounted in a Vehicle	123

DESTRUCTION NOTICE

WHY To prevent the enemy from using or salvaging this equipment for his benefit.

WHEN When ordered by your commander, or when you are in immediate danger of capture.

- HOW**
1. Smash— Use sledges, axes, hand-axes, pick axes, hammers, crowbars, heavy tools, etc.
 2. Cut— Use axes, hand-axes, machete, etc.
 3. Burn— Use gasoline, kerosene, oil, flame-throwers, incendiary grenades, etc.
 4. Explosives— Use firearms, grenades, TNT, etc.
 5. Disposal— Bury in slit trenches, foxholes, other holes. Throw in streams. Scatter.
 6. *Use anything immediately available for destruction of this equipment.*

- WHAT**
1. Smash— Crystals, meter, plugs, tuning controls, tubes, capacitors, resistors, sockets, insulators, microphones, headsets, and relays.
 2. Cut— Cords, wiring, and cables.
 3. Bend and/or Break— Antenna sections, panels, mounting, and nameplate.
 4. Burn— Circuit label, technical manual and all papers, cords, wiring, cable, dynamotors, capacitors, resistors, and nameplate.
 5. Bury and/or Scatter— Any or all of the above pieces after breaking.

DESTROY EVERYTHING

SAFETY NOTICE

THIS EQUIPMENT USES DANGEROUSLY HIGH VOLTAGES. IT CAN KICK LIKE A MULE AND IS A DARN SIGHT MORE DANGEROUS. DON'T CHANGE VACUUM TUBES OR WORK IN THE EQUIPMENT WITH THE DYNAMOTOR RUNNING, EXCEPT AS SPECIFICALLY DIRECTED IN THIS MANUAL. BE CAREFUL, DON'T TAKE CHANCES.

SPECIAL NOTICE

Certain schematic and wiring diagrams in this manual include modifications during manufacture which are discussed in Paragraph 43. Not all these changes are included in the functional diagrams, Figs. 25 through 38. Any discrepancies between these two groups of figures are explained under appropriate heading in Paragraph 43. In case of such discrepancies, follow the circuit label on the equipment.




Fig. 1. Radio Set SCR-608-A: Front View of Cabinet CH-74-A with Associated Components

SECTION I. DESCRIPTION

1. Purpose. Radio Sets SCR-608-A and SCR-628-A provide frequency-modulated radio telephone communication for anti-aircraft and anti-tank warning and control nets, for base stations at battalion command posts for fire control and fire direction nets, and for intra-battalion communication. The radio sets may be installed and operated in combat vehicles such as command cars, half-tracks, or any other authorized vehicle.

The sets are designed to operate within a temperature range of minus 40 degrees to plus 130 degrees Fahrenheit around the set. Don't operate this equipment for long periods of time in enclosed spaces where the temperature may rise too high. Watch this.

2. Performance Characteristics.**a. System.**

- (1) Frequency range.....27.0 to 38.9 megacycles
- (2) Channel spacing.....100 kilocycles
- (3) Number of channels available.....120
- (4) Channel numbers.....270 to 389 inclusive
- (5) Number of preset channels.....10
- (6) Communication range.....5 to 15 miles
- (7) Power supply.....12- or 24-volt vehicular battery (see Note)

Note: Radio Sets SCR-608-A and SCR-628-A are equipped with dynamotors for operation from a 12-volt battery. If authorized, they may be operated from a 24-volt battery by substitution of the proper dynamotor. This is explained fully in Paragraph 10c. Be sure you don't operate your set from a battery of the wrong voltage. You'll burn out tubes, dynamotor, and capacitors.

b. Radio Receiver BC-683-A.

- (1) Sensitivity.....1 microvolt
- (2) Intermediate frequency.....2.65 megacycles
- (3) Band width.....80 kilocycles
- (4) Power output, speaker.....2 watts
- (5) Power output, headset.....0.2 watt
- (6) Call signal.....1 amp
- (7) Noise suppression....."Squelch"
- (8) Battery drain, 12-volt supply.....4 amperes
- (9) Battery drain, 24-volt supply.....2 amperes
(see Note under Paragraph 2a.)

NOTE: Throughout this manual an asterisk within parentheses (*) indicates the applicable issue letter of interchangeable components of the equipment.

c. Radio Transmitter BC-684-A.

- (1) Nominal power output.....20 watts
- (2) Nominal frequency deviation..... ± 40 kilocycles
- (3) Crystal frequency range.....375,000 to 540,277 kilocycles
- (4) Frequency multiplication.....72
- (5) Battery drain, 12-volt supply.....20 amperes
- (6) Battery drain, 24-volt supply.....12 amperes
(see Note under Paragraph 2a.)

3. General Features.

a. Arrangement and Weight of Major Components. The general construction and arrangement of Radio Sets SCR-608-A and SCR-628-A are shown in Figs. 1 and 2. Over-all component and assembly dimensions are shown in Fig. 3. The radio sets consist of these combinations of major units:

(1) Radio Set SCR-608-A.

- 2 Radio Receivers BC-683-A with 12-volt Dynamotor DM-34(*).....70 lbs.
- 1 Radio Transmitter BC-684-A with 12-volt Dynamotor DM-35(*).....67 lbs.
- 1 Mounting FT-237(*) with Cord CO-278-A for connection to power supply.....44 lbs.
- Total weight.....181 lbs.

(2) Radio Set SCR-628-A.

- 1 Radio Receiver BC-683-A with 12-volt Dynamotor DM-34(*).....35 lbs.
- 1 Radio Transmitter BC-684-A with 12-volt Dynamotor DM-35(*).....67 lbs.
- 1 Mounting FT-237(*) with Cord CO-278-A for connection to power supply.....44 lbs.
- Total weight.....146 lbs.

b. Components of Radio Sets SCR-608-A and SCR-628-A. For a list of components, refer to Table I.

c. Vacuum Tube Complement. Radio Receiver BC-683-A and Radio Transmitter BC-684-A include, and are issued with, a complete




Fig. 2. Radio Set SCR-628-A: Front View of Cabinet CH-74-A with Associated Components

Table I. List of Components and Other Items Required

Quantity	Article
	Adapter Kit MC-471; includes:
*	1 Adapter plate; 15 in. x 35 in. x $1\frac{3}{8}$ in.
	1 Reinforced plate; 16 in. x $1\frac{1}{2}$ in. x $\frac{3}{4}$ in.
	Necessary hardware
1	Antenna A-83-(*) (Phantom)
2	Battery Bracket BA-27 [for Remote Control Unit RM-29-(*)]; 1 in Use, 1 Running Spare
1	Box BX-40 [for 30 crystal Holders FT-241-(*)]; includes 30 Holders FT-241-(*)
*	Bracket (extension for Mounting FT-285)
*	Bracket (Cabinet CH-74-A)
*	Cabinet CH-74-A
1	Case CS-76-(*) [for Remote Control Unit RM-29-(*)]
1	Chest CH-96 [for Microphone T-17, Headset HS-30-(*), Box BX-40, spare tubes, technical manuals, etc.]
2	Clamp MC-423 (for Mast Section MS-51); 1 in Use, 1 Running Spare
2	Clamp MC-424 (for Mast Section MS-52); 1 in Use, 1 Running Spare
2	Cord CD-307-A [65-in. long, for Headset HS-30-(*)]; 1 in Use, 1 Running Spare
*	Connector and Bondnut; Appleton Electric Co. No. 61004 and BL-50 respectively
*	Connector and Bondnut; Appleton Electric Co. No. 61007 and BL-50 respectively
2	Cord CD-604 [for Headset HS-30-(*)]; 1 in Use, 1 Running Spare
1	Cord CD-689 (for Mast Base MP-48-A)
*	Cable WC-562
*	Cord CD-318-A (for Microphone T-45)
*	Cordage CO-212
*	Cordage CO-218 [for connecting slip ring to Interphone Control Box BC-606-(*) in turret.]
1	Cover BG-96 (for radio set)
1	Cover BG-108 (for Mast Base MP-48-A)
2	Dynamotor DM-34-(*) [for Radio Receiver BC-683-(*)]; 12 volts; includes the following Running Spare in DAG attached to dynamotor: 4-BRUSH (L.V.) INCLUDES SPRINGS 4-BRUSH (H.V.) INCLUDES SPRINGS
1	Dynamotor DM-35-(*) [for Radio Transmitter BC-684-(*)]; 12 volts; includes the following Running Spare in DAG attached to dynamotor: 4-BRUSH (L.V.) INCLUDES SPRING 4-BRUSH (H.V.) INCLUDES SPRING
1	Frame FM-43 [for Cabinet CH-74-A or Mounting FT-237-(*)]
1	Hardware Kit: Miscellaneous items
2	Headset HS-30-(*); 1 in Use, 1 Running Spare (When Headset HS-30-(*) is not available, Headset HS-18 or HS-23 may be issued.)
*	Insulator IN-101
*	Insulator IN-104
*	Insulator IN-121 ($1\frac{1}{8}$ -in. long, for insulating antenna wire through metal partition.)
*	Interphone Control Box BC-606-(*); includes attached hardware as follows: screws, washers, clamps, clips, and hooks.

Table I. List of Components and Other Items Required—Continued

Quantity	Article
1	Mast Base MP-48-A
*	Mast Base Bracket MP-52 (Cabinet CH-74-A)
*	Mast Base Bracket MP-54
*	Mast Section MS-51
2	Mast Section MS-52; 1 in Use, 1 Running Spare
2	Mast Section MS-53; 1 in Use, 1 Running Spare
*	Microphone T-17 (hand-type)
*	Microphone T-45 (lip-type)
	(When Microphone T-17 or T-45 is not available, Microphone T-30 may be issued.)
3	Microphone Cover M-367; 2 in Use, 1 Running Spare
1	Mounting FT-237-(*) ; includes:
	1 Cord CO-278 (for power)
	1 set dust covers for receptacles
	All necessary mounting holes, nuts, and lock washers.
*	Mounting LT-284 (for Cabinet CH-74-A)
*	Mounting FT-285 (for Cabinet CH-74-A); includes: mounting bolts, nuts, screws, straps, and bracket.
*	Mounting FT-326
2	Radio Receiver BC-683-(*) ; includes:
	10 Fuse FU-24; 1 in Use, 9 Running Spare
	3 Lamp LM-63; 1 in Use, 2 Running Spare
	2 Tube JAN-6H6 (VT-90); 1 in Use, 1 Running Spare
	2 Tube JAN-6J5 (VT-94); 1 in Use, 1 Running Spare
	2 Tube JAN-6V6GT/G (VT-107-A); 1 in Use, 1 Running Spare
	4 Tube JAN-6AC7/1852 (VT-112); 3 in Use, 1 Running Spare
	3 Tube JAN-12SG7 (VT-209); 2 in Use, 1 Running Spare
	3 Tube JAN-6SL7GT (VT-229); 2 in Use, 1 Running Spare
1	Radio Transmitter BC-684-(*) ; includes:
	120 Crystal Holder FT-211-(*) with Crystal (10 in Sockets, 80 in Drawer Compartment, 30 in Box BX-10)
	10 Fuse FU-64; 1 in Use, 9 Running Spare
	3 Lamp LM-38; 1 in Use, 2 Running Spare
	11 Tube JAN-1619 (VT-164); 7 in Use, 4 Running Spare
	2 Tube JAN-1624 (VT-165); 1 in Use, 1 Running Spare
1	Remote Control Unit RM-29-(*)
1	Roll BG-56-A (for antenna mast sections)
2	Technical Manual TM 11-620 for Radio Sets SCR-608-(*) and SCR 628-(*)
6 ft.	Wire W-128

The asterisk within parentheses (*) indicates that items so indicated are interchangeable with those marked with a different suffix letter.

An asterisk in the column headed *Quantity* indicates that the item is issued in quantities authorized, depending upon the type of installation to be made.

set of vacuum tubes in place. The tube complement of each component follows:

(1) *Radio Receiver BC-683-A.*

Circuit Designation	Function	Signal Corp. Designation	Commercial Designation
V1	R-f amplifier	VT-112	6AC7
V2	Modulator	VT-112	6AC7
V3	R-f oscillator	VT-94	6J5
V4	I-f amplifier	VT-209	12SG7
V5	I-f amplifier	VT-209	12SG7
V6	Limiter	VT-112	6AC7
V7	Detector (discriminator)	VT-90	6H6
V8	Second a-f amplifier	VT-107-A	6V6-GT
V9	AVC and squelch	VT-229	6SL7-GT
V10	First a-f amplifier and i-f oscillator	VT-229	6SL7-GT

(2) *Radio Transmitter BC-684-A.*

Circuit Designation	Function	Signal Corp. Designation	Commercial Designation
V101	First r-f amplifier	VT-164	1619
V102	Rectifier	VT-164	1619
V103	Doubler	VT-164	1619
V104	Power amplifier	VT-165	1624
V105	First a-f amplifier	VT-164	1619
V106	Second a-f amplifier	VT-164	1619
V107	Oscillator	VT-164	1619
V108	Tripler	VT-164	1619

d. Crystal Holders and Frequency Range.

The receiver and transmitter operate between 27.0 and 38.9 megacycles; this range is divided into 120 channels of 100 kilocycles each. (See Table II.) Channels 270 to 279, inclusive, have the same frequencies as channels 70 to 79, inclusive, of the Armored Force [Radio Sets SCR-508-(*), SCR-528-(*), and SCR-538-(*)]. These channels may therefore be used for liaison purposes.

A drawer in the transmitter provides storage for 80 Crystal Holders FT-241-A, one for each of 80 channel frequencies out of the 120 channels available. Each crystal holder contains a low-frequency quartz crystal (see Table II), and is marked with the channel number and output frequency.

e. General Spare Equipment.

(1) *Receiver.* Ten 15-ampere Fuses FU-24 (one in use, one in the spare holder, and eight in the attached bag) and three neon CALL SIGNAL lamps (one in use and two in the attached bag) are furnished with each receiver.

(2) *Transmitter.* Ten 1/2-ampere Littelfuse Type 4AG fuses (one installed, one in the spare holder, and eight in the attached bag) and three pilot lamps (one installed and two in the attached bag) are furnished with each transmitter.

(3) *Mounting.* The mounting includes and is issued with one Cord CO-278-A and ten 75-ampere Western Electric 66B fuses (one in use, one in the spare holder, and eight in the attached bag). Also included are one set of receptacle dust covers and all necessary mounting bolts, nuts, and lock washers, together with two copies of Preliminary Instructions for Radio Sets SCR-608-A and SCR-628-A.

f. Code Designation of Component Parts.

Remember the method of numbering the component parts used in the various units of these radio sets. This will help you determine whether the part belongs in the receiver, transmitter, etc. Parts in the schematic and wiring diagrams, and usually on the equipment units also, are designated by a number preceded by one or more letters. For example, C25, C115, L701, etc. Numbers for these units are shown in the column headed "Reference Number" in the Table of Replaceable Parts, Paragraph 45. Reference numbers from:

1 to 99 are used for parts in Radio Receiver BC-683-A.

101 to 199 are used for parts in Radio Transmitter BC-684-A.

401 to 499 are used for parts in Mounting FT-237-(*).

501 to 599 are used for parts in Dynamotor DM-35-(*). (transmitter, 12 volts).

601 to 699 are used for parts in Dynamotor DM-37-(*). (transmitter, 24 volts).

701 to 799 are used for parts in Dynamotor DM-34-(*). (receiver, 12 volts).

801 to 899 are used for parts in Dynamotor DM-36-(*). (receiver, 24 volts).

Table II. Channel and Crystal Frequencies

Channel	Crystal Frequency (kilocycles)	Output Frequency (megacycles)	Channel	Crystal Frequency (kilocycles)	Output Frequency (megacycles)
270	375.000	27.0	330	458.333	33.0
271	376.388	27.1	331	459.722	33.1
272	377.777	27.2	332	461.111	33.2
273	379.166	27.3	333	462.500	33.3
274	380.555	27.4	334	463.888	33.4
275	381.944	27.5	335	465.277	33.5
276	383.333	27.6	336	466.666	33.6
277	384.722	27.7	337	468.055	33.7
278	386.111	27.8	338	469.444	33.8
279	387.500	27.9	339	470.833	33.9
280	388.888	28.0	340	472.222	34.0
281	390.277	28.1	341	473.611	34.1
282	391.666	28.2	342	475.000	34.2
283	393.055	28.3	343	476.388	34.3
284	394.444	28.4	344	477.777	34.4
285	395.833	28.5	345	479.166	34.5
286	397.222	28.6	346	480.555	34.6
287	398.611	28.7	347	481.944	34.7
288	400.000	28.8	348	483.333	34.8
289	401.388	28.9	349	484.722	34.9
290	402.777	29.0	350	486.111	35.0
291	404.166	29.1	351	487.500	35.1
292	405.555	29.2	352	488.888	35.2
293	406.944	29.3	353	490.277	35.3
294	408.333	29.4	354	491.666	35.4
295	409.722	29.5	355	493.055	35.5
296	411.111	29.6	356	494.444	35.6
297	412.500	29.7	357	495.833	35.7
298	413.888	29.8	358	497.222	35.8
299	415.277	29.9	359	498.611	35.9
300	416.666	30.0	360	500.000	36.0
301	418.055	30.1	361	501.388	36.1
302	419.444	30.2	362	502.777	36.2
303	420.833	30.3	363	504.166	36.3
304	422.222	30.4	364	505.555	36.4
305	423.611	30.5	365	506.944	36.5
306	425.000	30.6	366	508.333	36.6
307	426.388	30.7	367	509.722	36.7
308	427.777	30.8	368	511.111	36.8
309	429.166	30.9	369	512.500	36.9
310	430.555	31.0	370	513.888	37.0
311	431.944	31.1	371	515.277	37.1
312	433.333	31.2	372	516.666	37.2
313	434.722	31.3	373	518.055	37.3
314	436.111	31.4	374	519.444	37.4
315	437.500	31.5	375	520.833	37.5
316	438.888	31.6	376	522.222	37.6
317	440.277	31.7	377	523.611	37.7
318	441.666	31.8	378	525.000	37.8
319	443.055	31.9	379	526.388	37.9
320	444.444	32.0	380	527.777	38.0
321	445.833	32.1	381	529.166	38.1
322	447.222	32.2	382	530.555	38.2
323	448.611	32.3	383	531.944	38.3
324	450.000	32.4	384	533.333	38.4
325	451.388	32.5	385	534.722	38.5
326	452.777	32.6	386	536.111	38.6
327	454.166	32.7	387	537.500	38.7
328	455.555	32.8	388	538.888	38.8
329	456.944	32.9	389	540.277	38.9

4. Associated Items.

a. Antenna System.

(1) Mast Base MP-48 or MP-37 is used and *must be mounted in such a way that the antenna will normally be in a vertical position.* Mast Base MP-48 is equipped with a coaxial connector cable running up through the center. An antenna terminal is provided at the top of the mast base. Another terminal is provided on the lower end of the coaxial connector cable for connecting to the set by means of Wire W-128. A coaxial cable fitting is also furnished with MP-48 for the purpose of joining the lower end of the coaxial connector cable of MP-48 to a coaxial line from the set.

(2) Three mast sections (MS-51, MS-52, MS-53) must be used, except that only two mast sections (MS-52, MS-53) are to be used with Mast Base Bracket MP-52. (Mast Base Bracket MP-52 is used in half-track installations and is mounted on the top of Cabinet CH-74-A at the left front corner.) Mast joints should be tightened securely by use of gas pliers or other suitable tools, and should be taped to prevent loss of mast sections. Put on two servings of friction tape as tightly as possible. The first serving should be applied counterclockwise, starting on the lower half of the joint and taping upwards from the left to the right. If available, Clamps MC-423 and MC-424 should be used instead of tape.

(3) Wire W-128 should be used between the mast base and the set when the length of the run is less than 40 inches. Do not use more W-128 than is necessary. This wire can be connected to either the top or the bottom terminal of MP-48, or may be fed up through the center of MP-48 after removal of the center coaxial connector cable. In the latter case the maximum permissible length of W-128 is 52 inches. *The center coaxial cable must always be removed when connection is made to the top terminal; otherwise the range of the set will be reduced greatly.* When passing W-128 through the side of the vehicle, chests, etc., always insert an insulating bushing, such as IN-101 or IN-111, in the


hole to protect the wire. Wire should be run and supported in such a way that it is protected from damage and will not be subject to chafing due to vibration.

(4) Coaxial cable, Cordage CO-282, should be used between the mast base and the set when the length of run is over 40 inches. The length of CO-282 must *always* be 7 feet (plus or minus 1 foot). If 7 feet is more than is needed, tape up the excess in a coil. The sheath of CO-282 *must* be grounded at *both* ends. When MP-37 is used, a short ground lead at the mast base is required to ground the sheath. When MP-48 is used, the coaxial cable fitting that joins CO-282 to the center coaxial cable connector of MP-48 provides for sheath grounding at the mast base. When passing CO-282 through the side of the vehicle, chests, etc., always insert an insulating bushing, such as IN-101 or IN-111, in the hole. Cable should be run and supported in such a way that it is protected from damage and will not be subject to chafing due to vibration.

(5) In installations using Mast Base Bracket MP-52 mounted on top of Cabinet CH-74-A, the lead from the mast base to the binding post on Mounting FT-237-(*) will be W-128 run inside of MP-52. Coaxial cable must not be used and will be removed from MP-48, if already installed.

(6) The antenna may be tied down when the vehicle is in motion in order to clear overhead power lines and obstructions. When the vehicle is stationary, the antenna may be tied down for reasons of concealment. Remember, however, that *range and signal strength are reduced* when the antenna is tied down. For maximum range and signal strength release the antenna. The antenna may be tied down by the use of Rope RP-5, an insulator such as IN-86 or IN-87, and a short piece of flat metal. Drill holes in each end of the metal piece, slip it over the threaded part of a mast section ferrule, and assemble the joint. Tie down to a convenient point on the vehicle with the insulator placed close to the antenna mast.

Note: The radiating system, which includes the antenna and ground circuit, must be of such



dimensions that the circuits of the transmitter and the receiver can be resonated at the authorized frequencies. Make the ground connection for the antenna system through the contact between the mounting and the frame of the vehicle. Where there is no direct connection to the frame, or where the connection is unsuitable, connect it to the frame through short lengths of braided copper strap $\frac{1}{2}$ -inch wide. Make certain that there is good electrical contact at both ends of the straps and allow sufficient slack to permit free movement of the unit in the shock mounting. If your ground lead is too short, vibration will soon break it.

b. Microphones and Headsets. One Headset HS-30-(*), HS-18, or HS-23 and one Microphone T-17, T-30, or T-33 are required for each person using the equipment. Microphone T-17 is the carbon hand type, Microphone T-30 is the carbon throat type, and Microphone T-33 is the magnetic hand type. Separate jacks are provided for use with either the carbon or the magnetic type of microphone.

c. Battery Power Supply. Your radio sets operate from either a 12- or 24-volt battery power source (depending upon the transmitter and receiver dynamotors furnished; see Paragraph 10). The battery used is the one already installed in your vehicle. *You must have sufficient battery capacity and charging rate to maintain essentially full charge in the battery under all operating conditions.* The battery current required to operate all units of the radio sets is given in Table III. Keep it in mind. Don't let your battery become discharged. If it does your communications will fail and your vehicle stall.

Table III. Battery Currents

Radio Set	Battery Drain (Amperes)	
	12-Volt Battery (11-15 volts)	24-Volt Battery (22-30 volts)
SCR-608-A	28	16
SCR-628-A	24	14

5. Frequency Modulation.

a. Radio Sets SCR-608-A and SCR-628-A operate on the principle of frequency modulation.

This system of communication, which is comparatively new, has one important advantage over the older amplitude modulation systems: Within the limit of its useful range, trouble from static is greatly reduced. Of course, static is not completely eliminated, but *within* the normal 5- to 15-mile range it is much less troublesome. If static becomes strong when talking to another station, it is generally a sign that you are near the limit of your working range. (See Paragraph 20d for good and bad places for radio communication.) Some of the technical features of frequency modulation (FM) are explained in Section III of this manual. The basic idea is outlined briefly in the following paragraphs.

b. Communication is effected by modulation of the carrier frequency. That is to say, *the carrier frequency is made to vary with the loudness and pitch of the voice signal. Loud speech causes greater variation of the carrier frequency, soft speech causes less variation. High-pitched sounds cause the carrier frequency to vary more rapidly than do low-pitched sounds.* The amplitude and power of the transmitted wave remain substantially constant during modulation.

These characteristics are quite different from those of amplitude modulation such as used by Radio Sets SCR-245-(*) and SCR-299-(*) in which the *amplitude and modulating frequency* of the transmitted wave vary with the speech loudness and pitch, while the carrier frequency remains constant. Static noise is more closely related to *amplitude modulation* than it is to *frequency modulation*; therefore interference with signals is reduced through the use of frequency-modulation receiver circuits which suppress amplitude variations. This "discrimination" against received static noise gives you improved communication within your set's range. But at the *end* of your range and *beyond it*, frequency modulation cannot control static. Therefore, when static gets bad, you're either at the end of your range, or your receiver isn't getting much of a signal from the station you are trying to hear.

The methods employed for modulation and demodulation are explained in Paragraphs 23 and 24 of this technical manual.




Fig. 4. Mounting FT-237-(*): Oblique Front View




Fig. 5. Mounting FT-237-(*): Details

6. Mounting FT-237-(*).

a. General. This mounting (Fig. 4), will hold either:

(1) Radio Set SCR-608-A. One Radio Transmitter BC-684-A and two Radio Receivers BC-683-A.

(2) Radio Set SCR-628-A. One Radio Transmitter BC-684-A and one Radio Receiver BC-683-A.

The transmitter must be installed in its allotted place at the left end of the mounting, but the receiver may be installed in either of the two right-hand positions. Each unit is secured to the mounting by thumbscrew clamps and may be quickly removed without tools.

Dust covers are provided for protection of the unused receptacles. Screw the dust covers to the rear of the mounting when removed from the receptacles. (See Fig. 4.)

A reversible nameplate bearing the words BATTERY VOLTAGE 12 V on one side, and BATTERY VOLTAGE 24 V on the other side, is screwed to the front of the mounting near the right-hand end. (This plate will normally show BATTERY VOLTAGE 12 V for Radio Sets SCR-608-A and SCR-628-A. Don't reverse the nameplate unless 24-volt operation is authorized.)

b. Fastening of Mounting. Secure the mounting to the vehicle frame or other support by bolts passed through two heavy bedplates on the mounting. There are four bolt holes in each bedplate.

Each bedplate supports the mounting through two sets of rubber shock absorbers. In addition, two rubber snubbers on each bedplate prevent excessive movement of the equipment on the mounting. Electrical bonding straps are connected across each rubber shock absorber to provide a good ground connection to the bedplates.

c. Terminals. There are two terminals at the left end of the mounting. Connect the antenna system to the terminal designated TR for radio transmission and reception (Radio Sets SCR-608-A and SCR-628-A) or to the terminal designated REC for reception only. A ground terminal

is provided by a screw on the mounting. Later mountings have a ground binding post located near the antenna terminals for grounding the sheath of coaxial cable (Cordage CO-282).

A door in the base plate of the mounting permits access to the battery fuse (F401), and a terminal strip (TS401). (See Fig. 5.) One of the spare battery fuses is held in a clip on the under side of the door. The positive battery connection is made at the right-hand end of fuse F401. The negative battery connection is made at a screw on the under side of the mounting base plate, which is marked x in Fig. 5. Three methods of running the battery cable, through the right end, front, or rear of Mounting FT-237-(*), are illustrated in Fig. 3.

d. Interconnections Between Units. All connections between the transmitter and receiver units and the mounting are made through multi-contact plugs and receptacles which are automatically engaged when the units are inserted into their proper positions on the mounting. The wiring between receptacles is enclosed in a trough along the rear and left end of the mounting.

7. Radio Receiver BC-683-A.

a. Description of Functions. Radio Receiver BC-683-A is of the superheterodyne type and is intended for reception of frequency-modulated signals within the range of 27.0 to 38.9 megacycles. The receiver can deliver an output of approximately 2 watts to its self-contained loudspeaker or about 200 milliwatts to its headset circuits.

A front view of the receiver is shown in Fig. 6 and an oblique rear view is shown in Fig. 7.

The receiver is turned to ON or to OFF by the switch marked REC.

The front panel contains ten push buttons by means of which any one of ten preadjusted channels may be selected immediately, much the same as any home "touch-tuning" radio. When a push button is fully depressed, it catches and is held in until another push button is partially depressed, at which time the first push button releases and the selector mechanism is disengaged. When the selector is disengaged (all push but-



Fig. 6. Radio Receiver BC-683-A: Front View

tions released), the receiver may be tuned by pushing the **PUSH TO TUNE** push button while rotating the **TUNING** control.

Two jacks, marked **PHONES**, are provided for headset operation. The output of the receiver may be connected to the headset circuit by throwing the **OUTPUT TO PHONES** switch to **ON**. When the **OUTPUT TO PHONES** switch is at **OFF**, the headset circuit is disconnected from the radio receiver. The loudspeaker, however, will still be connected to the receiver output. To use the loudspeaker, place the **SPEAKER** switch at **ON**. Regulate the headset and loudspeaker volume by adjusting the **VOLUME** control.

A noise suppression or "squell" circuit is switched on or off by the **SQUELCH** switch. When the **SQUELCH** switch is at **ON**, the sensitivity of the receiver is adjusted by the **SENSITIVITY** con-

trol. When the **SQUELCH** switch is at **OFF**, the receiver sensitivity is restored to maximum and cannot be adjusted.

The **CALL SIGNAL** lamp indicates that a signal is being received provided the **SQUELCH** switch is at **ON** and the **SENSITIVITY** control has been adjusted to prevent operation of the squelch circuit by received noise.

The **TUNE-OPERATE** switch starts a preset intermediate-frequency oscillator when at **TUNE** to assist in the adjustment of the channel selector mechanism or to aid in tuning to weak signals. The intermediate-frequency oscillator is also used when aligning or servicing the receiver.

Active and spare fuses are contained in the two fuse receptacles designated **FUSE** and **SPARE**.

Antenna and ground binding posts, designated **A** and **G**, are provided for testing purposes and special services. These connections are not used when the receiver is installed for operation.

To remove the receiver dust cover turn the fastener on the rear of the cover (see Fig. 7) one-fourth turn to the left and slide the cover off the rear of the receiver. Figure 8 is a view of the left-hand side of the receiver, and Fig. 9 shows the right-hand side of the receiver after removal of the dust cover. Figures 10 and 11 show the receiver push button assembly, viewed from the right side and the front respectively.

b. Power Supply. Radio Receiver BC-683-A is issued with Dynamotor DM-34-(*) for operation from a 12-volt vehicle battery. If authorized, the receiver may be operated from a 24-volt vehicle battery by merely substituting Dynamotor DM-36-(*) in place of Dynamotor DM-34-(*). This is the only change necessary since a multi-contact jack on the base of each dynamotor is wired to make the necessary circuit changes.

8. Radio Transmitter BC-684-A.

a. Description of Functions. The transmitter operates in the frequency band from 27.0 to 38.9 megacycles and delivers a nominal power output of 20 watts to its antenna system. The carrier is frequency-modulated. A maximum frequency deviation of plus or minus 80 kilocycles (total frequency swing, 160 kilocycles) can be ob-




Fig. 7. Radio Receiver BC-683-A; Oblique Rear View




Fig. 8. Radio Receiver BC-683-A: Left-hand Interior View






Fig. 9. Radio Receiver BC-683-A: Right-hand Interior View



RIGHT-SIDE VIEW

Fig. 10. Radio Receiver BC-683-A: Push-button Assembly, Right-side View



FRONT VIEW

Fig. 11. Radio Receiver BC-683-A: Push-button Assembly, Front View




Fig. 12. Radio Transmitter BC-684-A: Front View with Crystal Compartment Open




Fig. 13. Radio Transmitter BC-684-A: Assembly and Exploded View of Crystals

tained; ordinarily, however, the frequency deviation is much less than this. Under most operating conditions the deviation, even on voice peaks, is less than plus or minus 40 kilocycles (total swing, 80 kilocycles).

A front oblique view of the transmitter is shown in Fig. 1 (large unit at the left). Figure 12 is a closer front view and Fig. 13 shows assembly and exploded views of typical crystals. A view of the right-hand end of the transmitter showing the various controls and access openings is given in Fig. 14.

The front panel contains ten push buttons by means of which any of ten preadjusted transmitting channels may be immediately selected. This operates exactly like the push-button type of broadcast radio for the home. Like the receivers, you merely push one of several buttons on the front of the set to select the channel you want. Antenna and ground binding posts, designated A and G, are provided for test purposes, and they are not normally used when the transmitter is installed for operation. The RECEIVER TUNE-OPERATE switch makes it possible to use the transmitter as a source of known signal frequency for adjustment and testing of associated radio receivers. The transmitter filaments and relay circuits are energized by the ON-OFF switch and

transmission is started by operating the control switch on the operator's microphone. The pilot lamp lights when the TRANSMITTER switch is ON. Plug microphones of the carbon type, such as Microphone T-17 and Microphone T-30, in the CARB MIC jack. Connect Microphone T-33, which is of the magnetic type, at the MAGNETIC MIC jack.

Active and spare fuses are contained in the two fuse receptacles designated FUSE and SPARE.

The panel meter may be connected in various circuits by means of the TUNE-ANT CUR switch on the panel and the six-position METER SWITCH (Fig. 14) to observe transmitter output and circuit operating conditions. The meter is not calibrated in milliamperes or other standard unit of measure as it is used only as an indicator of relative current flow.

The SIDETONE control shown in Fig. 14 adjusts the volume of transmitted speech heard in the operator's headset. The ten screwdriver-operated controls are for antenna tuning adjustments.

Remove the top or bottom cover plates for access to the interior of the transmitter. Figure 15 is a view of the interior with the top cover plate removed. Figures 16 and 17 show the transmitter push-button assembly viewed from the left and from the right side respectively. A view of the interior with the bottom cover plate removed is shown in Fig. 18.

b. Power Supply. Radio Transmitter BC-684-A is furnished with a dynamotor, Dynamotor DM-35-(*), suitable for operation from a 12-volt vehicle battery. If authorized, the transmitter may be operated from a 24-volt vehicle battery by merely substituting Dynamotor DM-37-(*), in place of Dynamotor DM-35-(*). This is the only change necessary, since a multicontact jack on the base of each dynamotor is wired to make the necessary circuit changes. *The design of Dynamotors DM-35-(*), and DM-37-(*), is based on an average duty cycle of 5 minutes on and 15 minutes off at high temperatures. Don't operate the transmitter dynamotors continuously over long periods. You might burn out your dynamotor.*




Fig. 14. Radio Transmitter BC-684-A: Right-hand End View with Cover Plate Removed






Fig. 15. Radio Transmitter BC-684-A: Interior View with Top Cover and Dynamotor Removed



LEFT-SIDE VIEW

Fig. 16. Radio Transmitter BC-684-A: Push-button Assembly, Left-side View



RIGHT-SIDE VIEW

Fig. 17. Radio Transmitter BC-684-A: Push-button Assembly, Right-side View




Fig. 18. Radio Transmitter BC-684-A: Interior View with Bottom Cover Removed




Fig. 19. Remote Control Unit RM-29-D; Front View




Fig. 20. Remote Control Unit RM-29-D; Interior View




Fig. 21a. Dynamometer DM-34-(*) or Dynamometer DM-36-(*)




Fig. 21b. Dynamometer DM-34-(*) or Dynamometer DM-36-(*): Sub-base View

9. Remote Control Unit RM-29-D.

Note: The information regarding Remote Control Unit RM-29-D in this and subsequent paragraphs is given to assist radio operators in setting up Radio Sets SCR-608-A and SCR-628-A for remote control operation. Do not regard this information as complete, but refer to Technical Manual TM 11-308, covering the remote control unit, for detailed information and instructions.

a. Description of Functions. Remote Control Unit RM-29-D provides for remote control of the radio equipment and operates in conjunction with Telephone EE-8-(*) over a two-wire telephone line. A front view of the remote control unit is shown in Fig. 19, and an internal view with the housing removed is shown in Fig. 20.

Two plug-terminated cords are provided to connect the remote control unit to the radio transmitter and radio receiver. The two-wire telephone line from the remotely located field Telephone EE-8-(*) terminates at binding posts L1 and L2 on the remote control unit. Microphone T-17 and a headset, when plugged into the remote control unit, are used for transmission and reception of signals via the radio set, for monitoring signals between the telephone and the radio set, and for direct communication with Telephone EE-8-(*).

The three modes of operation are selected by the switch marked RADIO-THROUGH-TELEPHONE on the front of the remote control unit. Operation is as follows:

(1) *Switch at RADIO.* The radio set is controlled entirely by the operator stationed at the remote control unit, with the switch at RADIO. The operator can transmit and receive signals via the radio set.

(2) *Switch at THROUGH.* The radio set is still under control of the operator at the remote control unit with the switch at THROUGH. However, this operator can no longer transmit via the radio set, but can only monitor all signals passing over the line, both from the radio receiver to any Telephone EE-8-(*) connected to the telephone line from the remote control unit, and from any telephone to the radio transmitter.

(3) *Switch at TELEPHONE.* The remote control unit functions as a telephone very similar to Telephone EE-8-(*) with the switch at TELEPHONE, and the operator can communicate with any telephone connected to the telephone line, but is disconnected from the radio equipment.

b. Power Supply. One Battery BA-27 (4½ volts) is mounted inside the remote control unit for operation of Microphone T-17. The current drain from this battery is from 50 to 95 milliamperes, depending on the position of the microphone.

10. Dynamotors DM-34-(*), DM-35-(*), DM-36-(*), DM-37-(*).

a. Dynamotors DM-34-() and DM-36-(*)*. Each of these dynamotors provides about 200 volts for operation of the receiver. The dynamotors are of similar appearance; and two views are shown in Fig. 21a and Fig. 21b. The dynamotors are totally enclosed. Their armatures are dynamically balanced and are supported by two single-race ball bearings. Both dynamotors are shunt wound. The primary and secondary windings are wound in the same armature slots, but the two windings are brought out to separate commutators mounted on opposite ends of the armature shaft.

b. Dynamotors DM-35-() and DM-37-(*)*. Each of these dynamotors provides approximately 625 volts for operation of the transmitter. The dynamotors are of similar appearance; and two views are shown in Fig. 22a and Fig. 22b. Except for screened breathing vents in the end covers, the dynamotors are totally enclosed. The screened holes have been omitted in later dynamotors to reduce the entrance of dust or sand. This does not affect the power rating of the dynamotors. Their armatures are dynamically balanced and are supported by two single-race ball bearings. Both dynamotors are compound wound. The primary and secondary are wound in the same armature slots, but the two windings are brought out to separate commutators mounted on opposite ends of the armature shaft.




Fig. 22a. Dynamometer DM-35-(") or Dynamometer DM-37-(")




Fig. 22b. Dynamometer DM-35-(") or Dynamometer DM-37-("): Sub-base View

c. **12- or 24-Volt Operation.** Dynamotor DM-34-(*) for the receiver and Dynamotor DM-35-(*) for the transmitter are designed for operation from a 12-volt vehicle battery supply. These dynamotors are issued with Radio Sets SCR-608-A and SCR-628-A which will normally be operated from a 12 volt battery. However, as mentioned in Paragraphs 7b and 8b, the receiver and transmitter can be operated in vehicles having a 24-volt battery supply. To do this, it is only necessary to substitute Dynamotors DM-36-(*) and DM-37-(*) for Dynamotors DM-34-(*) and DM-35-(*) in the receiver and transmitter, respectively. Dynamotors DM-36-(*) and DM-37-(*) operate from a 24-volt battery supply.

11. **Cabinet CH-74-A.** Cabinet CH-74-A is a protective housing for the radio equipment in installations where the equipment would otherwise be exposed to the elements (see Fig. 1). Cabinet CH-74-A is supported within the vehicle by Mounting FT-284-(*), Mounting FT-285-(*), or Frame FM-43, depending upon which vehicle is being used. Mounting FT-237-(*) is bolted in place in the cabinet. The top of the cabinet extends somewhat over the front of the radio equipment. A canvas cover assembly is provided for the front of the cabinet to completely enclose the radio equipment, if desired. The canvas cover may be rolled back over the top of the cabinet, or it may be supported by a bracket which telescopes into the top of the cabinet. Except in an emergency, do not operate the equipment during hot weather with the canvas cover completely closed. *Even in an emergency, do not operate either the transmitter or the receiver long enough for the equipment to overheat before the cover is raised.*

12. **Mountings FT-284-(*) and FT-285-(*) and Frame FM-43.** Mountings FT-284-(*) and FT-285-(*) and Frame FM-43 are used to support Cabinet CH-74-A in vehicles where the cabinet is used. The choice among these mountings depends upon the particular vehicle in which the radio equipment is to be installed. (See Paragraph 3b.) Figure 1 shows an installation using Mounting FT-284-(*).

13. Mast Bases.

a. **Mast Base MP-37.** This mast base provides an insulated and flexible mounting for the antenna; it is rigidly mounted on the vehicle but includes a large helical spring for flexibility. Mast Section MS-53, the largest, screws into this base.

b. **Mast Base MP-48.** Another way to have a flexible antenna support is to use Mast Base MP-48. Use this base with a coaxial transmission line such as Cordage CO-282. Two binding posts permit use of a single wire lead (Wire W-128).

14. **Mast Base Bracket MP-52.** Mast Base Bracket MP-52 serves to support an antenna and mast base about two feet above Cabinet CH-74-A. Clamp the mast base to the bracket cover plate and bring the antenna lead down through insulating guides into the cabinet for connection to the radio equipment. The bracket is fastened to the cabinet by 12 bolts. (See Fig. 1.)

15. **Mast Sections.** Mast Sections MS-51, MS-52, and MS-53 are used with these radio sets, except that only two mast sections (MS-52, MS-53) are to be used with Mast Base Bracket MP-52. (Mast Base Bracket MP-52 is used in half-track installations and is mounted on the top of Cabinet CH-74-A at the left front corner.) The mast sections are made of high-tensile-strength flexible steel. Mast Section MS-51 is the top (and smallest) section. The others follow in numerical order. The lower end of each mast section is fitted with a serrated (notched) shank and screw for engaging the threaded upper end of the next mast section. Ends which are joined in assembling have enamel marks of the same color. The body of each section is enameled black and bears the type number at the lower end. The lower end of each mast section has an entering guide to aid assembly. Store the mast sections in Roll BG-56-A when not in use.

16. Cords and Cordage.

a. **Cord CO-278-A.** Cord CO-278-A is used to connect Mounting FT-237-(*) to the terminal box (battery) of the vehicle. It consists of 8 feet

of Cordage CO-212 to which connection terminals have been soldered. The inner conductor is connected to the positive side of the battery and the outer conductor is grounded.

b. Cord CD-307-A. Cord CD-307-A in two lengths, 48 inches and 65 inches, extends the radius within which the crew of the vehicle may receive signals in their headsets. Plug PL-55 at one end of Cord CD-307-A plugs into the radio receiver. The headset plug is connected into Jack JK-26 at the other end of Cord CD-307-A.

c. Cord CD-318. Cord CD-318 is a 7-foot cord assembly for connection between the short cord supplied with Microphone T-30 and the radio equipment or a remote control box. The assembly includes Switch SW-141-E for control of the microphone current, provided with a neck strap for its support. The neck strap quickly detaches from the switch.

d. Cord CD-786. The auxiliary Cord CD-786 provides for making thirteen connections to a receiver or transmitter when not installed in the mounting. One such use is testing a receiver on a bench. The cord consists of

(1) A male plug for insertion in the socket J401, J402, or J403 of Mounting FT-237-(*).

(2) A receptacle for connection to the plug PG1 of the receiver, or PG101 of the transmitter.

(3) Six feet of cordage containing conductors to connect corresponding numbers in these two plugs.

Terminals 1 and 2 of the plug are connected to corresponding numbers in the receptacle by 10-gauge stranded wires. This constitutes the power connection and is suitable for carrying several amperes. A 22-gauge twisted, shielded pair of stranded wire is used for terminals 4 and 5. The other terminals used are numbers 7, 8, 9, 10, 19, 20, 21, 22, and 25.

e. Cordage CO-212. Cordage CO-212 is composed of two concentric conductors and is used in making Cord CO-278-A. Cordage CO-212 is supplied in bulk lengths and is used to replace damaged Cords CO-278-A or where a longer cord is needed. The cordage is installed so that the inner conductor is positive and the outer conductor is at ground potential.

f. Cordage CO-282. Cordage CO-282 is a flexible two-conductor coaxial cordage intended for transmission of high-frequency currents. It is used in all installations of Radio Sets SCR-608-A and SCR-628-A where the distance between the binding post on Mounting FT-237- (*) and the mast base is more than 40 inches. The length of Cordage CO-282 must *always* be 7 feet (plus or minus 1 foot). If 7 feet is more than is needed, tape up the excess in a coil. Be sure to ground the sheath at both ends.

SECTION II. INSTALLATION AND OPERATION

17. Initial Procedure.

a. Unpacking. Check the containers before opening them. Be careful when unpacking or handling the equipment. Avoid damage. Carefully inspect each unit for damage incurred in shipment and for loose parts. Remove all dust covers and inspect the interiors. *Very carefully* blow or brush out any dust or dirt. If an air gun is used, be sure that the air is free from water, oil, and grit. *Avoid displacing or damaging any apparatus or wiring.* Manually check operation of the push buttons and other controls on each unit.

b. Preparation for Installation.

(1) Determine whether the vehicle battery is 12 or 24 volts and set the reversible voltage designation plate on the front of the mounting so that it properly describes the battery in use. (See Fig. 4.)

(2) Open the hinged door on the mounting and check for the presence of a 75-ampere fuse in the circuit and in the spare fuse clip on the door. (See Fig. 5.)

(3) Remove the unnecessary dust covers from the receptacles on the mounting and mount them in the positions provided at the back of the mounting.

(4) Using Table IV, select the proper dynamotor for installation in each of the units.

Table IV. Selection of Dynamotors

Unit in Which Dynamotor is Required	Dynamotor for Use With a Vehicle Battery of	
	12 Volts	24 Volts
Receiver	DM-34. (*)	DM-36. (*)
Transmitter	DM-35. (*)	DM-37. (*)

(5) Remove the dust cover from the receiver, insert the proper dynamotor in place, and make certain that the dynamotor receptacles properly engage the plugs on the receiver. Tighten the four hold-down screws of the dynamotor and replace the receiver dust cover.

(6) Remove the top cover plate from the transmitter. Take out the crystal storage drawer by pulling the drawer all the way out and lifting up the front end. Insert the proper dynamotor and make certain that the dynamotor receptacles properly engage the plugs on the transmitter. Tighten the four hold-down screws, using a long, thin screwdriver. Replace all parts that were removed.

(7) Open the cover of the transmitter crystal storage drawer and remove the crystal compartment cover plate. Check the number of crystal holders in both places. Do not remove any crystals found in the crystal compartment, since they will be used for subsequent installation tests.

18. Installation.

a. Preparation of Vehicle. Detailed information on installation of the radio sets in various types of vehicles are to be found in the installation instructions for the particular type of vehicle concerned.

b. Installation of Equipment.

(1) Check the vehicle battery and the battery designation plate on the mounting. Shine up the contact areas around the mounting bolt holes on the mounting and the corresponding areas on the vehicle or the adapter plate to insure a good contact when the mounting bolts are tightened. *A good ground connection must be made at these points or the radio set will not function properly. Watch this.* Place the mounting in its assigned position with the bolt holes in the two bedplates aligned with the holes in the vehicle or the adapter plate. Select the required mounting bolts from the bolts furnished with the mounting and tighten them firmly in place.

(2) Install Cord CO-278-A, which connects the mounting to the vehicle terminal box, in the mounting in a manner to prevent its damage by personnel (especially by their feet) and by movement of the mounting on its shock absorbers. Three sets of holes in the mounting



**DON'T DESIGN YOUR OWN ANTENNA!
—STICK TO WHAT'S RECOMMENDED**

make possible the entrance of Cord CO-278-A from any one of three directions, as shown in Fig. 3. Use the holes which will result in the cleanest and shortest installation. The center conductor connects to the *positive* or ungrounded side of the terminal box. The outer conductor connects to the *negative* or grounded side of the terminal box. One end of the cord has smaller terminal lugs than the other end. Connect the smaller lugs to the mounting with the lug on the center conductor connecting to fuse F401 and the lug on the outer conductor connecting to the ground screw on the mounting (marked x in Fig. 5). *Do not connect the battery (terminal box) end of Cord CO-278-A without checking for accidental ground on the mounting. Check the polarity.*

(3) Antenna and ground connections differ somewhat for each type of vehicle, but make the installation in accordance with the general information contained in Paragraph 4a. The TU binding post on Mounting FT-237-(*) is used for the antenna connection when both transmission and reception are desired. Use the REC binding post for reception only.

(4) Check the dynamotor installed in the transmitter to make sure it is of the proper type

for the vehicle battery voltage. If not, replace the dynamotor with one of the proper voltage rating. Replace the cover plate. Place the transmitter on the mounting base with the push buttons toward the front of the mounting. Slide the transmitter to the left until the transmitter plug firmly engages the receptacle on the end of the mounting. The guides and tapered pins on the mounting properly align the transmitter as it is pushed into place. The two thumbscrews at the right-hand end of the transmitter may then be pressed down to engage the threaded holes in the mounting and firmly turned to the right to lock the transmitter in place.

(5) Make certain that the dynamotor installed in each receiver is correct for the vehicle battery employed. If two receivers are to be used (Radio Set SCR-608-A), they may be placed in either of the two positions on the mounting (see Fig. 1). When only one receiver is used (Radio Set SCR-628-A), place it in the right-hand position to give yourself enough room to get at the adjustments on the right end of the transmitter (see Fig. 2). Slide the receiver toward the rear of the mounting until its plug engages with the receptacle. The tapered pins properly align the receiver to engage the receptacle. Engage the cupped edges of the thumbscrews on the mounting with the hold-down brackets. Then tighten the thumbscrews.

(6) To install Remote Control Unit RM-29-D follow the instructions provided with this unit.

19. Preparation for Use.

a. Receiver.

(1) *Performance Check.* Here's how to check receiver performance:

(a) Turn the REC switch to ON and make certain that the receiver dynamotor starts. After about 15 seconds the vacuum tubes will be heated sufficiently for operation of the receiver.

(b) Set the SPEAKER switch to ON, the SQUELCH switch to OFF, and the OUTPUT TO PHONES switch to ON. Plug a Headset HS-30-

(*) HS-18, or HS-23 into one of the PHONE jacks.

(c) Turn the VOLUME control all the way to the right. If it's on the air, you should hear noise, or a signal, from the loudspeaker and in the headset. The volume of sound may be varied by adjusting the VOLUME control. The CALL SIGNAL lamp should light.

(d) Turn the SQUELCH switch to ON and observe the CALL SIGNAL lamp while turning the SENSITIVITY control. It should be possible to extinguish the CALL SIGNAL lamp by turning the SENSITIVITY control to the left; the CALL SIGNAL lamp may not always light when no signal is being received. The noise, or signal, from the loudspeaker should cease whenever the CALL SIGNAL lamp goes out.

(e) Turn the SQUELCH switch to OFF and listen to the noise while pressing the PUSH TO TUNE push button and operating the TUNING control. Noise or signals should be heard at any dial setting. An unmodulated signal (a station on the air but not talking) will sometimes cause a reduction of noise at one dial setting. The noise should increase as the dial is turned either side of such a station.

(2) *Receiver Antenna Tuning.* In making the following adjustments, place the receiver in the vehicle and connect the antenna. Don't let the antenna touch anything and locate your vehicle in the open, but *only* to the extent permitted by camouflage requirements.

(a) Install the receiver in the *right-hand* position on the mounting and set the ON-OFF switch to ON. The *left-hand* position must be vacant.

(b) Set the SQUELCH switch to OFF and the TUNE-OPERATE switch to OPERATE.

(c) Set the SPEAKER switch to ON. (If you wish you may use a headset instead of the loudspeaker, in which case set the SPEAKER switch to OFF and the OUTPUT TO PHONES switch to ON.)

(d) Release the push buttons (see Paragraph 7).

(e) Manually tune the receiver to a frequency near the high-frequency end where there

is *noise* (not a signal). To manually tune the receiver hold in the PUSH TO TUNE button and rotate the TUNING control.

(f) Adjust the VOLUME control so that noise is just audible.

(g) Adjust the antenna trimmer (accessible through port hole on left side of receiver) for maximum noise in your headset or loudspeaker. Use a small insulated screwdriver or an insulated hexagonal socket wrench.

(h) Set the ON-OFF switch to OFF.

b. Transmitter. Here's how to check transmitter performance:

(1) Remove the antenna lead from the antenna post on the mounting and connect Antenna A-83 between the TR binding post and the ground screw on the mounting.

(2) Connect either Microphone T-17 or T-33 to the transmitter.

(3) Throw the RECEIVER TUNE-OPERATE switch to OPERATE, and the TUNE-ANT CUR switch to ANT CUR.

(4) Turn the TRANSMITTER switch to ON and see that the pilot lamp lights.

(5) After about three seconds, depress a channel selector push button, and press the microphone switch. The transmitter dynamotor should start and the panel meter should show a deflection or movement. Release the microphone switch.

(6) Repeat step (5) on all remaining channels.

(7) Throw the TUNE-ANT CUR switch to TUNE and note the meter reading for each position of the METER SWITCH. The readings should agree approximately with those given in Table V. (See Paragraph 31e(11) for a detailed discussion.)

(8) Start an associated receiver, plug a Headset HS-30(*), HS-18, or HS-23 into the receiver PHONES jack, and throw the OUTPUT TO PHONES switch to OFF. Operate the microphone push button and speak into the microphone. The

Table V. Meter Switch Readings*

Switch position	1	2	3	4	5	6
Circuit	Doubler Grid	First R-f Grid	Rectifier Grid	Tripler Grid	Power Amplifier Grid	Total Plate and Screen
Meter reading (27.0 mc)	30	30	20	20	15	65
Meter reading (38.9 mc)	20	25	25	25	15	65

*Transmitter RECEIVER TUNE-OPERATE switch at OPERATE.

speaker's voice should be heard in the headset. The headset volume may be adjusted to the desired level by turning the SIDETONE control on the end of the transmitter.

(9) Press in a channel selector push button on the transmitter, and throw the transmitter RECEIVER TUNE-OPERATE switch to RECEIVER TUNE. The transmitter dynamotor should start when this latter switch is operated.

Caution: Don't run the dynamotor for long periods. It may overheat.

(10) Manually tune the associated receiver to the transmitter channel frequency. Throw the SPEAKER switch to ON.

(11) Operate the microphone switch and speak into the microphone. The speaker's voice should be heard in the receiver loudspeaker at a receiver dial setting within about one-half a channel of the transmitter frequency. Restore the transmitter RECEIVER TUNE-OPERATE switch to OPERATE.

c. Frequency Check on Receiver Dial.

(1) Throw the transmitter and the receiver ON-OFF switches to ON.

(2) Throw the receiver TUNE-OPERATE switch to TUNE.

(3) Throw the SPEAKER switch to ON and turn the VOLUME control to the right.

(4) Throw the SQUELCH switch to ON and set the SENSITIVITY control to minimum.

(5) Latch (depress) corresponding transmitter and receiver push buttons.

(6) Set the transmitter RECEIVER TUNE-

OPERATE switch to RECEIVER TUNE. A beat note should be heard and the receiver dial setting should correspond to the transmitter frequency within one half a dial division.

(7) If a beat note is not obtained hold in the PUSH TO TUNE button and rotate the dial slightly to obtain a beat note.

(8) Repeat steps (5) through (7) for the remaining push buttons, noting all channels upon which note is not obtained.

(9) Reset all receiver and/or transmitter push buttons for channels upon which a beat note is not obtained (see Paragraph 21).

(10) If practical, check settings by establishing communication with another vehicle.

d. System Test. Whenever practicable, check operation of the installation by establishing communication with another radio set.

20. Operation. This paragraph describes procedures for placing the receiver and transmitter in operation, assuming that the push button selectors are adjusted to select the ten desired channels. If it is necessary to change the channels selected by the push buttons of the receiver or transmitter, follow the procedures in Paragraph 21 before operating the equipment.

a. Operation of the Receiver. You may operate the receiver with the SQUELCH switch at either ON or OFF. The squelch circuit controlled by the SQUELCH switch functions to disable the receiver output when no signal is being received; undesirable background noise is thus eliminated during "no-transmission" intervals.

(1) **SQUELCH Switch at OFF.** For loud-

speaker reception, throw the **SPEAKER** switch to ON, turn the **VOLUME** control to the extreme right, and throw the **TUNE-OPERATE** switch to **OPERATE**. For headset reception, plug the headset into a **PHONES** jack, throw the **SPEAKER** switch to OFF, turn the **VOLUME** control to the extreme left, set the **TUNE-OPERATE** switch to **OPERATE**, and the **OUTPUT TO PHONES** switch to ON.

To start the receiver, throw the **REC** switch to ON. It takes about 15 seconds for the vacuum tube cathodes to heat. If the receiver controls are set for loudspeaker operation, noise (or possibly a signal) will be heard when the tubes have heated. Regulate the volume with the **VOLUME** control. If the receiver controls are set for headset operation, and sufficient time has elapsed for the tubes to heat, noise (or a signal) will be heard upon advancing the **VOLUME** control.

Depress the push button corresponding to the channel upon which reception is desired. The **TUNING** adjustment is supplementary to the selector push buttons, the selector having previously been set to the desired channels. However, the receiver may be manually tuned to any desired channel by releasing all push buttons (see Paragraph 7) and adjusting the **TUNING** control while pushing the **PUSH TO TUNE** button. Tuning is facilitated in this case by throwing the **TUNE-OPERATE** switch to **TUNE** and adjusting the **TUNING** control for a beat note at the transmitter frequency. When the tuning is correct, restore the **TUNE-OPERATE** switch to **OPERATE**.

(2) **SQUELCH Switch at ON.** When the **SQUELCH** switch is at ON, the gain of the receiver may be varied by adjusting the **SENSITIVITY** control. (With the **SQUELCH** switch at OFF, the receiver operates at full gain and the **SENSITIVITY** control is inoperative.) When the squelch circuit is used (**SQUELCH** switch at ON), adjust the **SENSITIVITY** control for the highest possible gain without operation of the **CALL SIGNAL** lamp and loudspeaker (or headset) by radio noise. Incorrect adjustment of the **SENSITIVITY** control reduces the operating range of the receiver. If there is any doubt about the **SENSITIVITY** adjustment, throw the **SQUELCH** switch to OFF. When re-

ceiving weak signals throw the **SQUELCH** switch to OFF and leave it there. Don't take a chance. If it isn't adjusted on the nose you may miss incoming calls.

For proper adjustment with the **SQUELCH** switch at ON, set the **SENSITIVITY** control as far to the right as possible for satisfactory operation. When receiving a weak signal (as evidenced by static with the incoming signal) rotate the **SENSITIVITY** control carefully to the left until the **CALL SIGNAL** light just goes out as soon as the incoming signal goes off the air. The **SENSITIVITY** control setting is correct if the **SQUELCH** switch may be thrown off and on again without interrupting a weak signal.

b. Operation of the Transmitter. Here's how to put the transmitter in operation:

(1) Set the **TUNE-ANT CUR** switch to **ANT CUR**. (Large differences between the meter readings as observed during operation of the transmitter on various channels and the readings noted when the transmitter was tuned up indicate trouble.)

(2) Start the transmitter by throwing the **TRANSMITTER** switch to ON. Allow about five seconds for the tube filaments to heat.

(3) Plug Microphone T-17 or T-30 into the **CARB MIC** jack, or Microphone T-33 into the **MAGNETIC MIC** jack.

Caution: Always make sure a **CHANNEL SELECTOR** push button is depressed before pressing the microphone switch. Remember this.

(4) Put the transmitter "on the air" by first latching the **CHANNEL SELECTOR** push button corresponding to the desired channel, and then pressing the microphone switch.


(5) Turn the **TRANSMITTER** switch to OFF when finished sending if the stand-by period is likely to exceed three or four minutes. This will prolong tube life.

c. Operation of the Remote Control Unit. For information regarding operation of Remote Control Unit RM-29-D, refer to Technical Manual TM 11-308 furnished with this unit.


THESE PLACES ARE BAD FOR RADIO !




VALLEY



HIGH TENSION LINES



STEEL BRIDGE



UNDERPASS

THESE PLACES ARE GOOD FOR RADIO !



LEVEL GROUND



SLIGHT RISE



HILL

IBC-56

d. Operating Precautions.

(1) *Transmission Conditions.* The range at which your radio set will work depends on terrain, interference, and radio noise. Under most conditions you should expect 5 to 7 miles *except* in valleys, and under or close to underpasses, overhead steel bridges, and other obstructions which box-in your signals.

Dips, depressions, valleys, and low places are poor for radio transmission and reception. The surrounding higher terrain tends to absorb radio energy.

Good places for sending and receiving are hills, elevations, and slight rises in ground. Flat terrain is also good. But avoid high-tension lines, overhead wires, and locations near electrical machinery which create interference and may blot out even the best of reception. In general, your radio works best in the clear.

You can conceal your vehicle under trees or camouflage, however. Trees and shrubbery won't cut your range. But don't let your aerial rest on



DON'T EXPECT DISTANCE FROM A VALLEY!



DON'T LET YOUR ANTENNA REST AGAINST BRANCHES! THEY'LL CUT YOUR RANGE...

branches or shrubbery when sending or receiving. They will leak off your radio power.

Here's another good operating tip to remember: When you come to the fringe of your operating range—say 10 miles out—static and ignition noise may begin to blot out your reception. If you can do it, try shutting off your vehicle's motor. You'll hear farther. But your battery must be well-charged as your radio draws heavily on it. Keep this in mind if you need a mile or two more range.

(2) *Overheating.* If the entire equipment is mounted in a tightly-enclosed space without enough ventilation, there is danger of overheating after extended periods of operation. Try to operate the equipment for as short intervals as practicable under such conditions.

(3) *Receiver.* Take care when using the squelch circuit and adjusting the SENSITIVITY control. Improper use of these features will result in seriously reducing the range of the set. If there is any doubt whatever about use of the SQUELCH, turn it to OFF and reduce the receiver output

volume sufficiently to prevent fatigue on long stand-by periods but not enough to prevent hearing a signal. Watch this. For weak signals and important incoming calls turn the SQUELCH to OFF and leave it at OFF. Don't take a chance.

(4) *Transmitter.* Always press a CHANNEL SELECTOR push button before starting the dynamotor by operating the microphone control switch or by throwing the RECEIVER TUNE-OPERATE SWITCH to RECEIVER TUNE.

Operation of the transmitter filaments for long periods without application of plate voltage tends to evaporate the active material from their surface and reduce their useful life. Therefore, the TRANSMITTER switch should be at OFF if the transmitter is not to be used for an extended period.

(5) *How to Use Your Microphone.* These radio sets have been designed to work under noisy conditions such as in a tank or other noisy vehicle. To get best results, hold the microphone in a nearly vertical position with your lips just touching the surface. You don't have to shout; but it is necessary to make your voice go into the microphone at a higher level than the surrounding noise. Complete each word before starting the next and put a slight emphasis on all syllables, such as c, s, and z, and terminal letters, such as t and g. *Speak slowly.* Although the equipment has been designed to reduce as much as possible the effects of the mechanical noise, these instructions will help you obtain satisfactory communication with a remote station, especially under poor receiving conditions. Remember, don't mumble away from your mike. Sound off, directly into it.

21. Presetting Push Buttons. Presetting the push buttons simply means tuning the channels ahead of time to the required frequencies and locking the settings, so from there on tuning may be accomplished by merely depressing the necessary push buttons. This process is exactly that used in a home "push button" radio. It's fast and simple to operate.

a. Presetting the Transmitter. The presetting

procedure is divided into two parts: First—setting the push buttons. Second—tuning the antenna circuit.

(1) *Setting the Push Buttons.* The push buttons may be set with the transmitter in the vehicle or removed. However, if the transmitter is removed a suitable source of d-c power and a Mounting FT-237-(*) or other means of connecting the source of power to the transmitter are required.

(a) Set the ON-OFF switch to ON. *Note.* Allow the transmitter to warm for five minutes before setting the push buttons. Perform steps (b) through (k) while waiting.

(b) Remove receivers. (If the receiver is already to be preset also you can save time by leaving the right-hand receiver in position and setting its ON-OFF switch to ON.)

(c) Remove the crystal holders from the crystal compartment and put them in the crystal storage drawer.

(d) Select the required crystal holder for the new frequencies and insert them in the jacks of the crystal holder compartment in the prescribed order. (If no order is prescribed, insert them by numerical order of channel number from top to bottom of the compartment). If desired, write the corresponding channel numbers on the white spaces provided opposite the push buttons.

(e) Replace the crystal holder compartment cover.

(f) Release the push buttons by partially depressing one of them.

(g) Turn the tuning capacitor control (located below the handle on the right end of the transmitter; see Fig. 52), as far as it will go toward the front of the transmitter.

(h) Turn the locking screw (you can reach this with a screwdriver through a small hole located above and to the left of the handle; see Fig. 52), to the left until it binds slightly then turn it to the right one-half turn.

(i) Turn the tuning capacitor control all the way to the rear (minimum capacity).

(j) Set the TUNE-ANT CUR switch to TUNE.

(k) Set the METER SWITCH to position 3.

(l) Latch the push button for the frequency to be set. You will find it easier to set the highest frequency (highest channel number) first.

(m) Then, if five minutes have elapsed since the ON-OFF switch was set to ON, start the dynamotor by setting the RECEIVER TUNE-OPERATE switch to RECEIVER TUNE.

Caution: Do not operate the dynamotor any longer than necessary. Always stop the dynamotor when any pause is made in the procedure. Don't let it overheat.

(n) Slowly turn the tuning capacitor control to the right until the panel meter indicates a peak value. Then continue to rotate the control for about one-eighth turn. If two or more peaks are obtained set the control for the highest one.

(o) Set the METER SWITCH to position 1 and carefully readjust the tuning capacitor control for the peak.

Caution: When the METER SWITCH is in position 1, the tuning capacitor adjustment is very critical and the control requires little or no change from the setting that was obtained for the highest peak in step (n).

(p) Stop the transmitter by setting the RECEIVER TUNE-OPERATE switch to OPERATE.

(q) Release the latched push button by slightly depressing an adjacent push button. While doing this step keep your finger on the button being released to prevent it from snapping out with such force as to disturb the setting.

(r) Repeat steps (k) through (c) for the remaining push buttons, preferably going each time from a higher to the next lower frequency channel.

(s) After the last push button is set, carefully release it. (Use two fingers.)

(t) Turn the tuning capacitor control to the maximum front position and tighten the locking screw.

(u) Check each push button setting by turning the METER SWITCH to position 1, depressing the push button, setting the RECEIVER TUNE-OPERATE switch to RECEIVER TUNE, and moving

the tuning capacitor control slightly. If the setting is correct the meter reading should decrease when the tuning capacitor control is moved slightly to each side of that position to which it has been set by the push button. Repeat steps (f) through (t) for all settings that are not correct.

(2) *Tuning the Antenna Circuit.* When tuning the antenna circuit use Antenna A-83 to prevent radiation. If Antenna A-83 is not available the transmitter must be in place in the vehicle, the mast antenna must not touch anything, and the vehicle should preferably be located well away from trees, trucks, and other large objects, but *only* to the extent permitted by camouflage requirements.

Caution: Never tune or operate the transmitter without the regular or a suitable artificial antenna (such as Antenna A-83) connected to the antenna post. Large currents developed in the antenna meter circuit with the antenna disconnected would burn out the thermocouple.

(a) Set the TUNE-ANT CUR switch to ANT CUR.

(b) Set the METER SWITCH to position 6. If the meter switch is not set to position 6 sufficient coupling may exist at some frequencies to cause the meter indicator to go off scale.

(c) Latch the push button for the frequency nearest 27 megacycles. (This is the best frequency upon which to tune the antenna for maximum output on the greatest number of frequencies. However, if it is definitely known that maximum output is desired on some particular frequency the coupling can be adjusted on that frequency, but *the coupling should be adjusted for one frequency only.*)

(d) Start the dynamotor with the push-to-talk switch on the microphone (RECEIVER TUNE-OPERATE switch at OPERATE).

(e) Adjust the antenna trimmer capacitor (see Fig. 14) that corresponds to the latched push button for maximum indication on the panel meter.

(f) Adjust the antenna coupling control (see Fig. 14) for maximum indication on the panel meter.

(g) Readjust the antenna trimmer capacitor that corresponds to the latched push button for maximum on the panel meter.

(h) Latch remaining push buttons one at a time and adjust the corresponding antenna trimmer capacitor for maximum on the panel meter. (Do not readjust the coupling control.)

Caution: Do not run the dynamotor any more than necessary.

(i) Make the frequency check outlined in Paragraph 19c.

(j) Remove Antenna A-83 (if used) and connect the mast antenna.

(k) If practical, check settings by establishing communication with another vehicle. (If desired, this check need not be made until after the receiver push buttons have been preset.)

b. Presetting the Receiver. The presetting procedure may be divided into two parts: First—setting the push buttons. Second—tuning the antenna circuit.

(1) *Setting the Push Buttons.* The push buttons may be set with the receiver in the vehicle or removed. However, if the receiver is removed a suitable source of d-c power and a Mounting FT-237-(*) or other means of connecting the source of power is required. An unmodulated signal at the frequency or frequencies to which the receiver is to be tuned must be available. The signal may be from either a remote transmitter or an associated transmitter. The changes necessary to adapt the procedure for use with a remote transmitter are obvious.

(a) Set the transmitter and receiver ON-OFF switches to ON. *Note:* Before setting the receiver push buttons the transmitter should warm up for at least 5 minutes and the receiver at least 15 minutes. If you had left the right-hand receiver in place, and it was warming while the transmitter was being preset, it would not be necessary to wait long. However, you may perform steps (b) to (h) while waiting.

(b) Release the receiver push buttons by partially pressing any one of them.

(c) Press the PUSH-TO-TUNE button and while holding it in, turn the TUNING control

toward the high frequency end of the tuning dial until the word LOCK appears under the hairline.

(d) Insert a screwdriver in the hole above the push buttons and turn the locking screw to the left until it binds slightly; then turn it right one-half turn.

(e) Set the receiver controls as follows:

(1) SPEAKER switch to ON. (You may use a headset instead of the loudspeaker if you wish.)

(2) VOLUME control about two thirds to the right.

(3) SENSITIVITY control to minimum (to the left position).

(4) SQUELCH switch to ON.

(5) TUNE-OPERATE switch to TUNE.

(f) If a second receiver is to be preset, place it in position and make the following settings. (These settings are necessary to eliminate all probability of interference by this receiver.)

(1) ON-OFF switch to ON. (Allow the receiver to warm up.)

(2) SPEAKER switch to OFF.

(3) SENSITIVITY control to minimum.

(4) TUNE-OPERATE switch to OPERATION.

(5) Rotate the dial to its LOCK position.

(6) SQUELCH switch to ON.

(7) OUTPUT TO PHONES switch to OFF.

(g) Latch the transmitter push button for the frequency to be set. (The procedure is made easier if the lowest frequency is set first.)

(h) Then if 15 minutes have elapsed since the ON-OFF switch on the receiver to be preset first was set to ON, turn the transmitter RECEIVER TUNE-OPERATE switch to RECEIVER TUNE.

(i) Hold in the PUSH-TO-TUNE button on the receiver to be preset first and turn the TUNING control until the receiver is tuned to the transmitter frequency as determined by a beat note and the setting of the dial which should correspond to the transmitter frequency. If the setting of the dial does not correspond to the transmitter frequency it is probable that the receiver is tuned to a harmonic or that the transmitter is incorrectly preset.

(j) Hold in the PUSH-TO-TUNE button and latch the receiver push button corresponding to the transmitter frequency.

(k) Slowly release the PUSH-TO-TUNE button while rotating the TUNING control just enough in either direction to maintain approximately zero beat (very low pitched note).

(l) Press the latched push button against its stop two or three times. If the beat note is still very low-pitched depress an adjacent push button slightly and carefully ease the latched push button out. (Use two fingers.)

(m) If the setting is still correct turn the transmitter RECEIVER TUNE-OPERATE switch to OPERATE.

(n) Repeat steps (g) through (m) for the remaining push buttons, preferably each time going from a lower to a higher frequency.

Caution: Always stop the transmitter dynamotor during any pause in the procedure.

(o) After the last push button is set, carefully release it (using two fingers) and rotate the dial to the LOCK position.

(p) Lock the setting by tightening the locking screw. The screw should be firmly tightened but not enough to damage the push-button mechanism.

(q) Make the frequency check outlined in Paragraph 19c.

(r) Set the controls for operation as follows:

(1) TUNE-OPERATE switch to OPERATE.

(2) Adjust the SENSITIVITY control so the CALL SIGNAL lamp just goes out when no signal is being received. (See Paragraph 20a.)

(s) If practical, check settings by establishing communication with another vehicle.

(2) *Tuning the Antenna Circuit.* You must tune the receiver antenna circuit when the set is first installed in the vehicle. Ordinarily it will not require tuning again unless you make some change in the antenna. You can tune it before setting the push buttons if you wish. See Paragraph 19a(2) for the prescribed method of tuning the antenna circuit.

REMEMBER THESE NINE POINTS—

1. Keep your antenna vertical. It sends and receives better that way. Be sure you use the right number of sections.
2. Don't talk away from your mike. Speak directly into it. Sound off!
3. If you want distance, head for the high spots. Watch out for steel bridges, valleys, dips, and low places. Your radio will work, but not so far.
4. Conceal your vehicle but don't let your antenna rest against tree branches when sending or receiving. They will leak off your radio power.
5. Watch out for the SQUELCH switch. For weak signals or important calls, turn it off and leave it off. Play it close to the vest.
6. Don't let your radio sit out in the rain. Try to cover it. Rain may ruin radio equipment in a hurry.
7. Don't install your radio in a tightly inclosed space. Give it air.
8. Don't run your dynamotors unnecessarily long. They get hot and, abused, may burn out.
9. The operation of your set is basically simple. Practice it a few times and it will become second nature.

22. System Operation.

a. Radio Set SCR-608-A. Each radio set may transmit on any one of 10 preset channels and receive on any one of 20 preset channels. Two-way communication between two radio sets may be established by use of a single channel or by use of two channels.

The radio set may be used in either of two communications systems: (1) radio communication only, or (2) radio-plus-wire telephone communication. In the first instance the radio equipment needs no auxiliary apparatus other than Microphone T-17, T-30, or T-35 and Headset HS-30(*), HS-18, or HS-23. In the second instance Remote Control Unit RM-29-D is used to connect a remotely located field Telephone EE-8(*) to the radio equipment. Figure 23 shows a system block diagram.

(1) *Radio Communication Only.* When the two ends of the radio system (5 to 15 miles apart) have been placed in operating condition, it is necessary only to choose the channel frequency by pressing the proper channel selector button on the respective radio transmitter and radio receiver and press the microphone control switch when transmission is desired.

(2) *Radio-Plus-Wire Telephone Communication.* In this case the twisted pair from the remotely located field Telephone EE-8(*) is connected to the L1 and L2 binding posts of Remote Control Unit RM-29-D, and Plugs PL-55 and PL-68 of the RECEIVER and MICROPHONE cords, respectively, are inserted into the receiver PHONES and the transmitter CARB MIC jacks. The radio operator's Headset HS-30(*), HS-18, or HS-23 and Microphone T-17 or T-30




Fig. 23. Radio Set SCR-608-A: System Block Diagram

are plugged into the HEADSET and MICROPHONE jacks on Remote Control Unit RM-29-D. The radio operator may communicate with the field telephone operator by throwing the three-position key to TELEPHONE. The ringing generator and ringer are connected at all times and are operative regardless of the position of the three-position key. When the key is at TELEPHONE, the radio equipment is disconnected from the telephone line and from the radio operator's headset and microphone. When the local operator wishes to communicate with the distant field operator, he may do so by throwing the three-position key to RADIO and pressing the microphone push button while speaking. Operation of the key to the RADIO position disconnects the wire line from the radio equipment and from

the local operator's headset and microphone. When the three-position key is at THROUGH, the field telephone is connected to the radio transmitter and the radio receiver, and the local operator's microphone is rendered inoperative except for the push button switch mounted thereon. The field telephone operator cannot start the radio transmitter when he desires to talk and it is necessary, therefore, for the local operator to monitor all conversations and press and release his microphone push button as required by the two speakers.

b. Radio Set SCR-628-A. This radio set operates exactly like Radio Set SCR-608-A except that it is only possible to receive on 10 channels instead of 20, since there is only one receiver.

SECTION III. FUNCTIONING OF PARTS




Fig. 24. Radio Receiver BC-683-A: Block Diagram

23. Functioning of Radio Receiver BC-683-A.

a. General Circuits Used. A block diagram of Radio Receiver BC-683-A is shown in Fig. 24.

The receiver employs the superheterodyne principle of operation. The high-frequency circuits include one stage of tuned radio-frequency amplification (V1), a modulator (V2), and a radio-frequency oscillator (V3). The intermediate-frequency amplifier comprises two stages (V4 and V5), the second of which (V5) provides some limiting action on strong signals. The limiter stage (V6) not only functions as a limiter on moderate signals, but it also reduces amplitude modulation. The detector or discriminator (V7) is followed by two stages of audio-frequency amplification (V10' and V8). An intermediate-frequency oscillator (V10'') permits checking the receiver tuning. A single dual-purpose vacuum tube (V10) functions as the first audio stage (V10') and the intermediate-frequency oscillator (V10''). A second dual-purpose tube (V9) provides delayed automatic volume control (V9') and "squelch" (V9'') which suppresses noise by disabling the receiver output when no signal is being received.

b. Schematic, Wiring, and Apparatus Location Diagrams. Complete schematic, wiring, and apparatus location diagrams are shown in Figs. 43, 44, 45, 46, 71, and 72. The system schematic, Fig. 69, shows (with some of the minor details omitted) the general arrangement of the control circuits; this drawing will be useful in studying the basic operation of these circuits.

c. R-f Amplifier, Modulator, and R-f Oscillator. Figure 25 is a functional diagram of the radio-frequency amplifier (V1), modulator (V2), and radio-frequency oscillator (V3) circuits.

The antenna is coupled to the input of the radio-frequency amplifier stage by the antenna tuning unit, LCU1A. Current flowing through the primary winding LCU1A induces a voltage across the tuned secondary winding. The voltage thus developed is impressed between the grid and cathode of V1 through by-pass capacitor C35. Decoupling resistor R37, along with this capacitor, prevents interstage coupling through the automatic-volume-control wiring. These by-pass capacitors are needed because the d-c grid return is made to the automatic-volume-control lead instead of to ground. The amplified radio-frequency voltage from V1 is impressed across the tuned primary winding of the interstage tuning unit, LCU2A, through by-pass capacitor C39. Trimmer capacitor C1.1 is used to compensate for variations in the antenna systems of various installations.

Current flowing through the tuned primary winding, L33, induces a voltage across the tuned secondary winding, L34, that is impressed between the grid and the cathode of the modulator tube V2, through by-pass capacitor C3. Capacitors C36 and C38 provide temperature compensation. The bias potential for V2 is determined by the cathode resistor, R3.

The signal frequency, 27.0 to 38.9 megacycles, is converted to the intermediate fre-




Fig. 25. Radio Receiver BC-683-A: Functional Diagram of R-f Amplifier, Modulator, and R-f Oscillator

quency, 2.65 megacycles, by heterodyning between the signal-frequency voltage and a frequency (2.65 megacycles higher) derived from the radio-frequency oscillator, V3, in the modulator (or mixer) tube, V2. The radio-frequency oscillator voltage is supplied to the suppressor grid of V2. Several modulation frequencies are available in the output of V2; but the first intermediate-frequency filter, FL1A, selects the lower sideband and rejects the undesired frequencies.

The radio-frequency oscillator employs a shunt-fed Hartley circuit. The oscillator embodies three negative coefficient capacitors C42, C44, and C46 in order to compensate for temperature changes and to enable the oscillator to maintain a high degree of frequency stability. Capacitors C41 and C42 are padding capacitors and capacitor C44 is a blocking capacitor. Energy fed back to the grid circuit through coupling capacitor C43 causes the tube to oscillate. Rectified grid current passing through grid leak resistor R4 provides grid bias for V3.

Radio-frequency voltage for the suppressor grid of V2 is derived from the plate circuit of V3 through a coupling capacitor, C45. Resistor R5 and capacitor C5 prevent radio frequency be-

ing fed from the plate of V3 to the plus B lead. L42 is the oscillator plate choke inductor.

Capacitors C1.2, C1.4, C1.6, and C1.8 are ganged to permit simultaneous adjustment of all four tuned circuits. Alignment of the circuits is assured by trimmer capacitors C1.1, C1.3, C1.5, and C1.7 and adjustable iron dust slugs in inductors L32, L33, L34, and L41.

d. I-f Amplifier and Limiter. The essential circuits of the intermediate-frequency amplifier and limiter stages are shown in Fig. 26. Band-pass filters FL1A, FL2A, and FL3A suppress undesired frequencies outside an 80-kilocycle transmission band which is centered at 2.65 megacycles, the intermediate frequency. Each filter is aligned by the adjustment of a magnetic core within each coil. Resistors R52, R62, and R72 in the three filters aid in securing the desired band-pass frequency characteristic.

Intermediate-frequency filter units FL1A, FL2A, FL3A, and FL4 are all provided with temperature compensation in the form of ceramic capacitors with negative temperature coefficients. See Paragraph 43b(10).

The arrangement used in later production is

shown in Fig. 26. Capacitors C53, C56, C63, C66, C73, C76, and C87 are all negative coefficient ceramic capacitors with a nominal capacitance of 60 micromicrofarads. In each case, the capacitor compensates for the positive temperature coefficient of the coil across which it is connected.

The details of the filters used in earlier production are shown in Fig. 70. In this case, the resonating capacitance for the coils was secured by the use of two parallel capacitors: a 50-micro-microfarad molded mica unit and a 10-micro-microfarad ceramic unit. This latter unit was so constructed that its negative coefficient compensated for the positive coefficients of both its associated coil and the mica capacitor.

The first intermediate-frequency amplifier (V4) is subject to delayed-automatic-volume-control action, its grid bias being supplied through decoupling resistors R51 and R53. The remaining potentials applied to the vacuum tube are such as to allow the tube to operate as a conventional amplifier.

The second intermediate-frequency amplifier (V5) differs from the first in the method of grid bias supply and in the relationships between the screen and plate operating potentials. The signal voltage developed across the secondary (L61) in FL2A is applied to the control grid of V5 through coupling capacitor C61. Grid bias is supplied through the decoupling resistor, R63, and the grid leak resistor, R61, from the negative high-voltage lead. The plate decoupling resistor, R74, is returned to the voltage divider at the common function of R21, R28, and R29; the plate voltage, under no-signal conditions, is approximately 60 volts. As a result of this low plate-supply voltage, the output of this stage is limited to a relatively low amplitude, even with a large input from the first intermediate-frequency stage. (Positive peaks are limited by plate saturation conditions; negative peaks are limited, or "clipped," by plate cutoff.)

The screen of V5 is connected to the plate return of the first intermediate-frequency stage (V4) through dropping resistor R8. Under the no-signal condition, the screen potential is approximately 90 volts. This results in a fairly high-

voltage gain on weak signals in spite of the low plate voltage. On strong signals, however, the increased screen current causes a relatively large voltage drop in resistor R8 (70,000 ohms); this reduces the screen potential, thereby reducing the gain. Consequently, the screen circuit serves as a form of automatic gain control.

On strong signals, rectified grid current flowing through R61 and R63 holds a negative charge on capacitor C61. The values of R61, R63, C61, and C63 are such that their time constant is high with respect to the intermediate frequency. As the input signal swings positive in each half cycle, grid current flowing through R61 charges C61. The charge is retained during the negative half cycle because of the high time constant. The negative bias from the rectified grid current flowing through R61 and R63 limits the positive swing on the grid of V5, thus limiting the peak excitation. The negative half-cycle swings are limited by the cutoff of the tube, which has been fixed by the plate voltage selected. The receiver is frequently required to operate with an extremely wide range of signal strengths impressed on the antenna. A peak limiter which is effective on moderate signal strengths tends to overload and fall off in output for very strong signals. To avoid this possibility the peak limiting action mentioned above is provided in the second intermediate-frequency stage to reduce the range over which the limiter stage (V6) is required to function.

The limiter stage (V6) uses two separate types of limiting action: (1) overload (peak) limiting, as just described, and (2) feedback limiting. The fixed grid bias obtained from the voltage drop across R24 is sufficiently large to give a degree of plate detection prior to overload, which is important in feedback limiting.

The overload method establishes a ceiling which the output cannot exceed. On received voltages big enough to reach this ceiling this method keeps the output uniform and thus cuts off disturbances which would tend to increase the output irregularly. It does not, however, have any limiting effect on signals which do not reach this ceiling.




Fig. 26. Radio Receiver BC-683-A: Functional Diagram of I-f Amplifier and Limiter

The feedback method is based on the idea of balancing out a disturbance in the audio-frequency range by means of an equal and opposite impulse. This is very effective on disturbances of an audio-frequency nature which are not large enough to be taken care of by the overload limiter. It is less effective but still helpful in the range between signals strong enough to start partial peak limiting and those of sufficient amplitude to cause complete peak limiting. The negative feedback method operates by means of the coil L1 and the small parallel capacitor C8, presenting a low radio-frequency impedance and a high audio-frequency impedance. Coil L1 is connected in series with the cathode of V6 and low-frequency amplitude variations in the plate circuit flow through this coil. The effect of this current flow is to develop a voltage across the coil between ground and the cathode. This voltage is therefore effectively applied across the grid-cathode circuit of the tube. The voltage developed across the coil and applied to the cathode opposes the effect of the audio-frequency variations in the grid circuit. When the grid voltage increases at an audio-frequency rate due to an increase in the undesired "ripple," the cathode bias will oppose the increase. When it decreases due to a decrease in the ripple, the bias will oppose the decrease. This action tends to smooth out the ripple. Amplitude variations at the carrier frequency will be by-passed by the capacitor C8 and will produce negligible feedback. At frequencies below the audible range the cathode choke L1 represents negligible impedance and does not affect the bias of the tube. For these slower changes the delayed automatic volume control is effective provided the signal is sufficiently large to overcome the delay bias. On the other hand, delayed automatic volume control does not respond to audio-frequency changes in amplitude, due to automatic-volume-control filter circuits.

In this discussion the noise producing disturbance has been considered as a single frequency having a more or less steady value. In practice, however, the disturbance will probably consist of a number of varying frequencies of varying

amplitudes. As long as the disturbing frequencies interact with the carrier to produce frequencies which are in the audio range (and the amplitude is not large enough to reach the ceiling of the peak limiting action), feedback caused by the coil will occur and smoothing of the ripple will be produced.

e. Discriminator. The purpose of the discriminator is to transform the received intermediate-frequency currents (which are frequency-modulated) into amplitude variations at audio frequencies. A functional diagram is shown in Fig. 27a.

The discriminator uses the phase shift between the primary and secondary windings of the intermediate-frequency transformer at the input of V7. Look at the diagram, Fig. 27a; the signal voltage across the primary L82 is shown as E_p . The tapped secondary winding L81 is shown as two windings in series. The induced voltage across these two windings is shown as E_s . Voltage E_s is developed across the capacitors C85 and C86 in series. Since C85 and C86 are very closely matched, their junction is at the same voltage as the midpoint of the secondary tuned circuit of FL4. The voltage across C85 is impressed on one diode (terminals 5 and 8 of V7). The return path is through capacitors C20.3 (which is paralleled by C82), ground, C83, C87 (which is paralleled by C88), and back to the junction of C85 and C86. The other half of the secondary voltage (developed across C86) is impressed on the other diode (terminals 3 and 4 of V7). The return is through C81, C20.3, ground, C83, C87, and back to the junction of C85 and C86.

In addition to these secondary voltages, the primary voltage is also impressed on these two diodes. The junction of C85 and C86 also connects directly to the plate of V6 (the limiter). The primary voltage is developed from this point to ground. Thus, E_p is impressed across a circuit consisting of C85, then the diode (terminals 5 and 8 of V7), then C20.3, to ground. The path through the other side of V7 is through C86, through terminals 3 and 4 of V7, through C81




Fig. 27a. Radio Receiver BC-683-A: Functional Diagram of Discriminator

and C20.3, to ground. These are all a-c paths. Since a diode is a tube that is unidirectional, that is, current flows in only one direction, these impressed alternating currents are rectified and this direct current flows through resistors R81 and R83 to the tap at the middle point of L81. This is merely a d-c return.

From this description, it is seen that each diode has impressed on it the primary voltage developed across C87 in series with one half the secondary voltage developed across C85 and C86.

The action of the discriminator depends upon the phase relations between these voltages. At resonant frequency (see Fig. 27b), E_p and E_s are each almost exactly 90 degrees out of phase with the primary voltage E_p . Consequently, W_p , the total voltage across R83, and W_s , the total voltage across R81, are equal in magnitude; since the rectified voltages appearing across the two resistors are opposite in sign, the resultant d-c voltage is zero. When the impressed signal is either above or below the resonant frequency, however (see Figs. 27c and 27d), the 90-degree phase relationship no longer holds, and the d-c voltages across R83 and R81 no longer balance out. The net result is that the discriminator output voltage follows the variations in frequency


of the incoming signal; the original frequency modulation is translated into amplitude modulation of the discriminator output voltage. This voltage is then impressed upon the grid of the first audio-frequency amplifier tube.

A somewhat more detailed explanation of the discriminator phase relations follows: Consider first the conditions when the output of the intermediate-frequency amplifier and limiter is at the resonant frequency to which both the primary and secondary circuits of FL4 are tuned. This is the case when the signal from the distant transmitter is at the mean or resting carrier frequency (i.e., no modulation is taking place). Voltage E_p (see Fig. 27b) exists across primary winding L82; the primary current, I_p , lags E_p by very nearly 90 degrees; the resulting flux, ϕ , which links the secondary winding is exactly in phase with the current, so it also lags 90 degrees behind the voltage, E_p . Now this flux induces, in secondary winding L81, an electromotive force which drives a current, I_s , through the secondary circuit. (Note that this electromotive force or inducing voltage is *not* E_s , the secondary voltage which would be measured by a voltmeter connected across the secondary winding.) The *induced* electromotive force lags the inducing flux


by 90 degrees; it therefore lags the primary voltage, E_p , by 180 degrees, as shown in Fig. 27b.

As mentioned before, the secondary circuit is resonated exactly to the frequency of the signal; consequently, the impedance which is presented to the induced electromotive force is a pure resistance and the resulting current, I_s , is in phase with the electromotive force, as indicated in Fig. 26b. Now consider voltages E_b , E_a , and E_p . Since secondary winding L81 is a nearly pure inductance, the voltage, E_p , appearing across its terminals will be almost in quadrature (90-degree phase relation) with the current through it. But the two components of E_a , namely, E_a and E_b ,


higher than resonance; the essential phase relations within the discriminator circuit are shown in Fig. 27c. The relations of E_p , I_p , ϕ , and the induced electromotive force in the secondary are as they were in the case of resonance. Now, however, the impedance presented to the induced electromotive force is no longer purely resistive; it has an inductive component and consequently the secondary current lags the electromotive force. Consequently, E_a and E_b are related to E_p as indicated in the figure and the voltages across R83 and R81 (W_c and Y_c , respectively) are no longer equal in magnitude; they do not cancel out.



27b. AT RESONANCE



27c. ABOVE RESONANCE



27d. BELOW RESONANCE

Figs. 27b, 27c, 27d. Radio Receiver BC-683-A: Vector Diagrams Showing Phase Relations in the Discriminator for Variations in Received Frequency

are 180 degrees out of phase with each other (remember that each is measured with respect to the mid-point of the two capacitors, or, what is the equivalent, the center tap of the secondary coil). It follows, then, that one of the two voltages must lead I_s by 90 degrees and the other must lag by 90 degrees, as indicated in Fig. 27b.

As explained previously, the total voltage impressed upon the left-hand diode of V7 is made up of E_p (across C87) in series with E_a (across C85); the total voltage impressed upon the right-hand diode is made up of E_p in series with E_b (across C86). These total voltages are shown in Fig. 27b as W_b and Y_b , respectively. It will be noticed that under the condition assumed (namely, the tuned circuit resonant at the frequency of the impressed signal), the absolute magnitudes, or lengths, of W_b and Y_b are the same.

Now assume that the signal frequency is

When the signal frequency is below resonance the phase relations are as shown in Fig. 27d. The series impedance of the secondary circuit is capacitive and accordingly the secondary current, I_s , leads the induced electromotive force with the result shown. Notice that whereas in the preceding case (frequency above resonance) W_c was greater than Y_c , in this case, Y_d is greater than W_d .

The functions of the various units are described as follows: The tuned circuit comprising L82, C87, and C88 tunes the plate circuit of the limiter tube V6 to the intermediate frequency. The capacitors C83 and C8 in series complete the intermediate-frequency circuit between plate and cathode. C88 provides temperature compensation for C87 and L82. The primary winding, L82, is adjusted for exact resonance at the intermediate frequency by means of an iron dust tuning slug. Plate voltage is applied to the limiter

tube, V6, through the decoupling resistor R85 from the junction of R28 and R29 on the voltage divider. L81 (the tapped secondary), which is coupled to L82, is resonated with capacitors C85, C86, and C84. (C84 is small and provides temperature compensation for the tuned circuit.) This secondary tuned circuit feeds through the double diode V7 to the load resistors R81 and R83 of the discriminator. Capacitor C81, connected across resistors R81 and R83, serves as an intermediate-frequency by-pass and also contributes somewhat to the shaping of the audio-frequency response characteristic. (R82 and R84 are discussed in connection with the automatic-volume-control and squelch circuits; they play no part in the discriminator action.)

One side of the discriminator load circuit is connected to ground through the radio-frequency by-pass capacitor C82 and the audio-frequency by-pass capacitor C20.3 connected in parallel. The other side of the discriminator load circuit connects to the audio-frequency amplifier through series resistor R10 and coupling capacitor C11.

j. Voltage Divider. The voltage divider which is shown in the lower part of Fig. 29 serves three general functions:

(1) It constitutes a bleeder across the high-voltage direct current from the filter to discharge the capacitors when the power supply is not in use.

(2) It provides the reduced positive voltages required by the second intermediate-frequency amplifier, the limiter, the delayed-automatic-volume-control, and the squelch circuits.

(3) It provides negative grid bias for the radio-frequency and intermediate-frequency amplifiers as well as the limiter.

Current flowing from the positive brush of the dynamotor must pass through audio- and radio-frequency choke coils and through R31, R29, R28, R27, R26, R25, R24, and P2 (provided the SQUELCH switch is in the ON position) to the negative brush of the dynamotor. It will be noted that R29 (13,000 ohms) and R31 (6,800 ohms) in series are shunted by R21 (30,000 ohms); this

is, electrically, the equivalent of a single resistor of 12,000 ohms. The combination of three resistors is used, rather than a single 12,000-ohm resistor, because of convenience in mounting and heat dissipation. The junction points between the resistors provide taps giving various voltages which are progressively less positive going from R31 to the junction point of R24 and R25, which point is grounded. (It is useful to bear in mind that neither terminal of the dynamotor is grounded.) The voltage becomes progressively more negative as we go from the ground point through R24 and P2. These two resistors are in the circuit which supplied bias to the grids of the first two amplifier tubes. R24 is fixed but P2 is adjustable. Since an increase in this resistance causes an increase in the voltage developed across it, an adjustment of P2 changes the negative bias applied to the first two amplifying tubes and thus changes the sensitivity of the receiver.

g. A-f Amplifier. A functional diagram of the audio-frequency amplifier is shown in Fig. 28.

The audio-frequency output of the discriminator is developed across the load (R81 and R83 in series) as described in Paragraph 23e. It is connected through the series resistor R10 and series capacitor C11 to the grid of vacuum tube V10'. The other side goes to ground through the radio-frequency by-pass capacitor C82, which has C20.3 shunted across it to reduce the audio-frequency impedance of this part of the ground return. The circuit to the cathode of V10' is through C20.2. Capacitor C13 is shunted from the grid of V10' to ground and shapes the audio-frequency response curve. The resistor R10, in conjunction with C13, is a radio-frequency filter which among other things prevents intermediate-frequency currents from appearing on the grid of V10'. C11 is an audio-coupling capacitor. C26 is part of the intermediate-frequency oscillator circuit. Plate current flowing through cathode resistor R12 serves to bias the grid of V10' when the receiver is operated with the SQUELCH switch at OFF. Since R12 is not by-passed there will be a small amount of negative feedback in the first stage of this audio amplifier which causes some

reduction in the gain of V10'. (Negative feedback is incorporated in this circuit not primarily to reduce distortion but rather to reduce the gain of V10', the full amplification of which is not required for this application.) Grid return is completed through the grid leak R11 and the squelch circuit resistor, R17, to one side of R12.

The function of R17 is described in Paragraph 23f. A portion of the SQUELCH switch D4 con-

nects the junction of R12 and R17 to ground when the SQUELCH switch is at OFF (removing any additional bias that might be developed across R17 by the squelch circuit). The plate circuit of V10' connects through R18 and R19 to the B supply voltage, which is by-passed to ground by C16. The 2-megohm resistor R19 is shunted by the CALL SIGNAL lamp E1, a neon lamp which has an impedance of about 200,000 ohms when normal lighting current is passing through it. When a signal is received the plate current flows and develops a voltage across R19, which increases up to the breakdown potential of the lamp. The lamp then breaks down, greatly reducing the impedance in series with the plate and lighting the lamp. At normal signal levels, the plate current variations of V10' are not

sufficient to extinguish the CALL SIGNAL lamp. At very high signal levels, which normally cause overloading, the lamp may be extinguished over part of the cycle due to that overload. This condition results in some distortion which is not usually objectionable.

The plate of V10' is connected through the coupling capacitor C21 to one side of the volume control P1, the wiper of this control being con-




Fig. 28. Radio Receiver BC-683-A: Functional Diagram of A-f Amplifier

nects the junction of R12 and R17 to ground when the SQUELCH switch is at OFF (removing any additional bias that might be developed across R17 by the squelch circuit). The plate circuit of V10' connects through R18 and R19 to the B supply voltage, which is by-passed to ground by C16. The 2-megohm resistor R19 is shunted by the CALL SIGNAL lamp E1, a neon lamp which has an impedance of about 200,000 ohms when normal lighting current is passing through it. When a signal is received the plate current flows and develops a voltage across R19, which increases up to the breakdown potential of the lamp. The lamp then breaks down, greatly reducing the impedance in series with the plate and lighting the lamp. At normal signal levels, the plate current variations of V10' are not

connected directly to the control grid of the second audio amplifier (beam power) V8. The grid circuit of V8 is completed from the other side of the volume control P1 to the minus B lead. A high-capacity electrolytic capacitor, C23, prevents audio-frequency feedback across the cathode bias resistor R20, which connects to the minus B lead. Capacitor C19 is connected across P1 to reduce further the higher audio frequencies, and to prevent the possibility of pickup of unwanted intermediate-frequency currents which might otherwise be amplified by V8.

The value of C21 as well as the value of C11 previously referred to were chosen to reduce the gain of the audio amplifier at frequencies below 400 cycles.

The screen grid supply for V8 is obtained

phone will often result in poor reception of your signals.

h. Delayed-automatic-volume-control Circuit. A functional diagram of the delayed-automatic-volume-control circuit is shown in Fig. 29.

As already mentioned it is very important that the signals reaching the discriminator be of uniform amplitude. In order to accomplish this, peak limiting is provided in the second intermediate-frequency amplifier (V3) and both peak limiting and feedback limiting are provided in the limiter stage (V6). In addition, the automatic volume control is used to take care of the variations below the audio-frequency range which are too slow to be handled by the feedback limiter and too small for the overload limiter. The detailed circuit arrangements will be described following a discussion of the general method by which the delayed-automatic-volume-control arrangement functions.

Since this is *delayed* automatic volume control, there must be a delay bias. This is provided by connecting the plate of the delayed-automatic-volume-control tube V9' to a point which is negative with respect to the cathode connection. This fixed bias prevents plate current from flowing in V9' when there is no output from the limiter V6. This fixed bias is the sum of the voltages across P2, R24, R25, and R26.

When there is output from the limiter, the intermediate-frequency voltage developed across FL4 is impressed across the plate and cathode of V9' (as described in more detail later). When this is sufficient in magnitude to overcome the fixed bias on V9', plate current will flow in that tube during part of each half cycle. This plate current flows through a high resistor (R14) which is in the common grid return of the radio-frequency and first intermediate-frequency amplifier tubes (V1 and V4). This causes a voltage to be developed in that resistance, thus increasing the negative bias applied to the grids of those amplifier tubes.

It will be noted that the cathode circuit of V9' includes R81 and R83 which form the discriminator load resistor. Direct current flowing through these resistors due to discriminator ac-

tion makes their junction negative with respect to the outer ends of the combination. Since the negative end of this developed voltage is toward the cathode of V9', this effect tends to reduce the delay bias materially as the signal strength increases.

In addition, intermediate-frequency current flowing through resistors R81 and R83 (from the plate of V6 through C85, C86, and tuned circuit of L81, returning to the cathode of V6 through C81, C82, and C8) causes an intermediate-frequency voltage to be applied directly to the cathode of V9'. This intermediate-frequency voltage is rectified when the peaks exceed the reduced delay bias. It will be noted that since this rectified current divides equally through the discriminator load resistors, it does not affect the audio-frequency discriminator output.

The net result of these factors is that the automatic-volume-control tube, V9', is biased so that no plate current flows in it until the output of the limiter V6 exceeds a certain amplitude. When that occurs, this intermediate-frequency voltage (which is applied to both the discriminator and the automatic-volume-control tube) undergoes half-wave rectification in V9' and causes pulsating plate current in that tube. This plate current develops a d-c voltage in R14 which is effectively in series with the fixed bias applied to the radio-frequency and first intermediate-frequency amplifiers (V1 and V4). This rectified d-c voltage component progressively increases the negative bias applied to V1 and V4, decreasing the amplification of these tubes, thus tending to maintain a constant output from the limiter.

The circuit arrangements for providing the automatic-volume-control actions are described in more detail as follows (referring again to Fig. 29): The cathode of the automatic-volume-control diode V9' is connected through R81 and R82 in parallel with R83 and R84 to the junction of R26 and R27 on the voltage divider, then through resistors R25 and R26, to ground. The plate and grid are both connected through R14 to the negative end of the dynamotor; thus they are negative with respect to the cathode when




Fig. 30. Radio Receiver BC-683-A: Functional Diagram of Squelch Circuit

no signal is being received. This rectifier circuit is completed to ground through R14 (P2 when the SQUELCH switch is at ON), and R24. These resistors are also in the circuit which provides bias to the first radio-frequency and first intermediate-frequency amplifying tubes, V1 and V4.

The intermediate-frequency voltage developed across FL4 appears between the plate of V6 and ground. The plate of V6 is connected directly to the junction of C85 and C86. As far as relation to ground potential is concerned, this junction is equivalent to the midpoint of L81 which is connected directly to the cathode of V9'. Thus the cathode of V9' is connected effectively to the plate of V6. The return circuit from the plate of V9 is through C14. The intermediate-frequency voltage is thus impressed across the rectifier V9'. When the amplitude is sufficient, half-wave rectification occurs, which causes plate current to flow through R14. This causes the point (x) to become increasingly negative as the output of V6 increases. Since the potential of point (x) determines the bias applied to V1 and V4 (radio-frequency and first intermediate-frequency amplifiers), it is apparent that increasing the input to the receiver causes a decrease in the gain and thus tends to keep the output of V6 constant.

Currents reaching the discriminator cause d-c

voltages across R81 and R83, by discriminator action. The junction of these two resistors is the negative end of each. R82 and R84 are connected in such a way that R81 and R82 are effectively in parallel with R83 and R84 for this application, and the negative end of the voltage developed across this combination is connected to the cathode of V9'. This voltage is not large enough to overcome the fixed bias but reduces it materially. R82 and R84 are provided to permit introducing the fixed bias on V9' without affecting discriminator action and also without short-circuiting the audio-frequency output across R81 and R83.

The grid bias lead for V1 and V4 is supplied through resistor R13 with capacitors C14 and C15 connected to ground at its two ends to prevent radio- and audio-frequency feedback to the grid of these tubes. V1 and V4 also have individual filter resistors R37 and R53 respectively, between the grid and the common grid bias supply. Each of these two tubes has an individual radio-frequency by-pass capacitor connected from the grid end of its filter resistor to ground.

i. Squelch Circuit. A functional diagram of the squelch circuit is shown in Fig. 30.

The squelch circuit is designed to disable the receiver output when the desired carrier is not received. In this manner, hiss and undesirable

background noise (normally present under a no-signal condition) are eliminated in the "no-transmission" intervals. In order to accomplish this more efficiently over a wide range of possible signal and background levels, a sensitivity control is provided. This is effective only when the squelch circuit is turned on, and normally enables the operator to adjust the threshold level (operating point) of the squelch circuit in such a way that the average background interference alone will not maintain the receiver in operating condition. Desired signals, however, not only will cause the set to become operative but also will light the CALL SIGNAL lamp.

The operation of the squelch circuit is accomplished by having plate current flow in the squelch tube V9" when no carrier is being received. This plate current in V9" flowing through resistor (R17) produces a d-c voltage which is applied as negative bias to the first audio-frequency amplifier V10'. This bias is sufficient to prevent any signal transmission beyond that point. Thus there is no receiver output. When carrier voltage is received, the current flowing through resistors R81 and R83 from discriminator action sets up a d-c potential which is applied to the grid of the squelch tube V9" to prevent the flow of plate current. Thus the bias caused by that plate current is removed from the grid of V10' and the audio amplifier operates normally. The following discussion shows in more detail how this is accomplished:

When there is no input to the discriminator, no signal voltage will be built up across either R81 or R83. With no signal voltage being received, noise voltage is developed across R81 and R83. If the SQUELCH switch is at ON, the amount of noise voltage is adjustable by means of P2, and the audio-frequency amplifier V10' (Fig. 30) is then biased beyond cutoff by reason of the current (from the plate circuit of the squelch tube V9") flowing through R17. The CALL SIGNAL light is then extinguished since no current flows in the plate circuit of V10'. It will be observed that the control grid of the squelch tube is positive with respect to the cathode (grid current flow is limited by R15 and R16). The cathode is connected to the junction of R25 and

R26 while the grid is eventually returned to the junction of R26 and R27. This return path is through resistors R15 and R16, then through R81 and R82 in parallel with R83 and R84, to the voltage divider. Also the plate is returned through R17 and the switch D4 (at ON) to the junction of R27 and R28 which is positive with respect to both the cathode and the grid. Therefore, plate current flows in the squelch tube V9" and through resistor R17 to produce a voltage drop through R17. The negative end of this voltage drop is at the junction with R11 and thus applies negative bias through R11 to the grid of the first audio-frequency amplifier V10'. This voltage is sufficient to bias V10' below cutoff; hence, no plate current flows and the amplifier is "disabled." The by-pass capacitors C17 and C18 are connected to ground from either side of R16, to prevent intermediate-frequency or audio-frequency currents from flowing through R15 and R16 and actuating the squelch tube, since operation of this circuit is controlled mainly by the d-c component of the rectified input signal. Capacitor C12 serves to filter the plate circuit of V9" in a similar way. Capacitor C20.2 provides an audio-frequency return path to ground from the cathode circuit of the first audio-frequency stage.

When a signal is being received, a voltage of intermediate frequency is developed across the tapped secondary L81 of filter unit FL4. This is applied to the two diodes of the discriminator V7. In one case a resulting electron flow occurs from the cathode (4) to the plate (3), through L81 (upper winding), R81, and back to the cathode. The other circuit is from the cathode (8) to the plate (5), through L81 (lower winding), R83, and back to the cathode. The voltages built up across R83 and R81 are such that the negative terminal of each is at the junction of the two resistors. For bias purposes, these two voltages are effectively connected in parallel by connecting two high resistors, R84 and R82, from the positive terminals of R81 and R83. The other ends of both R82 and R84 are then connected to the junction of R26 and R27 on the voltage divider.

The negative end of this potential effectively




Fig. 31. Radio Receiver BC-683-A: Functional Diagram of I-f Oscillator

developed across R81 and R83 in parallel is applied through resistors R15 and R16 to the grid of the squelch tube V9". It will be noted that this potential is in opposition to the grid bias (the voltage drop across R26 and R27) which is applied to V9" whenever the SQUELCH switch is at ON. When no input exists at the discriminator, plate current will flow in V9". When a signal is being received, however, the voltage developed across resistors R81 and R83 is sufficient to overcome the fixed bias and stop the flow of plate current in V9"; thus the effect of the squelch is eliminated and the audio-frequency amplifier will function normally.

The SENSITIVITY control is described as part of the voltage divider. It regulates the radio-frequency gain of the receiver to make it as high as possible without providing enough average noise voltage to "trip" the squelch tube.

i. I-f Oscillator. A functional diagram of the intermediate-frequency oscillator is shown in Fig. 31.

The intermediate-frequency oscillator employs a Hartley circuit which is quite similar to the radio-frequency oscillator of the receiver. Coil L91 is adjustable to permit tuning to 2.65 megacycles. Capacitor C93 provides the bulk of the tuning capacitance. Capacitor C92 provides temperature compensation and C94 is a blocking

capacitor. Capacitor C91 provides feedback and resistor R91 provides grid bias.

The intermediate-frequency oscillator operates as an autodyne detector. Some intermediate-frequency energy from limiter V6 is impressed upon the plate of the oscillator through a small coupling capacitor, C10. This energy modulates the oscillator, and the audio-frequency beat note produced is passed on to the first audio-frequency amplifier through R6 and C26. C26 is a coupling capacitor. R6 prevents a short circuit of the audio amplifier. The coupling capacitor C10 is small enough to prevent audio frequencies from appearing on the plate of the limiter. The oscillator is controlled by the TUNE-OPERATE switch, D5, which supplies plate voltage to V10" through the load resistors R92 and R93.

k. Vacuum Tube Heater Circuits. A functional diagram of the vacuum tube heater circuits in the receiver is shown in Fig. 32.

These circuits are permanently grounded to the receiver chassis at three points, i.e., terminal 2 of V1, terminal 7 of V4, and terminal 2 of V3. Terminal 1 of plug PG2 is grounded also. When the dynamotor is installed in the receiver, the strap connections shown (which are included in the base of the dynamotor) modify the circuit as required for operation at the battery voltage indicated on the dynamotor. Thus, if 24-volt bat-

tery operation with Dynamotor DM-36-(*) is assumed, J801 of the dynamotor connects terminal 3 on plug PG2 to terminal 2; and the 24-volt battery is impressed across three parallel circuits (of series heaters) to ground: (V9, V7, V10, and V3), (V5 and V4), and (V8, V6, V2, and V1). If 12-volt battery operation with Dynamotor DM-34-(*) is assumed, J701 of the dynamotor connects terminal 3 on PG2 to terminals 12, 9, and 15 and straps terminal 1 to terminal 2. By these connections, the 12-volt battery is impressed across six combinations of

accomplish a similar function on the high-voltage end. L701 together with C25 constitutes an audio filter to remove the audio-frequency ripple which exists at the output of the dynamotor.

For Dynamotor DM-36-(*), the corresponding components in the 800 series perform similar functions.

24. Functioning of Radio Transmitter BC-684-A.

a. Block Diagram. A block diagram of the transmitter is shown in Fig. 33.




Fig. 32. Radio Receiver BC-683-A: Functional Diagram of the Heater Circuits

heaters to ground: (V2 and V1), (V6 and V8), (V10 and V3), (V7 and V9), (V4), and (V5).

As mentioned in Paragraph 76, a 12-volt dynamotor must be used with a 12-volt battery and a 24-volt dynamotor with a 24-volt battery. The connections within a dynamotor are so arranged that the circuit is automatically changed to adapt it to the battery voltage.

1. Dynamotor Filter Circuits. Filter circuits are provided in both the low- and the high-voltage sides of the dynamotors to overcome interference caused by the commutator as well as to provide the required degree of filtering. In the case of Dynamotor DM-34-(*), capacitors C703 and C704 together with L702 constitute a low-voltage filter to prevent commutator interference from the low-voltage end. C701, C702, C705, and C706 together with L703 and L704

The gang-tuning control, operated by the push button selector, selects any one of ten preselected crystals and connects it to the oscillator (V107). The oscillator output frequency (f_c) is amplified by the first radio-frequency amplifier (V101) and, along with the audio-frequency signals, is impressed upon a saturated iron-core modulation coil (MOD COIL).

The output of the modulation coil is rich in harmonics of the crystal frequency. After rectification by V102, the reason for which will be given later, the *twelfth* harmonic of the crystal frequency ($42 f_c$) is selected and impressed upon a frequency tripler (V108). The tripler output ($36 f_c$) excites a frequency doubler (V103). The doubler output ($72 f_c$) drives the power amplifier (V104) at the carrier frequency ($f_c = 72 f_c$). The proper one of ten pretuned an-




Fig. 33. Radio Transmitter BC-684-A: Block Diagram

antenna coupling circuits is selected by the gauging-tuning control and connected to the antenna.

Speech signals from a microphone associated with the transmitter are amplified by a two-stage audio-frequency amplifier (V105 and V106).

A small amount of audio output from V106 is caused to pass through the headset circuit. This is called "sidetone." It enables the commander to hear all that goes out from his radio transmitter and prevents confusion where two people have microphones for the same transmitting set. Also, when the operator's ears are covered by a headset he does not have the normal sensation of hearing himself talk unless sidetone is provided.


b. Schematic, Wiring, and Apparatus Location Diagrams. Complete schematic, wiring, and apparatus location diagrams are given in Figs. 47-50, 74, and 75.

c. Crystal Oscillator and First R-f Amplifier. A functional diagram of the crystal oscillator

(V107) and the first radio-frequency amplifier (V101) is shown in Fig. 34.

The frequency of the oscillator (V107) is controlled by any one of ten crystals in Holders FT-241-A placed in the crystal compartment. The crystal frequencies are in the range of 375 to 340 kilocycles, as listed accurately in Paragraph 3d, Table II. In the functional diagram the important components of the oscillator are the crystal, Y101 to Y110, capacitor C151 from the control grid of V107 to ground, and the tuned circuit C105-L102 in series with capacitor C104. The crystal is connected between the control grid and the junction of the tuned circuit and C104. The remaining components provide the proper screen grid and plate potentials, grid bias, and a high-frequency impedance (L117-R149).

The oscillator operates as a modified "grid-ground" oscillator in which the crystal is above ground because of the impedance of capacitor C104. The phase of the current through this



capacitor is such that some additional feedback is obtained, over that occurring in the usual grid-ground circuit. This causes more rapid crystal starting and increases the output.

The parallel-connected inductor and capacitor in the plate circuit of the oscillator, L102 and C103, are proportioned to increase the excitation on the grid of V101 at the higher frequencies over that which would be obtained otherwise. Capacitor C150 prevents the oscillator plate d-c voltage from appearing on the grid of V101.

Grid bias for the first radio-frequency amplifier V101 flows through resistor R139. The screen of V101 is kept at radio-frequency ground potential by by-pass capacitor C101. The d-c supply for the screen is obtained from the 400-

audio signal (output of the second audio-frequency amplifier, V106).

The radio-frequency input derived from the first radio-frequency amplifier causes a current of about 0.3 ampere to flow through parallel-resonant circuit L103A, L104, C106, and C147. L104 becomes magnetically saturated at a much lower current than this. When the instantaneous radio-frequency current exceeds the saturation value there is no appreciable increase of flux density and the inductance of the coil drops to a low value. Consequently very little voltage appears across it when the instantaneous current through it is higher than the saturation value.

Between the saturation value and zero current, the coil has a high inductance, and a change




Fig. 35. Radio Transmitter BC-684-A: Functional Diagram of Modulator and Rectifier

volt supply through resistor R103. The plate circuit is fed through radio-frequency choke coil L101, and the load circuit (L103A, L104, and C106), is isolated by blocking capacitor C103.

d. Modulator and Rectifier. A functional diagram of the modulator and rectifier stages is given in Fig. 35.

Two important functions are performed by inductor L104, which is a small nonlinear coil specially designed for use in this transmitter. The coil, together with its associated tuning inductor and capacitors (L103A, C106, C147), serves as a harmonic producer; at the same time, it functions as a modulating element which causes the carrier-frequency output of the first radio-frequency amplifier to be phase-modulated in conformity with amplitude variations of the

in current causes a relatively large change of flux density. Under this condition (that is, when the current passes through the *magnetization range* of the coil) there is a large change in the magnetic field; a high counter-voltage is induced across the coil. The current through L104, therefore, produces sharp voltage peaks each half cycle as the radio-frequency current wave passes through zero. The voltage peaks alternate in polarity each half cycle and are evenly spaced in time. The peaks have a distorted wave shape and contain many harmonics of the original (crystal) frequency.

Figure 36 shows how phase modulation may be produced by passing combined carrier and signal currents through L104. Figure 36a represents the current through L104 (crystal fre-




Fig. 36. Radio Transmitter BC-684-A: Method of Modulation




Fig. 37. Radio Transmitter BC-684-A: Functional Diagram of Tripler, Doubler, Power Amplifier, and Antenna Coupling Circuits




Fig. 38. Radio Transmitter BC-684-A: Functional Diagram of A-f Amplifier

quency) in the absence of any modulating signal. An audio-frequency (sine wave) signal is shown in Fig. 36b. As shown in Fig. 35, the two currents pass through L104 to ground. The combined current is shown in Fig. 36c. Figure 36d shows the inductive voltage peaks generated in L104 (near zero instantaneous coil current) by the combined current.

The peaked voltage across L104 is rectified by a biased rectifier, V102, as shown in Fig. 35. The fixed bias on the grid of V102 is sufficient to eliminate all portions of the wave shown in Fig. 36d except the upper peaks. The rectified output of V102 is illustrated in Fig. 36e. The wave shown in Fig. 36f is representative of the fundamental component of the wave in Fig. 36e. The difference between the evenly spaced intervals on the "time axis" and the points of "zero current" represents the amount by which modulation has shifted the wave.

The wave in Fig. 36e contains a large number of harmonic frequencies, each of which is similarly phase-modulated. A tuned filter (C152, C153, L119, L118, C156, and C157) suppresses all but the *twelfth* harmonic of the crystal frequency. This is passed on to the tripler stage of the transmitter.

e. Tripler, Doubler, Power Amplifier, and Antenna Coupling Circuits. A functional dia-

gram of the tripler (V108), doubler (V103), power amplifier (V104), and antenna coupling circuits is shown in Fig. 37.

The input to the tripler tube, the voltage across tuning capacitors C156 and C157, is at twelve times the crystal frequency, or one sixth of the output carrier frequency. Coupled anti-resonant circuits (C113, C114, L106 and C115, C116, L107) in the plate circuit of V108 and the grid circuit of V103 select the thirty-sixth harmonic of the crystal frequency and impress it upon the doubler stage, V103. The doubler output is tuned to the output carrier frequency by anti-resonant circuit L108, C119, C120. While capacitor C121 is included in the tuned circuit, it is of low reactance and is used only as a dc blocking capacitor. The power amplifier, V104, is coupled to the antenna by coupled circuits C125, C126, L110 and L111, C127-C136. L123-R158 is included in the grid lead of V104 to suppress high-frequency parasitic oscillations.

f. A-f Amplifier and Microphone Circuits. The essential circuits of the audio-frequency amplifier and the microphone circuits are shown in Fig. 38.

The first audio-frequency amplifier tube, V105, may be excited by a microphone. This may be a carbon-type microphone (either Microphor T-17 or T-30) connected to J102, or a magnetic

type microphone (Microphone T-33) connected to J101. In either case, pressing the switch on the microphone energizes the dynamotor relay winding (S102) and closes its contacts to start the transmitter dynamotor. The voltage from a magnetic-type microphone is impressed across the primary of input transformer T101. The secondary of T101 is loaded by resistor R115. The voltage across R115 is impressed upon the input of V105 through capacitor C137.

Since the output of a carbon-type microphone exceeds that of a magnetic-type microphone, means are provided to care for this difference. A magnetic-type microphone may be plugged into jack J101 or a carbon-type microphone may be plugged into jack J102. The desired uniformity of excitation of V105 (in spite of differences in microphone output) is obtained by the voltage divider action of capacitors C137 and C138. C138 is smaller than C137 and the audio signal voltage across C137, which is the excitation for V105, is proportionally smaller. The d-c microphone current is obtained through a ripple filter (R120, C140, and R121), from the vehicle battery.

The output of V105 is coupled to the grid of V106 by capacitor C141 and resistors R151 and R125. R123 is a noise filter resistor for the plate of V105. Capacitor C145 serves as a ground return for the plate circuits of V105 and V106.

Output transformer T102 has two series-connected secondary windings. One winding supplies sidetone to terminal 21 on plug PG101 through resistor R128. The sidetone volume is adjusted by varying the setting of potentiometer P101. The second winding supplies modulating signals to the modulation coil, L104, through radio-frequency choke coil L105A.

g. Metering Circuits. A single meter, M101 (Fig. 74), may be switched to any one of several circuits in the transmitter by operation of switch D125. The panel switch D121 is used to connect the meter to D125 or to the thermocouple TC101 for indicating antenna current. The following six circuits may be checked by use of D125.

Switch Position

1
2
3
4
5
6

Circuit

Doubler grid
First r-f amplifier grid
Rectifier grid
Tripler grid
Power amplifier grid
Total plate and screen

25. Functioning of Remote Control Unit RM-29-D. A combined schematic and wiring diagram for the remote control unit is given in Fig. 76. The association of this unit with Radio Set SCR-608-A is also shown in the detailed system schematic diagram, Fig. 69, and is explained in Paragraph 27. For more detailed information on the functioning of the various components in Remote Control Unit RM-29-D, refer to Technical Manual TM 11-308 which covers this unit.


26. Functioning of Dynamotors DM-34(*), DM-35(*), DM-36(*), and DM-37(*). Four types of dynamotor are used with Radio Sets SCR-608-A and SCR-628-A. They are:

Dynamotor DM-34(*): Receiver (12 volts)
Dynamotor DM-35(*): Transmitter (12 volts)
Dynamotor DM-36(*): Receiver (24 volts)
Dynamotor DM-37(*): Transmitter (24 volts)


Each dynamotor combines the functions of a low-voltage (12-volt or 24-volt) d-c motor with a high-voltage (200 volts for the receiver; 600 volts for the transmitter) d-c generator in a single machine. Only one frame, one armature, one field winding, and one pair of bearings are required. The armature is wound with two separate windings, each of which is connected to its own commutator. Schematic and wiring diagrams of the four dynamotors are shown in Fig. 39. Apparatus location diagrams are shown in Fig. 40. Exploded views of the dynamotors are shown in Figs. 41 and 42. The parts numbers are given in Paragraph 41, Maintenance of Dynamotor.

27. Functioning of Control Circuits.

a. Radio Set SCR-608-A. Figure 69 is a system schematic drawing of Radio Set SCR-608-A showing control circuit wiring in the receivers, transmitter, and mounting. It also shows Remote Control Unit RM-29-D and field Telephone







DYNAMOTOR DM-34-W, WIRING DIAGRAM



DYNAMOTOR DM-36-W, WIRING DIAGRAM

NOTE:
THESE WIRES SHOULD BE KEPT AS FAR AS POSSIBLE
FROM ALL OTHER WIRES.

Fig. 39. Dynamotors: Schematic and Wiring Diagrams



NOTE:
THE HIGH VOLTAGE LEADS FROM THE GROUNDED END
OF SHIELDING TO THE PLUG TERMINALS SHALL BE
COVERED WITH DIEFLEX FLEXIBLE VARNISHED
TUBING NO. 9 OR EQUIVALENT.

Fig. 39. Dynamotors: Schematic and Wiring Diagrams




Fig. 40. Dynamometers: Apparatus Location Diagrams




Fig. 41. Dynamometer DM-34(*) or Dynamometer DM-36(*): Exploded View




Fig. 42. Dynamotor DM-35-(*) or Dynamotor DM-37-(*): Exploded View

EE-8-(*), so that the wiring of a complete system is included. Refer to Fig. 69 for the discussion which follows.

Connections to the vehicle battery are shown at the lower right of the mounting. The negative side is grounded and the positive lead goes to terminal 1 of mounting receptacles J401, J402, and J403. On the corresponding plugs of the receivers (PG1), terminal 1 connects to the ON-OFF switches D1, and on plug PG101 of the transmitter, terminal 1 connects to the ON-OFF switch D124.

When a receiver ON-OFF switch D1 is closed, the receiver vacuum tube cathodes are heated and the receiver dynamotor starts. The output of either or both receivers is available at receiver headset jacks J1 and J2, when the OUTPUT TO PHONES switches D2 are at ON. Interconnection between headset jacks of the two receivers is over the lead connecting to terminal 21 of PG1. This lead also connects through the mounting to terminal 21 of the transmitter plug PG101, which goes to a winding on transformer T102 of the transmitter to provide sidetone in the receiver headsets when transmitting. Receiver output volume is adjusted by VOLUME control P1, and sidetone level is adjusted by potentiometer P101 in the transmitter. The receiver loudspeakers are turned on or off by switches D3. The antenna connection to the receivers is from the TR binding post on the mounting through terminal A1 of J403 and PG101, through a break contact of the transmitter antenna relay S101, through terminal A2 of PG101 and J403, through terminals A1 of J401 or J402 and PG1, to the grid of vacuum tube V1. Transmitter relay S101 is energized when transmitting, so that the receivers are disconnected from the antenna.

When the transmitter ON-OFF switch D124 is closed, the pilot lamp lights and the vacuum tube filaments are heated. When a carbon-type Microphone T-17 (or T-30) is plugged into jack J102 and the RECEIVER TUNE-OPERATE switch D122 is at OPERATE, the transmitter is ready for operation. Closing the microphone switch energizes dynamotor relay S102, thus starting the transmitter dynamotor. At the same time relays S101 and S103 in the transmitter are

energized. S101 is the antenna relay which transfers the antenna connection from the receiver to the transmitter, applies plate voltage to the power amplifier tube V104, and grounds the bias lead of the oscillator V107. S103 is the receiver disabling relay which, when operated, short-circuits the output of both receivers (leads from S103 contacts through terminals 7 and 22 of PG101 and J403, through terminal 7 of J402, J401, and PG1, to transformers T1 in receivers). Speech signals from the microphone through J102 are amplified in the audio amplifier tubes V105 and V106 and are impressed on the radio-frequency tubes via transformer T102. The lower secondary winding on T102 provides sidetone to the receiver headsets as previously described.

If a magnetic-type Microphone T-33 is used, it is plugged into jack J101 instead of J102. Closing the microphone switch grounds the dynamotor relay S102 winding over leads marked A and B and speech signals are impressed on the audio input transformer T101 via leads marked C and D. Otherwise, operation of the transmitter is the same as that described for the carbon-type microphone.

To furnish carrier-frequency voltage for setting push button selectors in the transmitter and the receiver without putting the transmitter "on the air," the RECEIVER TUNE-OPERATE switch D122 is provided in the transmitter. In the foregoing discussion of operation of the transmitter, it was stated that switch D122 was at OPERATE. When this switch is set to RECEIVER TUNE (after the ON-OFF switch is turned to ON), the transmitter dynamotor relay S102 is energized and the dynamotor starts without a microphone plugged in. The antenna relay S101 and receiver disabling relay S103 do not operate, however, so that carrier voltage is not applied to the antenna and the receiver output is not short-circuited.

Radio Set SCR-608-A may be used with Remote Control Unit RM-29-D and field Telephone EE-8-(*). These are also shown in Fig. 69, and a brief description of their function is given here.

Plug PL-55 of the remote control unit is plugged into a headset jack of the receiver and Plug PL-68 is plugged into the carbon-type microphone jack of the transmitter. A headset is

plugged into Jack JK-34-A of the remote control unit and a carbon-type microphone is plugged into Jack JK-33-A. Leads to the field telephone are connected at terminals L1 and L2. With Switch SW-185 of the remote control unit at RADIO, Jacks JK-33-A and JK-34-A are connected directly through to Plugs PL-68 and PL-55, respectively. When the transmitter and the receiver are turned on, operation is as previously described, except that speech signals pass through the remote control unit. The secondary of transformer C280 is not connected, so that no voice communication with field Telephone LE-8 (*) is possible. The field telephone station may ring the Ringer MC-131 in the remote control unit, however.

To communicate with a remote station, Switch SW-185 of the remote control unit is thrown to TELEPHONE, which disconnects Jacks JK-33-A and JK-34-A from Plugs PL-68 and PL-55 and connects them to transformer C280, also connecting Battery BA-27 in series to provide talking battery supply for the microphone at the remote

control unit. When a remote station is to be called, the handle on the crank of Generator GN-38 is lifted and rotated to the right.

To allow the remote station to transmit and receive over Radio Set SCR-608-A, Switch SW-185 in the remote control unit is set to THROUGH. In this position, the speech signals from the field telephone may be passed to the transmitter by pressing the ANTI-HOWL switch SW-175 in the remote control unit. The ANTI-HOWL switch must be released for speech signals from the receiver to be passed to the field telephone. It is not possible to transmit from the remote control unit when Switch SW-185 is at THROUGH, but the speech signals can and must be monitored with a headset in Jack JK-34-A.

b. Radio Set SCR-628-A. The functions of Radio Set SCR-628-A are exactly the same as Radio Set SCR-608-A except that only one receiver is furnished. With this difference the foregoing discussion of the functioning of Radio Set SCR-608-A applies to Radio Set SCR-628-A.

SECTION IV. MAINTENANCE

Special Notice to Maintenance Personnel: Before making replacement of any parts in this equipment, read Section V and particularly Paragraph 43 for changes in circuit components.

28. General Maintenance Information.

a. Precautions. Use care in servicing this equipment. Servicing should be done only by competent personnel who are supplied with adequate tools and test equipment. An inexperienced operator, in attempting to locate and repair a minor trouble which a competent serviceman could care for in a few moments, might misalign or damage the equipment to such an extent as to require its being sent to a repair depot.

When working with the transmitter, either in use or in testing, make sure that one of the push buttons is *always* depressed when the dynamotor is running. Also, turn the transmitter off whenever possible.

In the following instructions it is necessary in some cases to give values of voltage and current for certain conditions. Because of variations in tubes and other apparatus items, consider such values to be only approximations in most cases. As long as the result obtained does not differ greatly from the typical figure, it is probable that the unit in question is not in trouble.

Several drawings will be useful in connection with maintenance work on this equipment, particularly the location of trouble. The following are included in addition to those mentioned in previous paragraphs:

Fig. 51. Radio Receiver BC-683-A: Location of Alignment and Tuning Controls. This shows where the various knobs and screws are located for use in aligning the tuned circuits and in making other necessary adjustments.

Fig. 52. Radio Transmitter BC-684-A: Location of Alignment and Tuning Controls. This shows where the various adjustments are located for use in aligning

the tuned circuits and in making other necessary adjustments.

Fig. 57. Radio Receiver BC-683-A: Voltage Diagram. This shows the voltages to be expected under normal conditions from various points to the chassis.

Fig. 58. Radio Receiver BC-683-A: Resistance Diagram. This shows the resistance values to be expected from various points on the receiver to the chassis. All resistance measurements are made with the *dynamotor removed* from the receiver.

Fig. 59. Radio Transmitter BC-684-A: Voltage Diagram. This shows the voltages to be expected under normal conditions from various points to the chassis.


Fig. 60. Radio Transmitter BC-684-A: Resistance Diagram. This shows the resistance values to be expected from various points on the receiver to the chassis. All resistance measurements are made with the *dynamotor in place* in the transmitter.

Fig. 61. Mounting FT-237-(*) : Schematic Diagram.

Fig. 62. Mounting FT-237-(*) : Wiring Diagram.

b. General Information. The cleaning, inspecting, and testing procedures contained in this section are intended to prevent development of faults in field service. Operation failures are usually caused by dirt, loose connections, bad vacuum tubes, defective wiring or component parts, misalignment, or incorrect tuning.

Unless otherwise specified, make the following routine checks of the major components after every 300 hours of service. (Check the vehicle battery, charging generator, and voltage regulator prior to making tests of equipment installed in the vehicle.)






Fig. 46. Radio Receiver BC-683-A: Apparatus Location Diagram, Right-side View

(11) Inspect the sockets for dirty or damaged prong grips.

b. Dynamotor Routine. Remove the dynamotor end bells and dust off the commutator and brushes. The receiver dynamotor may be serviced in accordance with Paragraph 41 of this section. Make sure that the dynamotor voltage rating is correct for the vehicle battery.

c. Vacuum Tube Check.

(1) Check the radio-frequency amplifier tube, V1, for tightness in its socket.

(2) Remove the tube and clean the prongs.

(3) Repair or replace the socket if the contact pins on the tube are not gripped properly by the socket receptacles.

(4) Make sure that the tube is of the type specified, VT-112.

(5) Test the tube, if possible, in the tube checker unit of Test Set I-56(*) in accordance with instructions furnished with the tube checker. Do not neglect the short-circuit test.

(6) If the tube is satisfactory put it back in the socket from which it was removed. (Otherwise install a new tube.)

(7) Repeat steps (1) through (6) for the remaining tubes.

Caution: Return each tube to the socket from which it was taken. It is important that even tubes of the same type shall not be interchanged.

d. Voltage Check.

(1) Place all switches on the receiver panel in the downward position. Remove cover.

(2) Connect the receiver to power, preferably with a test cord (such as Cord CD-786, one end of which plugs into a receptacle on the mounting and the other into the receiver under test). Otherwise insert the receiver into a mounting.

(3) Connect a 1000-ohms-per-volt voltmeter or a vacuum-tube voltmeter (250- or 300-volt scale) across capacitor C25, minus (-) to the blue lead and plus (+) to the red-white lead.

(4) Turn the REC switch to ON. Observe the wiring side of the chassis for smoke or sparks. If any are observed, turn the REC switch to OFF at once and check the set completely to remedy the trouble. Then proceed with the following tests:

Caution: High voltages are exposed.

(5) Make sure that, after the tubes are warmed up, the potential across C25 is approximately 200 volts when the supply battery is in good condition.

(6) Check the voltages at each terminal of V6 (limiter) as shown in Fig. 57. The values obtained should be reasonably close to those specified for V6. Approximate agreement with the values given in Fig. 57 indicates that normal voltages are being supplied to a representative tube.

e. Operation Check.

(1) Place all switches on the receiver panel in the downward position. Replace cover.

(2) Insert the receiver into a mounting in which a transmitter is mounted.

(3) Depress the first channel selector buttons on the transmitter and the receiver.

(4) Start the transmitter and the receiver.

(5) Throw the RECEIVER TUNE-OPERATE switch on the transmitter to RECEIVER TUNE and the TUNE-OPERATE switch on the receiver to TUNE.

(6) Throw the SPEAKER switch to ON. If the receiver is in the proper adjustment, and set for the same frequencies as the transmitter, the dial reading should agree with the channel in use, and a beat note should be heard in the loudspeaker.

(7) If no beat note is heard, check the transmitter and receiver controls to be sure that they are in the positions specified and set for the same frequency. If not, tune the receiver as described in Paragraph 21b. If the settings are correct and no beat note is heard, check the receiver in accordance with Paragraph 39.

(8) Throw the SQUELCH switch to ON and observe that the CALL SIGNAL lamp remains lighted. If necessary, adjust the SENSITIVITY control as described in Paragraph 20a(2).

(9) Repeat steps (5) through (7) for each channel set up on the receiver. Turn the RECEIVER TUNE-OPERATE switch on the transmitter back to OPERATE whenever the output is not needed.

(10) Check the operation of the manual tuning mechanism.

(11) Throw the RECEIVER TUNE-OPERATE switch to OPERATE.

(12) Throw the RECEIVER TUNE-OPERATE switch of the transmitter to RECEIVER TUNE. Operate the microphone push button and speak into the microphone. Check the loudspeaker output for normal volume and quality.

Note: The receiver output will be short-circuited by the disabling relay S103 in the transmitter if the RECEIVER TUNE-OPERATE switch is at OPERATE.

(13) Check the sidetone volume in the headset (OUTPUT TO PHONES switch in the OFF position) while talking into the microphone. If sidetone is not heard there may be trouble in either the receiver or the transmitter. Check them in accordance with Paragraph 39 or 40.

(14) Throw the RECEIVER TUNE-OPERATE switch on the transmitter to OPERATE, operate the microphone push button, and speak into the microphone. The sidetone volume should be satisfactory in the headset when the OUTPUT TO PHONES switch is set to ON.

(15) Release the microphone push button and check the volume of noise in the headset. Turn the SPEAKER switch to OFF and note that the noise volume in the headset remains the same.

f. Lubrication of Push-button Mechanism. Inspect the push-button mechanism occasionally. The push-button plungers should be lubricated with a very small amount of Univis 40 oil, or its equivalent. The rack and gears should be lubricated with Univis 115 oil, or its equivalent. Use

only a slight amount of oil, since too much oil may cause the plungers to stick under low-temperature conditions. If it is found necessary to clean the push-button mechanism, kerosene is the preferred cleaning fluid. Under field conditions, where the recommended lubricants may not be available, cleaning should be done with great care and lubricant omitted if the equipment is to be used under low-temperature conditions. *Do not get oil on the locking wedge or the friction washers.*

31. Routine Check of Radio Transmitter BC-684-A.

a. Cleaning and Inspecting.

(1) Remove the transmitter from the mounting.

(2) Clean the case and the panel.

(3) Clean and inspect plug PG101. Make certain that there is a slight play in the plug mounting.

(4) Turn the transmitter upside down and remove the bottom cover plate.

Important: After any repair, adjustment, or replacement of parts is made inside Radio Transmitter BC-684-A, always take a reading with an ohmmeter between coil L119 and ground. If the reading is zero resistance you will burn out resistor R119 as soon as you apply power. *Be careful.*


(5) Inspect the bottom of the transmitter for:

- (a) Loose nuts, bolts, or screws.
- (b) Loose or broken connections.
- (c) Damaged or worn parts.
- (d) Dirt.

(e) Excessive heating. Use your nose as well as your eyes.

(6) Carefully inspect relays S102 and S103. If either relay requires servicing, refer to Paragraph 31f.

(7) Inspect the spring and roller guides which keep the gang capacitor gear rack in place.



SECTION A-A (See Fig. 48)




Fig. 47. Radio Transmitter BC-684-A: Apparatus Location Diagram, End View and Detail Through Section A-A




Fig. 48. Radio Transmitter BC-684-A: Apparatus Location Diagram, Top View




Fig. 49. Radio Transmitter BC-684-A: Apparatus Location Diagram, Front View

- (8) Clean the bottom of the transmitter.
- (9) Replace the bottom cover plate and run the transmitter right side up.
- (10) Remove the top cover plate and the crystal storage drawer. See that the circuit label is secure. (When the drawer has been pulled out to its most extended position it can be removed by raising the back portion and then rotating the front upwards to clear the catch under the back of the drawer.)
- (11) Inspect the top of the transmitter for:
 - (a) Loose nuts, bolts, or screws.
 - (b) Loose or broken connections.
 - (c) Damaged or worn parts.
 - (d) Dirt.
 - (e) Excessive heating.

(12) Carefully inspect relay S101. If this relay requires servicing, refer to Paragraph 31f.

(13) Clean the push-button assembly with compressed air or a bellows. Use of an air hose requires caution as noted in Paragraph 30a(5).

(14) Lubricate the push-button assembly as directed in Paragraph 31g.

Caution: Do not get oil on the locking wedge or friction washers.

(15) Check each socket mounting screw with a screwdriver.

Caution: Do not use abnormal force when tightening the screws.

(16) Check the security of the grounding points.

(17) Inspect the tube clamps.

b. Dynamotor Routine. The transmitter dynamotor may be serviced in accordance with Paragraph 41. Make sure that the dynamotor voltage rating is correct for the vehicle battery.

c. Vacuum Tube Check.

(1) Loosen the tube clamp and check the power amplifier tube, V104, for tightness in its socket.

(2) Remove the tube and clean its prongs.

(3) Repair or replace the socket if the contact pins on the tube are not gripped properly by the socket receptacles.

(4) Make sure that the tube is of the specified type, VT-165.

(5) Check the tube with a tube tester. Do not neglect the short-circuit test.

(6) If the tube is satisfactory, put it back in the socket from which it was taken and retighten the tube clamp. (Otherwise install a new tube.)

(7) Repeat steps (1) through (6) for the remaining tubes. The tubes in the remaining sockets are marked VT-164. Replace each tube in the socket from which it was removed.

d. Crystal Check.

(1) Open the crystal storage drawer and the crystal operating compartment and check the number of crystal holders issued.

(2) See that the required crystal holders are properly placed in the crystal operating compartment.

(3) Check each operating crystal for firmness in its socket.

(4) Replace the crystal storage drawer and the crystal operating compartment cover plate.

e. Operation Check.

(1) Remount the transmitter and associated receiver on the mounting in the vehicle.

(2) If radio transmission is not authorized, remove the antenna lead from the TR binding post on the mounting and connect Antenna A-83 (phantom) to the A and G terminals on the transmitter with short leads.

Note: If Antenna A-83 is not available, an antenna constructed according to Fig. 77 may be used. If, in an emergency, neither of these is available, a 40-watt, 115-volt Mazda lamp may be used. Notice, however, that neither the lamp nor the antenna according to Fig. 77 closely




Fig. 50. Radio Transmitter BC-684-A: Apparatus Location Diagram, Bottom View

simulates the actual antenna; it is therefore doubly important to readjust the antenna trimmers, as covered in paragraph (11) following, after connecting to the real antenna.

(3) Plug in a microphone and a headset.

(4) Turn the transmitter and the receiver on and note that the transmitter pilot lamp lights.

(5) Throw the transmitter RECEIVER TUNE-OPERATE switch to OPERATE and the receiver OUTPUT to PHONES switch to OFF.

(6) Press the microphone button, observe that the dynamotor starts, and talk into the microphone.

(7) Note that sidetone is heard in the headset and that its volume may be varied by adjusting the transmitter SIDETONE control.

(8) Tune the transmitter and the receiver to the same channel and throw the OUTPUT to PHONES switch on the receiver to ON.

(9) Speak into the microphone and observe that the speaker's voice is heard in the headset.

(10) Turn the SPEAKER switch to ON and see that the speaker's voice is not heard. Throw the RECEIVER TUNE-OPERATE switch on the transmitter to RECEIVER TUNE and note the speech output is then obtained from the loudspeaker. Return to OPERATE at the transmitter.

(11) For each push button, check the meter readings in accordance with Paragraph 19b, Table V, for each of the METER SWITCH positions (TUNE-ANT CUR switch ON TUNE) and for the ANT CUR position of the TUNE-ANT CUR switch. It may be necessary to adjust the antenna trimmers (C127 to C136) because of possible differences between the real antenna and the phantom antenna. There will be considerable variation in meter readings among different transmitters due to power supply, vacuum tube, and circuit variations. Experience with a number of transmitters is the best way to learn which readings are satisfactory and which are not. When the transmitter is set to RECEIVER TUNE the meter current for METER SWITCH position 5

will rise to about twice that shown in Table V and the current for METER SWITCH position 6 will drop to about half that shown in Table V. Paragraph 40e gives further information on these differences.

(12) If this check is made in cold weather, notice that the thermostat which controls the heaters in the crystal compartment operates at approximately 70 degrees Fahrenheit.

f. Relay Maintenance.

(1) *General.* Burnish the relay contacts with a burnishing tool or other thin flat piece of smooth metal. Never use abrasive papers or cloths. If the contacts become pitted, a fine file may be used to remove the rougher spots, after which the contacts should be burnished. Take precautions against metallic filings falling or being blown into the apparatus.

No provision is made for adjusting contacts and it should not be necessary under ordinary conditions. The contacts should be parallel when brought together. If some special situation makes it necessary to adjust the contacts, it is preferable to bend the contact arm rather than the spring (except for relay S101).

Warning: The spring assembly of S102 is connected to the vehicle battery even when the transmitter ON-OFF switch is in the OFF position and the green pilot light is extinguished. If you find it necessary to work on this relay be sure to disconnect the battery at plug PG101. If you don't, you are very likely to destroy the relay; you may also get a nasty burn on your hand.

(2) *Antenna Switching Relay S101.* The contact springs are mounted on Isolantite bars which are very brittle. Take care to avoid straining or deforming these bars. If any bending adjustment is required, it should be made on the springs. Keep the points clean.

(3) *Dynamotor Starting Relay S102.* Keep the points clean at all times. When the relay is released, the separation between points should be approximately the thickness of a thin dime. When the relay is operated, the armature travel

should be somewhat more than the amount necessary to close the points. Then the contact springs will be bent slightly and will exert some pressure to hold the points in good contact.

(4) *Receiver Disabling Relay S103.* The points should be kept clean.

g. Lubrication of the Push-button Mechanism. Inspect push-button mechanisms occasionally. Lubricate the push-button plungers with a very small amount of Univis 40 oil, or its equivalent, and the rack and gears with Univis 115 oil, or its equivalent. Use only a slight amount of oil. Too much oil may cause the plungers to stick under low-temperature conditions. (*Caution:* Do not get oil on the locking wedge or friction washers.) If necessary, clean the push-button mechanism with kerosene. Under field conditions, where the recommended lubricants may not be available, cleaning should be done with great care and lubricant omitted if the equipment is to be used under low-temperature conditions.

32. Routine Check of System.

a. Inspection of Antenna System.

(1) See that Wire W-128 or Coaxial Cord CO-282 between the antenna mast base and the binding post of the mounting is properly supported and that the connections are firm and not short-circuited.

(2) Be sure the proper antenna mast sections are installed and that their couplings are firmly joined.

(3) Inspect the antenna mast base carefully. Wipe off all dust and any vegetation that may have caught in the springs. Flex the base to be sure the springs are not broken and that the lead to the radio equipment is in good order.

(4) Carefully inspect all ground straps, if used, and all bolted connections in the ground system. Tighten or resolder any doubtful connections.

b. Talking Tests. Upon completion of the routine tests described in Paragraphs 28 to 32a,

inclusive, it is desirable, if practicable to do so, to talk between two vehicles. Make this test with Antenna A-83 (phantom) instead of the regular radiating system to prevent excessive signal radiation from either equipment. (If no Antenna A-83 is available, use an antenna constructed according to Fig. 77; if this is not possible, use a 40-watt, 115-volt Mazda lamp.) A two-way conversation test should be made with vehicle equipped with Radio Set SCR-608-A or Radio Set SCR-628-A.

33. Emergency Check of Receiver Output Volume and Circuit Alignment.

a. General. When the testing equipment for precision servicing of a receiver is not available, make a rough check of the alignment of the receiver circuits. The tests described may be made with the receiver mounted in the vehicle. Misaligned circuits so found may be realigned with a minimum of testing apparatus by following the directions in Paragraph 34. The location of the alignment controls is shown in Fig. 51.

b. Testing Apparatus Required.

- 1—Radio Transmitter BC-684-A known to be in good condition.
- 1—Microphone T-17 or Microphone T-33.
- 1—Output meter of Test Set I-56-(*) equipped with a 3½-foot assembly of Cordage CO-14 and Plug PL-55.
- 1—Volt-ohmmeter of Test Set I-56-(*), or a 1000-ohms-per-volt voltmeter, or a vacuum tube voltmeter, 3-volt scale.

c. Check of Output Volume.

- (1) Install the transmitter on the mounting.
- (2) Plug in a microphone and adjust the transmitter and the receiver to the same channel (the transmitter not operating).
- (3) Connect the plug and cord assembly of Test Set I-56-(*) to the \pm and VM terminals of the output meter, adjust the meter for the 15-volt scale, and insert the plug into one of the PHONES jacks on the receiver.

(4) Turn the **SPEAKER** switch to **ON**, throw the **TUNE-OPERATE** switch to **OPERATE**, the **OUTPUT TO PHONES** switch to **ON**, and the **SQUELCH** switch to **OFF**. Adjust the **SENSITIVITY** and **VOLUME** controls to the extreme right (maximum volume).

(5) Turn on the transmitter and the receiver and, after the vacuum tubes are hot, throw the **RECEIVER TUNE-OPERATE** switch on the transmitter to **RECEIVER TUNE**.

(6) Operate the microphone switch and whistle or shout for about three seconds into the microphone. The output meter should indicate 12 volts or more; if it does not, check the receiver in accordance with Paragraph 39. (Tune the receiver to the transmitter frequency.)

(7) Check the receiver **VOLUME** control by turning the control to the extreme left while whistling or shouting. The output meter reading should decrease uniformly to 1.0 volt or less; if it does not, it indicates that the **VOLUME** control may be defective or the amplifiers may be noisy.

d. Check of Circuit Alignment.

(1) Remove the receiver dust cover and place the receiver in the right-hand position of the mounting. Leave the left-hand position vacant.

(2) Turn the **SPEAKER** switch to **ON**, throw the **TUNE-OPERATE** switch to **TUNE**, and the **SQUELCH** switch to **ON**. Adjust the **SENSITIVITY** and **VOLUME** controls to the extreme right.

(3) Press any convenient channel push button on the transmitter. Operate both transmitter and receiver **ON-OFF** switches to **ON**. Operate the **RECEIVER TUNE-OPERATE** switch to **RECEIVER TUNE**.

(4) Manually tune the receiver to zero-beat with the transmitter frequency. Make sure that the **CALL SIGNAL** lamp lights. Read the setting of the receiver dial.

(5) Carefully adjust the tuning dial to each side of the zero-beat setting until the **CALL SIG-**

NAL lamp goes out. Note the two dial readings at which the lamp goes out. The lamp should remain lighted over approximately three channel divisions, and the zero-beat setting should be close to the center of this tuning range.

(6) Set the **SENSITIVITY** control to the extreme left (minimum sensitivity) and carefully adjust the tuning dial to each side of the zero-beat setting. The lamp should remain lighted over approximately two channel divisions; and the zero-beat setting should be at the center of this tuning range, within plus or minus one-half channel.

(7) If the zero-beat setting is found to be not centered, in steps (5) and (6), obtain the "reduced-voltage" points as described in Paragraph 33e following and realign the circuits as outlined in this paragraph.

e. Reduced-voltage Points.

(1) Connect the voltmeter across the limiter cathode choke (L1), with the minus (-) terminal of the meter connected to ground. (See Fig. 51.)

(2) Turn the **SPEAKER** switch to **OFF**, set the **TUNE-OPERATE** switch on **OPERATE**, and throw the **SQUELCH** switch to **OFF**.

(3) With the transmitter operating on **RECEIVER TUNE**, manually tune the receiver dial for a maximum deflection of the voltmeter. Note the voltmeter reading and the dial setting.

(4) Carefully adjust the tuning dial to each side of the maximum voltmeter deflection until the voltmeter indicates three fourths of the maximum deflection. Note the two dial readings so obtained. These are the "reduced-voltage" points. The dial should be found adjustable to between plus or minus one-half and plus or minus one channel division without reducing the voltmeter indication to less than three fourths of its maximum deflection.

(5) Throw the **SPEAKER** switch and the **SQUELCH** switch to **ON**, and the **TUNE-OPERATE** switch to **TUNE**.

(6) Tune for zero beat with the transmitter frequency. The zero-beat setting of the dial should be centered between the "reduced-voltage" points. If the zero-beat setting is not centered, the intermediate-frequency oscillator should be adjusted as described in Paragraph 34. If the zero-beat setting is centered with respect to the "reduced-voltage" points but not centered with respect to the dial settings at which the CALL SIGNAL lamp goes out, realign the discriminator circuit, FL4, as described in Paragraph 34.

34. Emergency Alignment of Radio Receiver BC-683-A.

a. General. When a receiver is found to be out of alignment it can be put into serviceable condition if another receiver or another transmitter in good condition is available. Whenever possible, check such emergency alignment in accordance with Paragraph 37. The method using a good receiver is described first as it permits alignment of all stages.

b. Method Using Good Receiver.

(1) *Testing Apparatus Required.* The following testing equipment is required:

- 1—Radio Receiver BC-683-A known to be in good condition.
- 1—Mounting FT-273-(*).
- 1—Insulated $\frac{1}{4}$ -inch hexagon socket wrench.
- 1—Resistor, 1000 ohms (not critical), equipped with clips. (To avoid accidental short circuits, the clips should be insulated, if possible.)
- 1—Voltmeter of Test Set I-56-(*) or other voltmeter of 1000 ohms or more per volt, equipped with approximately 3-foot leads (preferably twisted), and clips.
- 1—Twisted pair (one wire with tracer) about 3 feet long, with clips on both ends, one wire to have a capacitor of 0.001 microfarad or larger between the wire and the clip.
- 1—Wire about eight inches long, with clips at both ends.

3—Wires each about one inch long, with a clip at each end of each wire.

1—Cord CD-786.

Caution: When connecting or disconnecting these wires, turn the receiver off each time to avoid shocks or equipment damage.

(2) *Preliminary Steps.* The following steps in receiver alignment are divided functionally for convenience in description and understanding, but remember that in most cases a change in the alignment of any of the parts involves checking the adjustment of the other parts. The receiver under test will be referred to as the "trouble" receiver in the following discussion.

(a) Remove the covers from both receivers.

(b) Place all switches at OFF (or downward) in both sets. (The SQUELCH switch may have to be turned on subsequently as explained in paragraph (3)(a) following.)

(c) Secure the good receiver in the right-hand position of the mounting. Apply appropriate power to the trouble receiver by means of Cord CD-786 or equivalent.

(d) Turn both sets on and set the TUNE-OPERATE switches at TUNE.

(e) Allow both sets 10 to 15 minutes to warm up.

(f) Connect both chassis together using one wire of the above twisted pair. Use the wire which does *not* have the capacitor in series.

(3) *Tuning of the I-f Oscillator and the I-f Amplifier Tuned Circuits FL1A, FL2A, and FL3A.* A signal from the intermediate-frequency oscillator in the good receiver is picked up by connecting the 0.001-microfarad capacitor (which is attached to the twisted pair as just described) to terminal 7 of FL4 of the good receiver. The other end of the wire in series with the capacitor goes to the control grid (terminal 4) of the modulator (V2) in the trouble receiver, step (c). This tone passes through the intermediate-frequency amplifier and is used to beat with the intermediate-frequency oscillator in the trouble receiver. Thus this intermediate-

frequency oscillator can be tuned to zero-beat with that in the good receiver. As a quantitative indicator for tuning the intermediate-frequency circuits, a 3-volt (1000-or-more-ohms-per-volt) voltmeter is bridged across L1, step (e). A rough adjustment of FL1A, EL2A, FL3A, step (f), may be necessary in order to pass enough intermediate-frequency tone for beating with the intermediate-frequency oscillator. Unless the intermediate-frequency amplifier in the good receiver is shorted, step (b), noise will be superimposed on the test signal. In order to avoid undesirable interference in the alignment, the radio-frequency oscillator in the trouble receiver is disabled by increasing the bias on the grid, step (a). In order to avoid flattened response and consequent errors in alignment, the delayed-automatic-volume-control load resistor, R14, is shorted, step (a). It may be necessary to turn the SQUELCH switch to ON and adjust the SENSITIVITY control until an accurate tuning indication is obtained. In aligning the secondary of an FL unit a 1000-ohm resistor is connected across the primary to improve the accuracy of the adjustment. Similarly, in aligning the primary the resistor is connected across the secondary.

(a) Short-circuit R14 of the trouble receiver. Also connect terminal 5 of V3 to C25—the side to which blue-tracer wires are attached. (It may be necessary to turn the SQUELCH switch to ON and adjust the SENSITIVITY control to obtain a usable reading on the voltmeter when tuning the FL units.)

(b) Short terminals 1 and 2 of FL3A of the good receiver with a short clip lead.

(c) Connect terminal 7 of FL4 in the good receiver through the series capacitor to terminal 4 of V2 in the trouble receiver. Use for this the remaining wire of the twisted pair, the wire which has the capacitor in series. The untwisted part at the ends should be as short as possible. The capacitor should be nearest to the good receiver.

(d) Place the SPEAKER switch of the trouble receiver at ON.

(e) Clip the 3-volt meter across L1 of

the trouble receiver with the negative side on the ground lug.

(f) If the receiver is seriously misaligned, obtain a rough alignment by adjusting the slugs in FL3A, EL2A, and FL1A, in that order, for maximum meter reading. (The 1000-ohm shunt is not used in this procedure.)

Note: If no change in meter reading is observed when the slugs of FL3A are adjusted, turn the good receiver on and off and note the deflection of the meter. If this does not cause any change in deflection the trouble receiver may be faulty and require service. If the deflection is too small for satisfactory reading, the connection at terminal 7 of FL4 may be moved to terminal 2 of FL4 to obtain a larger reading for the preliminary adjustment. After that preliminary adjustment it should be returned to terminal 7 of FL4 which gives a signal strength more appropriate for the subsequent tests.

Caution: The lock washers on the tuning slugs of the tuned circuits may be damaged by turning the slugs in too far. When any adjustment of these units is made, make sure that the tuning slugs bind sufficiently to insure permanency of setting. If they feel loose during adjustment, tighten the lock washers by turning them to the right with a small screwdriver.

(g) Align LCU4 of the trouble receiver for zero-beat and turn the TUNE-OPERATE switch to OPERATE.

(h) Clip the 1000-ohm resistor across terminals 3 and 4 of FL3A. Adjust the primary slug (P) for maximum meter reading.

(i) Remove the 1000-ohm resistor and clip it across terminals 1 and 2 of FL3A and adjust the secondary slug (S) for maximum meter reading.

(j) Repeat step (h) for FL2A.

(k) Repeat step (i) for FL2A.

(l) Repeat step (j) for FL1A.

(m) Repeat step (k) for FL1A and remove the 1000-ohm resistor when the alignment is completed.

(n) It is advisable to check all adjustments, especially that of LCU4.

(4) *Tuning of FL4: The Discriminator Circuit.* The voltmeter is connected across the discriminator load resistors, step (a). The secondary is adjusted for zero d-c output in this meter, step (b). As the secondary slug is adjusted through the proper point, the d-c reading will change polarity. The automatic volume control is restored to operation and the delay bias removed, step (c), and the meter is connected across the resistor (R38) in the plate circuit of V1, step (e), thus giving an indication of automatic-volume-control action amplified through V1. The primary of FL4 can then be adjusted for a minimum reading in the meter. The 1000-ohm shunt is used across the output of FL1A, step (d), to control the gain.

(a) Remove the meter and bridge it across terminals 3 and 7 of FL4. Polarity of the meter cannot be specified as it will depend on the adjustment.

(b) Align the secondary of FL4 for zero reading on the meter. Note that as the slug is varied in either direction from the zero reading, the alignment meter should move *up* scale for one direction and *down* scale for the other.

(c) Remove the short from R14, and ground terminal 1 of FL4.

(d) Place the 1000-ohm shunt between terminals 3 and 4 of FL1A.

(e) Remove the meter and bridge it between terminals 2 and 3 of LCU2A, the positive lead going to terminal 3. It may be necessary to use the 30-volt scale.

(f) Align the primary of FL4 for minimum meter reading.

(g) Remove both the 1000-ohm shunt and the meter.

(h) Remove the short between C25 and terminal 5 of V3.

(i) Remove the lead from terminal 4 of V2 of the trouble receiver, and from terminal 7 of FL4 of the good receiver.

(j) Remove the short between terminal 1 of FL4 and ground.

(5) *Tuning of the R-f Oscillator, Assuming the Intermediate Frequency to be Exactly*

2.65 MC. This involves beating the radio-frequency oscillator of the trouble receiver with that of the good receiver to give zero-beat in the loudspeaker. The stray pickup in the trouble receiver from the good receiver is sufficient so that no direct connection of the radio frequency between the two receivers is required. The intermediate-frequency oscillator of the trouble receiver has been adjusted and is thus suitable for beating purposes. The meter is bridged across L1, step (a), as an indicator to show when the current through the intermediate-frequency amplifier is increasing even though the frequencies are not close enough together to give an audible beat. It is left in this position to show when LCU1A and LCU2A are properly adjusted. The short is placed across R14, step (b), to avoid a flattened response curve, as discussed in Paragraph 34b(3). The intermediate-frequency oscillator is turned on, step (c), to provide a beat-note. At the upper end of the scale the oscillator is set by adjusting the trimmer C1.7 to give zero-beat in the loudspeaker. Since the intermediate frequency is nominally 2.65 megacycles, there must be a corresponding difference between the two oscillators involved in order to produce a beat tone which will pass through the intermediate-frequency amplifier. For the high-frequency end of the scale, set the trouble receiver dial at 39 megacycles and set the good receiver dial at $(39 - 2.65 =) 36.35$ megacycles. Then the trimmer, C1.7, is set for zero-beat in the loudspeaker. For the low-frequency end of the scale set the good receiver dial at 27 megacycles and the trouble receiver at 29.65 megacycles. With this setting the slug in LCU3A is set for zero-beat. These two adjustments are then made alternately until the oscillator "tracks" satisfactorily at both ends of the band.

(a) Bridge the meter across L1 (negative terminal toward ground).

(b) Place a short across resistor R14.

(c) Place the TUNE-OPERATE switch of the trouble receiver at TUNE and throw the TUNE-OPERATE switch in the good receiver to OPERATE.

(d) Assuming the intermediate frequency to be 2.65 megacycles, set the good re-

ceiver at $(39 - 2.65 =) 36.35$ megacycles and the trouble receiver at 39 megacycles.

(c) Adjust the radio-frequency oscillator trimmer capacitor C1.7 of the trouble receiver to give zero-beat in the loudspeaker.

(f) Still assuming the intermediate frequency to be 2.65 megacycles, set the good receiver at 27 megacycles and the trouble receiver at $(27 + 2.65 =) 29.65$ megacycles, and, in the same way, adjust the slug in LCU3A for zero-beat.

(g) Repeat the preceding two steps until the radio-frequency oscillator tracks at both ends of the band.

(6) *Check of the Intermediate Frequency and Readjustment of the R-f Oscillator.* In the foregoing procedure it was assumed that both the intermediate-frequency amplifier stages and the intermediate-frequency oscillator were adjusted to exactly 2.65 megacycles. Actually, a variation in this frequency over a moderate range will not interfere with satisfactory operation as long as the adjustment of the radio-frequency oscillator is consistent with the intermediate frequency. For example, if the dial of the trouble receiver is set at 39 when the intermediate-frequency amplifier (and oscillator) circuits of the good receiver and the trouble receiver are tuned for 2.5 megacycles, then set the dial of the good receiver at $(39 - 2.5 =) 36.5$ megacycles for aligning the radio-frequency oscillator in the trouble receiver. Otherwise, the dial calibration will not be correct. For this reason, it is desirable to make the following tests which supplement Paragraph 34b(5) rather than supersede it. The trouble receiver is set (in the middle of the range) at 33 megacycles and the good receiver is adjusted to a frequency which will give zero-beat with the intermediate-frequency oscillator in the trouble receiver. The reading on the dial of the good receiver should be very close to $(33 - 2.65 =) 30.35$ megacycles. (This reading serves as a guide. The second beat, to be obtained near 35.65, is a better indication of the accuracy of adjustment.) A similar beat, though not so strong, can be obtained by tuning the good receiver the same distance above the trouble re-

ceiver. (If the beat note cannot be found readily, due to insufficient pickup, connect the bared end of a piece of insulated wire to the A post of the trouble receiver and extend it across the top of the good receiver to act as an antenna. Remove this wire when the observation is complete.) This dial setting should be between 35.6 and 35.7 megacycles. This allows for the 0.05-megacycle tolerance at $(33 + 2.65 =) 35.65$ megacycles. If it falls within that range, the radio-frequency oscillator is properly tuned and no further work on it is necessary. If not, steps (d) through (g) should be followed. Assume, as an example, that the two dial settings giving zero-beat were 30.35 and 35.35 megacycles. Half the difference between these frequencies represents the true intermediate frequency which, in this example, comes out as 2.5 megacycles. This figure is then used instead of 2.65 in steps (d) to (g). Ordinarily, the necessary correction will be obtained by a slight change in the trimmer C1.7 at the high end of the scale. The procedure to be followed if a correction is necessary is described in steps (a) through (g).

(a) Set the dial of the trouble receiver to 33 megacycles.

(b) Adjust the dial of the good receiver to give zero-beat at approximately 30.35 megacycles and note the dial reading at which it occurs.

(c) Leaving the trouble receiver tuned to 33 megacycles, retune the good receiver to obtain the (somewhat weaker) beat note between 35 and 36 megacycles. Note the dial reading.

(d) By subtraction, obtain the difference between the two dial readings obtained in steps (b) and (c).

(e) Divide this difference by two.

(f) The value obtained in this way is the actual intermediate frequency.

(g) Repeat the alignment procedure, (5)(d) through (g), for the radio-frequency oscillator, using this value in place of 2.65 megacycles.

(h) Make certain that the radio-frequency oscillator tracks at both ends of the band.

(i) Remove the short from terminals 1 and 2 of FL3A in the good receiver.

(j) Replace the cover on the good receiver.

(7) *Adjusting LCU1A and LCU2A.* In tuning the radio-frequency circuits a shunt is placed across FL1A, step (a), to avoid limiting action. Also, R14 is shorted and the SQUELCH switch turned to ON for the reasons just discussed. If the trouble receiver is not in a mounting, the ground on the primary at LCU1A is floating. Therefore, terminal 2 of LCU1A must be shorted directly to ground, step (b). Also, short the antenna post (terminal 3 of LCU1A) to terminal 2 and ground, step (b), as its effect on the adjustment of the secondary would be noticeable if it were allowed to float. Without the ground, this floating condition would exist as there is no termination across the primary of LCU1A when we are relying on stray pickup for the test signal. For preliminary alignment, at the top of the frequency band, adjust the trimmers C1.1, C1.3, and C1.5 to give maximum reading in the meter; at the bottom of the band, adjust the slugs of LCU1A and LCU2A for maximum meter reading. For final alignment, the 1000-ohm shunt should be removed, the good receiver turned off, and the final alignment of LCU1A and LCU2A made on noise alone at both ends of the scale. This procedure is given as step (k).

(a) Place a 1000-ohm shunt between terminals 1 and 2 of FL1A. Connect the 3-volt meter across L1 of the receiver with the negative side on ground lug. Short R14.

(b) Short terminals 3 and 2 of LCU1A to ground, using the shortest wires.

(c) Set the dial of the trouble receiver to 39 megacycles.

(d) Tune the good receiver at approximately 36.35 megacycles on the dial to give a beat note on the loudspeaker.

(e) Align C1.1, C1.3, and C1.5 for maximum reading on the meter.

(f) Set the dial of the good receiver at 27 megacycles.

(g) Tune the trouble receiver at approximately 29.65 megacycles to give a beat note.

(h) Adjust the slugs in both the primary

and secondary of LCU2A and the slug in LCU1A for maximum reading of the meter.

(i) Repeat steps (c) through (h) until these units track at both ends of the band. (This completes the rough adjustment.)

(j) Turn the good receiver off. Turn the SQUELCH switch of the trouble receiver to OFF. Remove the 1000-ohm shunt from FL1A of the trouble receiver.

(k) Repeat the alignment steps for LCU1A and LCU2A using noise background alone for maximum meter reading at both ends of the dial (27 and 39 megacycles).

(l) Remove the short circuit from R14. Remove also the meter, and the short circuits from terminals 3 and 2 of LCU1A to ground.

(m) Replace all cover plates securely.

(n) Replace the dust cover.

(o) Reset the push buttons using a transmitter as described in Paragraph 21a.

(p) Place the set in its installation and trim C1.1.

c. Method Using Transmitter.

(1) *General.* One, or possibly two, misaligned circuits in a receiver can be roughly aligned with the remaining circuits of the receiver, in an emergency, by using an associated transmitter, or the transmitter in a nearby vehicle, as a source of testing frequency. Such an emergency alignment should be checked in accordance with Paragraph 37 as soon as practicable. Alignment of the radio-frequency oscillator unit (LCU3A) should not be attempted by this method. In the instructions which follow, it is assumed that the radio-frequency oscillator is functioning properly.

It is also assumed here that the source of radio-frequency testing frequency is the associated transmitter. Modifications to adapt the method to the use of a transmitter in a nearby vehicle are obvious. (For example, when the local transmitter is used, the RECEIVER TUNE-OPERATE switch is turned to RECEIVER TUNE, whereas it is turned to OPERATE when another vehicle is used.)

Note: During the following tests, operate the

transmitter dynamotor only when reading the meter or making an adjustment which requires power from the dynamotor.

(2) Testing Apparatus Required.

1—Radio Transmitter BC-684-A known to be in good condition.

1—Mounting FT-237-(*).

1—Volt-ohmmeter of Test Set I-56-(*), or a 1000-ohm-per-volt voltmeter, or a vacuum-tube voltmeter. Meter to have a 3-volt scale and also a 10- or 30-volt scale.

1—Insulated $\frac{1}{4}$ -inch hexagon socket wrench.

1—IRC BT- $\frac{1}{2}$, 5000-ohm resistor or its equivalent with clips and short leads.

1—500-micromicrofarad mica capacitor with small clips and very short leads.

2—Wires, each $1\frac{1}{2}$ -inches long, with a small clip on each end of each wire.

1—Wire, 6-inches long, with small clip on each end.

(3) Emergency Alignment of I-f Oscillator.

Align a defective or replacement LCU4 tuning unit as follows:

(a) Install transmitter and receiver on the mounting. Place the receiver in the right-hand position.

(b) Find the "reduced-voltage" points as directed by Paragraph 33e, and make your setting halfway between.

(c) Remove the cover plate which permits access to the adjusting screw in LCU4.

(d) Vary the setting of this screw until a beat note is heard. Carefully adjust for zero-beat. This step brings the replacement tuning unit, LCU4, into alignment with the intermediate-frequency amplifier.

(4) Emergency Alignment of I-f Amplifier.

Emergency alignment of an intermediate-frequency filter unit (FL1A, FL2A, FL3A) may be accomplished as follows:

(a) Install the transmitter and the receiver in the mounting, with the receiver in the right-hand position.

(b) Connect the voltmeter (3-volt scale) across the limiter cathode choke, L1, as shown in Fig. 51.

(c) Disable the automatic-volume-control circuit by short-circuiting resistor R14. Use the short jumper wire with a clip on each end.

(d) Using the 6-inch jumper, wind a coil of four turns of $\frac{1}{4}$ -inch diameter about $\frac{1}{2}$ -inch long. Connect this coil between terminal 4 (control grid) of modulator tube V2 and the adjacent socket ground terminal. This shunt is to reduce the input to the intermediate-frequency amplifier to a point where the action of the limiter circuits will not mask the tuning point during tests. It may be found necessary to adjust the number of turns or the spacing to secure suitable values, step (h).

(e) Turn the receiver ON-OFF switch to ON; the TUNE-OPERATE switch to TUNE; the SPEAKER switch to ON; the SQUELCH switch to OFF; the VOLUME control to the extreme right. Release the tuning dial by depressing one of the CHANNEL SELECTOR push buttons part way.

(f) Adjust the transmitter to a channel near the 27-megacycle end of its frequency range. Turn the transmitter on. Place the RECEIVER TUNE-OPERATE switch on RECEIVER TUNE.

(g) After the receiver has had time to warm up, carefully adjust the receiver dial (use the same setting as on the transmitter) for zero-beat with the transmitter signal and note the maximum deflection of the voltmeter as the dial is tuned through the zero-beat point. The meter deflection should decrease as the dial is varied to either side of zero-beat. Restore the zero-beat adjustment after completing the observation.

(h) Remove the coil from V2 and note the reading of the voltmeter. The voltmeter reading with the coil in place should not be more than three fourths of the reading with the coil removed. If it is more, adjust the spacing of the turns or change the number of turns until a satisfactory reading is obtained.

(i) Replace the coil.

(j) Detune the receiver by several channels (to a point where no signals are being received) and note the minimum voltmeter read-

ing. (The voltmeter is effective as a tuning indicator only if its deflection is kept between the minimum value and the "three-fourths" reading, step (h). Therefore, keep the deflection within this range at all times during this procedure.)

(k) Remove the cover plates from the tuning unit (FL1A, FL2A, or FL3A) to be aligned.

(l) Adjust the μ (primary) and s (secondary) adjusting screws of the tuning unit for a rough approximation of the maximum voltmeter deflection.

(m) Connect the 5000-ohm resistor between terminals 3 and 4 of the tuning unit being adjusted.

(n) Adjust the P screw for a maximum voltmeter reading. See the Note following step (p).

(o) Remove the resistor from terminals 3 and 4 and connect it between terminals 1 and 2.

(p) Adjust the s screw for maximum voltmeter reading.

Note: Check the zero-beat setting occasionally as the work progresses. Also, keep the voltmeter within the limits given in step (j) by adjusting the shunting coil as necessary. Remove the coil and the 5000-ohm resistor.

(5) *Emergency Alignment of R-f Amplifier.* Make an emergency alignment of a radio-frequency tuning unit (LCU1A or LCU2A) as follows:

(a) Install the transmitter and the receiver in the mounting, with the receiver in the right-hand position.

(b) Connect the voltmeter (3-volt scale) across the limiter cathode choke, L1, as shown in Fig. 51.

(c) Disable the automatic-volume-control circuit by short-circuiting resistor R14. Use the short jumper wire with a clip on each end.

(d) Connect the 500-micromicrofarad capacitor between terminals 1 and 2 of filter unit FL1A. (The capacitor reduces the signal input to the intermediate-frequency amplifier sufficiently to prevent limiter action from masking the desired tuning point in the test.)

(e) Remove the cover plates from the LCU1A and LCU2A tuning units and from the trimmer capacitors, C1.3, C1.5, and C1.7. (The cover plate of C1.7 is beside C24.)

Caution: Do not disturb the setting of the oscillator trimmer capacitor C1.7 during this alignment.

(f) Turn the SPEAKER switch to ON, set the TUNE-OPERATE switch to TUNE, and turn the SQUELCH switch to OFF. Turn the VOLUME control to the extreme right.


(g) Adjust the transmitter for operation near the 39-megacycle end of its frequency range and start the transmitter and the receiver. Place the transmitter in the RECEIVER TUNE condition.

(h) After the receiver has warmed up, carefully adjust the receiver dial for zero-beat with the transmitter (the receiver dial should read the frequency to which the transmitter is set). Adjust each of trimmer capacitors C1.1, C1.3, and C1.5, for maximum voltmeter deflection. If the 500-micromicrofarad capacitor bridged across terminals 1 and 2 of FL1A has not reduced the signal strength (from the transmitter) sufficiently to obtain a good range of meter deflection, a further reduction may be obtained by connecting that capacitor across terminals 1 and 2 of either FL2A or FL3A instead of FL1A. When the trimmers are properly set, the voltmeter deflection decreases as the set is detuned from the zero-beat point.

(i) Remove the 500-micromicrofarad capacitor shunt from terminals 1 and 2 of the filter unit shunted as called for in step (g). The voltmeter reading with the capacitor in place should be not more than three fourths of the reading with the capacitor removed. If it is more, the capacitor leads are too long, or the clips are not making good contact.

(j) Replace the capacitor and trim the settings of C1.1, C1.3, and C1.5, if necessary.

(k) Operate the transmitter near the 27-megacycle end of its frequency range and carefully adjust the receiver to zero-beat with the transmitter. The reading of the receiver dial should correspond with the transmitter frequency.



NOTES:

1. WHEN THE SHUNTING RESISTOR IS CONNECTED ACROSS TERMINALS 1 AND 2, ADJUST SCREW "S".
2. WHEN THE SHUNTING RESISTOR IS CONNECTED ACROSS TERMINALS 3 AND 4, ADJUST SCREW "P". (THE ADJUSTING SCREWS REFERRED TO IN NOTES 1 AND 2 ARE ACCESSIBLE THROUGH THE TOP OF THE FILTER COVER ON THE OTHER SIDE OF THE CHASSIS, AND THE SHUNTING RESISTOR IS CONNECTED AS DESCRIBED IN PARAGRAPHS 34b, 34c, AND 37d).
3. ADJUSTING SCREWS ARE ACCESSIBLE THROUGH THE COVER ON THE OTHER SIDE OF THE CHASSIS.
4. CONNECT THE HIGH SIDE OF THE SIGNAL-GENERATOR OUTPUT TO TERMINAL 6 OF FL3 THROUGH A 0.005-MF MICA CAPACITOR FOR DISCRIMINATOR (FL4) ADJUSTMENT. CONNECT THE LOW SIDE OF THE SIGNAL-GENERATOR TO CHASSIS.

Fig. 51. Radio Receiver BC-683-A: Location of Alignment and Tuning Controls

(l) Adjust the P (primary) and s (secondary) adjusting screws in tuning unit LCU2A and the single adjusting screw in LCU1A for maximum deflection of the voltmeter.

(m) Readjust the transmitter and receiver to the higher test frequency and trim C1.1, C1.3, and C1.5 for maximum voltmeter deflection.

(n) Check back and forth between the two test frequencies, repeating steps (l) and (m) until no further improvement can be made.

(o) Restore the receiver to normal and check the antenna trimmer capacitor as described in Paragraph 19a.

(6) *Emergency Alignment of Discriminator.* Align a discriminator filter unit (FL4) in an emergency as follows:

(a) Install the transmitter and the receiver in the mounting, with the receiver in the right-hand position.

(b) Connect the voltmeter (3-volt scale) across the limiter cathode choke, L1, as shown in Fig. 51.

(c) Disable the automatic-volume-control circuit by short-circuiting resistor R14. Use the short jumper wire with a clip on each end.

(d) Connect the 500-micromicrofarad capacitor between terminals 1 and 2 of filter unit FL2A. (The capacitor reduces the signal input to the intermediate-frequency amplifier sufficiently to prevent limiter action from masking the desired tuning point in the test.)

(e) Remove the cover plate from filter FL4.

(f) Turn the SPEAKER switch to ON, turn the TUNE-OPERATE switch to TUNE, and turn the SQUELCH switch to OFF. Turn the VOLUME control to the extreme right.

(g) Adjust the transmitter for operation near the 27-megacycle end of its frequency range and start the transmitter and the receiver. Place the transmitter in the RECEIVER TUNE condition.

(h) After the receiver has warmed up, carefully adjust the receiver tuning dial for zero-beat with the transmitter frequency. Observe that zero-beat occurs at maximum deflection of the

voltmeter and note the maximum reading.

(i) Remove the capacitor from FL2A and note the new voltmeter reading. The voltmeter reading with the capacitor connected to FL2A should not exceed three fourths of the reading with the capacitor removed. If it does, the capacitor leads are too long, or the clips are not making good contact.

(j) Reconnect the capacitor to terminals 1 and 2 of FL2A.

(k) Ground terminal 1 of FL4 to the chassis with a short jumper wire. Remove the voltmeter from across L1 and connect it between terminals 3 and 7 of filter FL4 (10-volt or 30-volt scale, + terminal to terminal 3 of the filter).

(l) Check the zero-beat setting of the dial while observing the voltmeter. The meter should read zero at zero-beat and reverse polarity as the receiver is tuned through the zero-beat point. If this is not the case, align the secondary by adjusting the s (secondary) adjusting screw for zero voltmeter reading.

(m) Remove the voltmeter from FL4 and connect it (3-volt scale) between terminals 2 and 3 of tuning unit LCU2A (+ terminal of voltmeter to terminal 3 of LCU2A). Remove the short circuit from resistor R14.

(n) Adjust the P (primary) screw in filter FL4 for a minimum deflection of the voltmeter.

(o) Reconnect the voltmeter (10-volt or 30-volt scale) to terminals 3 and 7 of FL4 and recheck the adjustment of screw s in FL4 as in step (l).

(p) Restore the receiver to normal.

35. Emergency Alignment of Radio Transmitter BC-684-A.

a. *General.* The test procedures described hereafter are intended to apply when it is necessary to replace one or more transmitter components which are likely to affect alignment of the transmitter tuned circuits and a precision wavemeter is not available for use. The critical components are: coils L101, L103A, L104, L105A, L106, L107, L108, and L110; the ganged adjustable capacitor assembly C106, C113, C115,

C119, C125, C152, and C156; and trimmer capacitors C107 (if used in the transmitter under test), C114, C116, C120, C126, C153, and C157. Replacement of capacitor C147 or the channel selector assembly also necessitates checking alignment of the circuits. The location of the alignment controls for the transmitter is shown in Fig. 52.

Note: During the following tests operate the dynamotor only when reading the meter or making an adjustment which requires power from the dynamotor. Paragraph 20b should be read and understood before the following or other servicing tests are made.

b. Testing Apparatus Required.

1—Narrow-blade ($\frac{1}{8}$ -inch) screwdriver or, preferably, a long-handled hexagon adjusting tool.

1—Rule (6-inches long x $\frac{1}{8}$ -inch wide).

c. Preliminary to Alignment. It is desirable to check the operation of the oscillator and metering circuits prior to emergency alignment of the transmitter circuits. This may be done as follows:

(1) Insert a low-numbered and a high-numbered crystal (preferably Channel 270 and Channel 389) in sockets numbered 1 and 10, respectively, in the crystal operating compartment.

(2) Set the METER SWITCH to position 2 (first radio-frequency amplifier grid current), turn the TUNE-ANT CUR switch to TUNE, and unlock the channel selector. This is described in Paragraph 21a.

(3) Press CHANNEL SELECTOR push button no. 1, start the transmitter, and operate the RECEIVER TUNE-OPERATE switch to RECEIVER TUNE.

(4) Observe the reading on the panel meter.

(5) Repeat steps (3) and (4) for push button no. 10. If meter readings are noted for both these frequencies the oscillator is operating properly.

d. Emergency Alignment of R-f Amplifier.

(1) In later transmitters C107 has been omitted, but if there is a C107 in the transmitter under test, see that it is set to the minimum capacitance position (open end of slot to left as viewed from the front of the transmitter).

(2) Press CHANNEL SELECTOR push-button no. 10. Set the METER SWITCH to position 3 (grid current of rectifier) and the RECEIVER TUNE-OPERATE switch to RECEIVER TUNE.

(3) Adjust the gang capacitor assembly for maximum deflection of the meter.

(4) Press push button no. 1 and repeat step (3).

(5) Carefully release push button no. 1, carefully turn the gang capacitor control to the extreme front, and lock the selector unit as also described in Paragraph 21a.


(6) Check the CHANNEL SELECTOR adjustments by pressing the no. 1 and no. 10 push buttons and observing the maximum meter deflection at each frequency as the gang capacitor assembly is rotated slightly against the restoring force of the selector. *Do not attempt to rotate the capacitor assembly more than a few degrees.* The test meter should indicate a maximum at the settings determined by the selector. If this is not the case, repeat steps (2) through (6) until you obtain the proper adjustment of the selector.

e. Emergency Alignment of Rectifier. Since the filters following the rectifier are primarily intended for selection of the correct crystal harmonic frequency, it is important that these circuits be disturbed as little as possible when replacing components which affect the alignment.

(1) If L118 or L119 has been replaced, adjust the tuning slugs to about $\frac{3}{4}$ inch from the open end of the coil as measured with the scale mentioned in Paragraph 35b.


(2) Set the METER SWITCH to position 4 (grid current of tripler).

(3) Start the transmitter at the high-frequency end of its range (by pressing the appropriate CHANNEL SELECTOR push button and



TOP VIEW OF TRANSMITTER, COVER REMOVED, SHOWING
LOCATION OF GAMING ADJUSTMENTS AND TUNING

Fig. 52. Radio Transmitter BC-684-A: Location of A



Transmitter BC-684-A: Location of Alignment and Tuning Controls

throwing the RECEIVER TUNE-OPERATE switch to RECEIVER TUNE).

(4) Adjust C153 and C157, respectively, for maximum deflection of the meter.

(5) Adjust the transmitter to the low-frequency end of its range (by pressing the appropriate CHANNEL SELECTOR push button and throwing the RECEIVER TUNE-OPERATE switch to RECEIVER TUNE) and adjust L119 and L118, in turn, for maximum meter deflection.

(6) Repeat steps (3), (4), and (5) until no further increase in meter deflection can be obtained.

(7) Start a nearby receiver, throw the SPEAKER switch to ON, the TUNE-OPERATE switch to TUNE, and the SQUELCH switch to ON. Adjust the SENSITIVITY control so that the receiver is operated by only one frequency from the transmitter. This frequency, as determined from the receiver dial calibration, should be that for which the transmitter is tuned. If it is not, readjust the filter circuits but with a somewhat different initial setting of the tuning slugs in L118 and L119 until the receiver (used as a wavemeter) indicates that this stage has been aligned properly and the correct harmonic has been chosen by the L118, L119 and C153, C157 circuits.

f. Emergency Alignment of Tripler.

(1) If L106 or L107 has been replaced, adjust the tuning slugs to about three-fourths inch from the open end of the coil.

(2) Set the METER SWITCH to position 1 (grid current of doubler).

(3) Adjust the transmitter at the high-frequency end of its range. (See Paragraph 35c.)

(4) Adjust C114 and C116, in turn, for maximum deflection of the meter.

(5) Adjust the transmitter to the low-frequency end of its range and adjust L106 and L107 for maximum meter deflection.

(6) Repeat steps (3), (4), and (5) until no further increase in meter deflection is obtainable.

g. Emergency Alignment of Doubler.

(1) If L108 has been replaced, adjust the tuning slug to about $\frac{3}{4}$ inch from the open end of the coil.

(2) Set the METER SWITCH to position 5 (grid current of power amplifier).

(3) Adjust the transmitter at the high-frequency end of its range and adjust C120 for maximum meter deflection.

(4) Adjust the transmitter to the low-frequency end of its range and adjust L108 for maximum deflection of the meter.

(5) Repeat steps (3) and (4) until no further increase in meter deflection is possible.

h. Emergency Alignment of Power Amplifier.

(1) If the L110-L111 coil assembly has been replaced, adjust the tuning slug at the bottom of L110 to the center of its range of variation.

(2) Set the METER SWITCH to position 6 (total plate and screen current) and make sure the RECEIVER TUNE-OPERATE switch is at OPERATE and left there for the following power amplifier tests.

(3) Set for minimum coupling of L111 to L110 (rotation of the coupling control to the right). Detune C136 by setting it to the maximum capacitance position and detune C127 by adjusting it to the minimum capacitance position.

(4) Start the transmitter at the high-frequency end of its range. (For this test the dynamotor must be started by operating a microphone switch.) Adjust C126 for a *minimum* deflection of the meter. If a tuning point cannot be found, try a different setting of the L110 adjusting slug.

(5) Adjust the transmitter to the low-frequency end of its range. Adjust the slug in L110 for a *minimum* deflection of the meter. Adjust this slug by inserting a screwdriver through the hole in the end of the transmitter and turning the slug adjusting gear.

(6) Adjust C126 at the higher frequency and L110 at the lower frequency until no further reduction in the meter deflection can be made at either end.

36. Emergency Sources of Test Tones. In the absence of a test oscillator, test tones can be obtained from a receiver or a transmitter known to be in good condition. The methods of doing this are discussed in detail in Paragraph 39g(6) for the receiver and Paragraph 39g(7) for the transmitter. Signal sources other than a signal generator may be summarized as follows:

a. A-f Signal.

(1) A good receiver will provide audio-frequency noise when there is no input signal.

(2) If two good receivers are available they can be used together to provide a beat note.

(3) A good transmitter may be used with a microphone into which the operator hums or whistles. The resulting audio output can be picked up for test purposes.

b. I-f Signal. This may be obtained from a good receiver.

c. R-f Signal. This may be obtained from either a receiver or a transmitter.

d. Atmospheric Noise. Atmospheric noise may be used as a signal source in the absence of other signal source. Since noise is an indefinite sort of signal (no precise frequency) and the intermediate-frequency band width is considerably wider than the range of frequency which may be heard, the number of circuits aligned by this means should be a minimum.

e. Signals from Distant Vehicle. Signals from a vehicle about 10 miles distant may be used as a rough check of receiver sensitivity, particularly when such signals are compared to the noise background when the distant transmitter is off the air.

f. Signals from Nearby Vehicle. Signals from a nearby vehicle which is operating into

Antenna A-83 (phantom), or the antenna shown in Fig. 77, or a 40-watt Mazda lamp, instead of the regular antenna structure, are strong enough for testing purposes.

37. Precision Alignment of Radio Receiver BC-683-A.

a. General. Whenever a complete inspection of a receiver is made, check alignment of the tuned circuits in accordance with the following procedure:

b. Testing Apparatus Required.

1-Adapter FT-384(*).

1-Insulated 1/4-inch hexagon socket wrench.

1-Output meter from Test Set I-56(*), or its equivalent.

1-Volt-ohmmeter I-107(*), or its equivalent.

1-Signal generator (frequency-modulated).

1-Cornell-Dubilier capacitor, Type 1W, 0.006-microfarad, or its equivalent, with suitable clips.

1-IRC resistor, Type BT-1/2, 1000 ohms, or its equivalent, equipped with insulated clip connectors.

Caution: When connecting or disconnecting these wires, turn the receiver off each time to avoid shocks.

Adapter FT-384(*) is a switching box for connecting test meters in various parts of the circuit to facilitate alignment procedure. Photographs and a circuit diagram are shown in the following figures:

Fig. 53. Adapter FT-384(*) : Front View.

Fig. 54. Adapter FT-384(*) : Back View.

Fig. 55. Adapter FT-384(*) : Application to Radio Receiver BC-683-A.

Fig. 56. Adapter FT-384(*) : Schematic and Wiring Diagram.

c. Alignment of Discriminator Circuit (FL4) and I-f Oscillator Circuit (LCU4). When aligning the intermediate-frequency amplifier or discriminator, if no shielded room is



Fig. 53. Adapter FT-384(*): Front View



Fig. 54. Adapter FT-384(*): Back View

available and disturbing interference from nearby electrical equipment is observed, this interference can be minimized by connecting a short strap lead from terminal 5 of V3 to C25 (the terminal to which blue-tracer wires are connected), whenever using the intermediate frequency.

(1) Remove the dust cover from the receiver.

(2) Make sure that a dynamotor of the correct primary voltage rating is in place.

(3) Loosen the cover plates from LCU1A, LCU2A, FL1A, FL2A, FL3A, FL4, and LCU4. (The plates may be loosened by removing the cotter pin at one end.)

Caution: Do not remove the cover from LCU3A.

(4) Set the receiver controls as follows: The **SPEAKER** switch at ON, the **SENSITIVITY** and **VOLUME** controls to the extreme right, the **TUNE-OPERATE** switch at OPERATE, the **REC** switch at OFF until ready, the **OUTPUT TO PHONES** switch at ON, and the **SQUELCH** switch at OFF.

(5) Set up Volt-ohmmeter I-107-(*) as follows: Connect the battery plug attached to the short cable at the bottom of the volt-ohmmeter to a Battery BA-40. Set the **SELECTOR** switch for —VOLTS and the **RANGE** switch for 3 V.D.C. Short the **COMMON** and **D.C. VOLTS** leads together and turn the **ZERO ADJ** knob for zero indication on the meter. It is advisable to leave Volt-ohmmeter

I-107-(*) on for approximately five minutes before using it, to allow the zero adjustment of the meter to become stable. Connect the volt-ohmmeter leads to the V.T.V.M. posts of Adapter FT-384-(*).

(6) Connect the high side of the signal generator output through the 0.006-microfarad capacitor to the limiter control grid (terminal 6 of FL3A) and connect the low side of the generator to the chassis.

(7) Adjust the generator for an output of between 1.0 and 2 volts at 2.65 megacycles.

(8) Plug Adapter FT-384-(*) into receptacle PG1 of the receiver and connect to the battery. Turn the switch of the adapter to MSC (discriminator output voltage).

(9) Turn the receiver to ON and, after allowing sufficient time for the vacuum tubes to heat, adjust screw s (secondary) in filter FL4 for zero current in the voltmeter. The meter should reverse polarity as s is varied to either side of the zero-current point. The selector switch of Volt-ohmmeter I-107-(*) can be turned from —VOLTS to +VOLTS to note this effect. This is an accurate indication of frequency and can be used as a check during the test. A check may be made from time to time to make sure that this meter still reads zero. If it does not, the signal generator should be readjusted to restore the reading to zero.

(10) Throw the **TUNE-OPERATE** switch to TUNE. Adjust the slug in tuning unit LCU4 for




Fig. 55. Adapter FT-384(*): Application to Radio Receiver BC-683-A

zero-beat. Set the TUNE-OPERATE switch to OPERATE.

(11) Turn the switch of the adapter to ALIGN and adjust the P (primary) adjusting screw in FL4 for maximum indication on the volt-ohmmeter.

(12) Restore the adapter switch to DISC and trim the S screw setting for zero meter current. Adjust the signal generator 50 kilocycles above and 50 kilocycles below 2.65 megacycles and make sure that the readings of the volt-ohmmeter are approximately the same (but of opposite polarity).

(13) Vary the signal generator frequency above 2.65 megacycles until the test meter deflection is greatest. Note the meter reading and the generator frequency. The frequency should be between 2.725 and 2.745 megacycles.

(14) Repeat step (13) below 2.65 megacycles. The meter reading should be within 0.75 volt of the previous reading and the frequency should be between 2.560 and 2.580 megacycles.

(15) Place the switch of the adapter at CATH, with the signal generator set for 1.0-volt output at 2.65 megacycles and note the reading of the volt-ohmmeter for later use in testing the intermediate-frequency amplifier.

d. Alignment of I-f Amplifier.

(1) Reduce the signal generator output to zero and connect its shielded cord to the control grid of the modulator (terminal 4 of V2). Exposed unshielded wires are dangerous and should be kept as short as possible, preferably less than 2 inches, including the clip.

(2) Adjust the generator to a small output at 2.65 megacycles and adjust it for zero-beat with the intermediate-frequency oscillator when the TUNE-OPERATE switch is set at TUNE. Then restore the switch to OPERATE.

(3) With the switch of the adapter at CATH, increase the generator output sufficiently to cause a reading of 0.9 on the volt-ohmmeter. Adjust the generator output from time to time during the following alignment to maintain a meter reading of between 0.6 and 0.9 volt.




Fig. 56. Adapter FT-384-A: Schematic and Wiring Diagram

(4) Connect the 1000-ohm resistor between terminals 3 and 4 of filter unit FL3A and adjust the primary of FL3A designated P, for maximum voltmeter reading.

(5) Connect the resistor between terminals 1 and 2 of FL3A and tune the secondary of FL3A, designated S, for maximum voltmeter indication.

(6) Repeat steps (4) and (5) for filter units FL2A and FL1A, respectively. Upon completion of these adjustments, note the signal generator output required to obtain the same meter deflection as in Paragraph 37c(15). It should not be necessary to increase the signal generator output beyond 50 microvolts to obtain this reading.

(7) Vary the signal generator frequency through the 2.65-megacycle setting and note that the selectivity is approximately symmetrical about the mid-frequency.

(8) Adjust the generator frequency to 2.65 megacycles and the generator output as required for a meter current of 0.9 volt.

(9) Double the signal generator output voltage (6 db increase) and determine the frequencies above and below 2.65 megacycles at which 0.9 volt is obtained. The band width between the two "6 db down" frequencies should

be not less than 75 kilocycles and the mid-band frequency should be within 5 kilocycles of 2.65 megacycles.

(10) Repeat steps (8) and (9) for a 1000-fold voltage increase (60 db) of generator output. The band width between the two "60 db down" frequencies shall not exceed 350 kilocycles.

(11) Remove the strap between C25 and terminal 5 of V3.

e. Alignment of R-f Oscillator (LCU3A) and R-f Amplifier Circuits (LCU1A and LCU2A).

(1) Reduce the signal-generator output to zero and connect its shielded output cord directly to the A and G binding posts on the receiver, with short leads. (This will be a test through the whole receiver except the connections from the front A and G binding posts to the regular A and G terminals in the plug PG1. It may be wise, therefore, to test for continuity between these two sets of terminals.)

(2) Rotate the tuning dial to the stop at the 27-megacycle end of the scale. The reference line on the dial should be in approximate alignment with the tuning index. If the error is $\frac{1}{8}$ inch or more, repair the unit. This involves removing the front panel and adjusting the glass with the hairline on it. It should be done only if unavoidable.

(3) Adjust the dial and the signal generator to 39 megacycles.

(4) Loosen the cover plate (near C24) from C1.3, C1.5, and C1.7 and the cover plate of LCU3A.

(5) Turn the switch of Adapter FT-384(*) to DISC.

(6) Place the TUNE-OPERATE switch of the receiver at TUNE.

(7) Adjust the trimmer C1.7 for zero-beat in the loudspeaker. The (discriminator) voltmeter should read zero when the frequency is correct. This is an additional check on the frequency of the intermediate-frequency oscillator.

(8) Set the signal generator and the receiver

dial at 27 megacycles and adjust the slug in LCU3A for zero-beat.

(9) Repeat steps (7) and (8) until the oscillator tracks satisfactorily at both ends of the band.

(10) When the oscillator is satisfactory at both ends of the band, check the 36-, 33-, and 30-megacycle points also. Zero-beat should be obtained within one-half dial division at each of these frequencies. If tracking at these frequencies is not satisfactory repeat step (7) using 38 megacycles and step (8) using 28 megacycles. After the dial tracking is regarded as satisfactory, take care to avoid touching C1.7 and the slug of LCU3A, when making further adjustments.

(11) Turn the switch of Adapter FT-384(*) to CATHODE and restore the TUNE-OPERATE switch to OPERATE.

(12) Increase the signal generator output sufficiently to cause a meter reading of 0.9 volt. Adjust the generator during the course of the following procedure to maintain a reading of between 0.6 and 0.9 volt on the meter.

Note: During the final alignment adjustments it is usually impossible to keep the meter deflection below 0.9 volt by reducing generator output. Under these conditions modulate the generator with 400 cycles and a frequency swing of ± 15 kilocycles. Connect the output meter of Test Set I-56(*) to Adapter FT-384(*), and supplement the test meter deflection by observing the output meter deflection.

(13) With the signal generator at 39 megacycles, tune the receiver dial for zero-beat at 39 megacycles. Adjust, in turn, trimmer capacitors C1.5, C1.3, and C1.1 for maximum test meter deflection.

(14) Adjust the generator and the receiver to 27 megacycles as in step (13).

(15) Adjust, in turn, the slugs in the LCU1A and LCU2A shield cans for maximum deflection of the meter.

(16) Readjust the trimmer capacitors at 39 megacycles and the inductance trimmers at 27 megacycles alternately until no further improvement can be obtained.

f. Check of Sensitivity and Stability.

(1) Set the signal generator to 39 megacycles and adjust the receiver to zero-beat at 39 megacycles. Then reduce the signal generator to zero output.

(2) Switch the SQUELCH control to ON and adjust the SENSITIVITY control so that the CALL SIGNAL lamp is barely extinguished.

(3) Increase the generator output sufficiently to illuminate the CALL SIGNAL lamp. A signal of 1.0 microvolt or less should suffice.

(4) Repeat steps (2) and (3) at 27 megacycles.

(5) Set the signal generator to give 3 microvolts output at 39 megacycles. It should be possible to extinguish the CALL SIGNAL lamp by turning the SENSITIVITY control to the left. Repeat this test at 27 megacycles.

(6) Throw the TUNE-OPERATE switch to TUNE and adjust the tuning dial for a low-pitched beat note.

(7) Vary the signal-generator output from about 1.0 to 1000 microvolts. The pitch of the beat note should remain within audibility over the entire range of signal voltage.

g. Output Power Measurement.

(1) Adjust the signal-generator frequency to 27 megacycles and 1.0-microvolt output.

(2) With the SPEAKER switch at ON, and the TUNE-OPERATE switch at TUNE, set the OUTPUT TO PHONES switch to ON, and the SQUELCH switch to ON. Turn the SENSITIVITY and VOLUME controls to the extreme right.

(3) Tune to zero beat with the signal generator and operate the TUNE-OPERATE switch to OPERATE. Turn the SPEAKER switch to OFF.

(4) Modulate the signal generator with 400 cycles with a frequency deviation of 15 kilocycles and read the output meter. The meter should read over 18 volts.

b. Noise Test. With the signal-generator output at 1.0 microvolt, remove the modulation

from the signal. The output meter should not read more than one fifth of the reading obtained in Paragraph 37g(5).

i. Check of Limiter Action.

(1) With conditions as in Paragraph 37g, increase the signal-generator output to 10 microvolts and observe the reading of the output meter.

(2) Increase the signal-generator output to 100, 1000, and 10,000 microvolts successively. The voltmeter reading should stay within ± 5 volts of the reading obtained in (1).

j. Volume Control. Remodulate the signal with 400 cycles with a frequency deviation of 15 kilocycles and 1.0-microvolt input, and gradually rotate the VOLUME control to the left. The output meter should decrease progressively to less than 1.0 volt. After restoring the volume to maximum, turn the SPEAKER switch to ON. The output meter reading should remain approximately constant. Observe the tone from the loudspeaker as a check on its operation. A very weak response or a bad rattle may indicate that the speaker cone has been damaged.

38. Precision Alignment of Radio Transmitter BC-684-A.

a. General. Whenever a complete inspection of a transmitter is made, check alignment of the tuned circuits as follows:

b. Testing Equipment Required.

1—Antenna A-83 (phantom), or an artificial antenna (Fig. 77), or, if radiation is permissible, a vehicle antenna of correct dimensions (including lead-in and ground).

1—Sensitive precision wavemeter, 4- to 20-megacycle range.

1—Narrow-blade ($\frac{1}{8}$ -inch) screwdriver or long-handled hexagon socket wrench for adjusting the trimmer capacitors and coil slugs.

1— $\frac{3}{8}$ -inch screwdriver for locking the selector, etc.

1—6-inch rule (narrow blade).

1—Cord CD-786 for connection of the transmitter under test to the power supply through a convenient mounting or equivalent.

c. Preliminary to Alignment.

(1) Throw the TRANSMITTER switch to OFF, the RECEIVER TUNE-OPERATE switch to OPERATE, and the TUNE-ANT CUR switch to TUNE.

(2) Insert Crystal Holder FT-241-A, Channel 270, into socket no. 1 and Crystal Holder FT-241-A, Channel 389, into socket no. 10 in the crystal operating compartment. If these particular crystals are unavailable, others within five channels of these may be used.

(3) Remove the top and bottom cover plates from the transmitter and lay the transmitter on its back so the bottom and top sections are accessible. Plug one end of Cord CD-786 into the left end of the transmitter and the other end into the left connector of the mounting which is connected to a large 12- or 24-volt battery supply. Make sure a dynamotor of the correct input voltage rating has been inserted in the transmitter.

(4) Unlock the channel selector (see Paragraph 21a) and then set the gang capacitor for minimum capacitance (plates all out).

d. Alignment of First R-f Amplifier.

(1) Set the METER SWITCH to position 2 (grid current in the first radio-frequency amplifier) and turn the TRANSMITTER switch to ON.

(2) Set C107 to the minimum capacitance position (open end of slot at left as viewed from front of the transmitter).

Note: Capacitor C107 has been omitted from later transmitters.

(3) Press push button no. 10 and start the dynamotor by placing the RECEIVER TUNE-OPERATE switch on RECEIVER TUNE. If the oscillator and metering circuit are working, the meter will deflect, indicating current in the first radio-frequency amplifier grid circuit. Stop the dynamotor by throwing the RECEIVER TUNE-OPERATE switch to OPERATE. Do not let the dynamotor run for long periods of time during the following tests.

(4) Set the METER SWITCH to position 3 (grid current in rectifier).

(5) Start the dynamotor (RECEIVER TUNE-OPERATE switch to RECEIVER TUNE). Adjust the gang capacitor for maximum meter deflection and observe the relative position of the capacitor plates. Rotate the gang capacitor by inserting a screwdriver in the slot on the end of the gang capacitor shaft (located near the handle on the right end of the transmitter) or by the associated small knob.

(6) Press push button no. 1 and repeat step (5). The observed rotation of the gang capacitor in passing from no. 10 to no. 1 should be at least 75 per cent of the total possible rotation.

(7) Carefully release push button no. 1, turn the gang capacitor to the extreme right, and lock the selector unit.

(8) Start the transmitter (dynamotor). Check the selector adjustment by pressing the no. 1 and then the no. 10 push button. Observe the maximum meter deflection at each frequency as the gang capacitor is varied slightly against the restoring force of the selector springs. *Do not attempt to rotate the capacitor control more than a few degrees.* The meter should indicate a maximum deflection at the capacitor setting determined by the selector. If the gang capacitor has not been properly positioned at each frequency, repeat the procedure, Paragraphs (5) through (8), until the proper adjustment is obtained or the trouble is located.

e. Alignment of Rectifier.

(1) Set the METER SWITCH to position 4 (grid current in tripler).

(2) Adjust the tuning slugs in L119 and L118 to about $\frac{3}{4}$ inch from the open end of the coils. This may be measured with the 6-inch narrow blade rule inserted in the open end of the coil form.

(3) Set C153 and C157 to the mid-capacitance position (open end of slot toward rear of set).

Note: Steps *e*(2) and *e*(3) are unnecessary if there is reason to believe that there has been no major change in the coils or capacitors in this stage.

(4) Adjust the wavemeter to one sixth of the output frequency ($38.9/6 = 6.48$ megacycles) and place the pickup coil near L118 and L119.

Caution: The wavemeter may affect the tuning of L118 and L119 if it is coupled too closely to these coils.

(5) Press push button no. 10, start the dynamotor, and adjust C153 and C157 for a maximum deflection of the transmitter panel meter at the wavemeter frequency. *Take care that the circuits are being tuned to the correct frequency.* Wavemeter resonance is indicated by a dip in panel meter reading. If the circuits cannot be tuned, try a different setting of the L119 and L118 tuning slugs. Repeat this procedure until a panel meter deflection is obtained, and with the wavemeter determine the frequency to which the circuits are tuned. If the tuned frequency is higher than the correct frequency, increase the tuning inductance or capacity, or both; if the tuned frequency is lower than the correct frequency, decrease the tuning inductance or capacity, or both, until the correct frequency is obtained. The transmitter employs copper tuning slugs in the coils and, therefore, the coil inductance is decreased as the slug is inserted farther into the coil winding.

(6) Press push button no. 1 and adjust the slugs in L119 and L118, respectively, for maximum deflection of the panel meter. Do not adjust C153 and C157. Check the frequency being tuned ($27.0/6 = 4.50$ megacycles) with the wavemeter and proceed as in step (5) if the frequency is incorrect.

(7) Repeat step (5) (adjusting only the capacitance trimmers on button 10) and step (6) (adjusting only the coil slugs on button 1) until no further adjustment is required. In some cases where the circuits do not appear to align

properly at both ends of the band it may be desirable (with the METER SWITCH in position 3) to adjust and lock selector button 3 at some frequency near the middle of the band (say 33 megacycles) and align between buttons 10 and 5 to get the coil slugs and capacitors near their correct positions. Then finally align between buttons 10 and 1 as described.

j. Alignment of Tripler.

(1) Set the METER SWITCH to position 1 (grid current in doubler).

(2) Adjust the tuning slugs in L106 and L107 to about $\frac{3}{4}$ inch from the open end of the coils.

(3) Set C114 and C116 to the mid-capacitance position (open end of slot toward rear of set).

Note: Steps *f*(2) and *f*(3) are unnecessary if there has been no major change in the coils or capacitors in this stage.

(4) Adjust the wavemeter to one half of the output frequency ($38.9/2 = 19.45$ megacycles) and place the pickup coil near L106 and L107.

(5) Press push button no. 10, start the dynamotor, and adjust C114 and C116 for a maximum deflection of the panel meter at the wavemeter frequency. *Take care that the circuits are being tuned to 19.45 megacycles.* If the circuits cannot be tuned to the proper frequency, try a different setting of the L106 and L107 tuning slugs.

(6) Depress push button no. 1 and adjust the slugs in L106 and L107 for maximum deflection of the meter. Check the frequency being tuned ($27.0/2 = 13.5$ megacycles) with the wavemeter. If the frequency is incorrect, it will be necessary to recheck the frequencies to which the rectifier stage has been aligned in accordance with Paragraphs 38e(4) and 38e(6).

(7) Repeat step (5) (adjusting only the capacitance trimmers on button 10) and step (6) (adjusting only the coil slugs on button 1) until no further adjustment is required.

g. Alignment of Doubler.

(1) Set the METER SWITCH to position 5 (grid current in power amplifier).

(2) Adjust the tuning slug in L108 to about $\frac{3}{4}$ inch from the open end of the coil.

Note: This step is unnecessary if there has been no major change in the coil or capacitor in this stage.

(3) Press push button no. 10, start the dynamotor, and adjust C120 for a maximum deflection of the meter. If a tuning point cannot be found, try a different setting of the L108 tuning slug. Frequency measurements are not required in this stage if the alignment of the preceding circuits has been done correctly.

(4) Press push button no. 1 and adjust the slug in L108 for a maximum meter deflection.

(5) Repeat step (3) (adjusting only C120 on button 10), and step (4) (adjusting only L108 on button 1), until no further adjustment is required.

(6) Replace the bottom cover plate of the transmitter and trim all alignment adjustments previously made, by repeating the procedure described in Paragraphs 38*d*, *e*, *f*, and *g*. The bottom cover makes only small changes in the circuit capacitances or inductances and so only small changes in the trimmer capacitors or coil slugs will be required. They are necessary, however, if most satisfactory performance and tube life are to be obtained.

h. Alignment of Power Amplifier.

(1) Set the METER SWITCH to position 6 (total plate current).

(2) Throw the RECEIVER TUNE-OPERATE switch to OPERATE.

(3) Adjust the coupling of L111 to L110 until the center of coil L111 is opposite the top of coil L110 as seen through the vertical slot in L110. This may be accomplished by rotation of the knurled finger wheel accessible through a rectangular hole in the right end panel. (See Fig. 52.)

(4) Connect an antenna (artificial or real; see Paragraph 38*b*) to the transmitter. (During manufacture this stage is adjusted with the artificial antenna (Fig. 77) plugged into the A and G posts on the front panel of the transmitter.)

(5) Press push button no. 10, plug in a microphone, and start the dynamotor by operating the microphone switch. Immediately adjust C126 on top of the selector unit for minimum deflection of the panel meter (minimum plate current).

(6) Adjust antenna trimmer capacitor C136 (marked as no. 10 on the right-end panel of the transmitter) for maximum antenna current in the artificial antenna meter.

Note: If an Antenna A-83 (phantom) or a real antenna is used for these coupling adjustments it will be necessary, in order to have an indication of antenna current, to throw the TUNE-ANT CUR switch to ANT CUR and observe the deflection of the panel meter. Restore the TUNE-ANT CUR switch to the TUNE position whenever adjustments are to be made to capacitor C126 or to the inductance trimmer of L110.

(7) Adjust the coupling between L110 and L111 for maximum antenna current, then reduce the coupling to lower the antenna current to approximately 60 per cent of maximum and readjust the antenna capacitor, C136, for maximum antenna current.

(8) Press selector button no. 1 and adjust the tuning slug (inductance trimmer) of L110 for minimum plate current (with the TUNE-ANT CUR switch at TUNE). The tuning slug is operated by a toothed wheel which is turned by inserting a screwdriver through the hole opposite the bottom of L110 in the right-end panel of the transmitter.

(9) Adjust the antenna trimmer, C127 (no. 1), for maximum antenna current.

(10) Shift alternately between selector buttons no. 1 and no. 10, making the proper adjustment of L110 and C126 for minimum plate current until no further adjustment of L110 and

C126 is required. When on button no. 1, adjust the tuning slug L110 for *minimum* plate current, and adjust the antenna trimmer, C127, for *maximum* antenna current. When on button no. 10, adjust the trimmer capacitor, C126, for *minimum* plate current and adjust the antenna trimmer, C136, for *maximum* antenna current.

As the minimum meter reading may not be sharply defined when the inductance trimmer is turned, it is sometimes easier to adjust the capacity trimmer C126 for *minimum* plate current when on selector button no. 10, then operate selector button no. 1, and again adjust C126 for *minimum* plate current. Then adjust the inductance trimmer by a few turns and repeat the procedure already outlined, noting the position of C126 for each selector button. Turn the inductance trimmer of L110 one way or the other until the position of C126 for *minimum* plate current is the same at both ends of the band (selector buttons 1 and 10).

The radio-frequency stages have now been ganged and should track satisfactorily at all frequencies.

i. Coupling to the Antenna Circuit. When the procedure in Paragraph 38*b* has been properly accomplished, the transmitter is ready for coupling to a suitable antenna. The method of making coupling adjustments is described in Paragraph 21*a*.

39. Location of Trouble in Radio Receiver BC-683-A.

a. General. The following tests aid in isolating the source of trouble. *To be effective the procedure should be followed in the order given here.* A faulty receiver will be referred to hereafter as the "trouble" receiver.

Refer to the following figures to aid in the locating of trouble in the receiver:

Figs. 44-46. Apparatus Location Diagrams.

Fig. 51. Location of Alignment and Tuning Controls.

Fig. 57. Voltage Diagram.

Fig. 58. Resistance Diagram.

Figs. 43, 72. Wiring Diagrams.

Remember first, servicing procedure should cause no further injury to the receiver. Second, trouble should be localized to a single stage or circuit. Third, the trouble may then be isolated within that stage or circuit by appropriate voltage, resistance, and continuity measurements. The relationship of the various steps of this suggested procedure to these considerations, graphically illustrated in Charts 2 and 3 at the end of Paragraph 39, may be summarized as follows:

The purpose of inspection is to locate any visible trouble. Through this inspection alone, you may frequently discover the trouble, or determine the stage in which the trouble exists. This inspection is valuable in avoiding additional damage to the receiver which might occur through improper servicing methods, and in forestalling future failures.

The power supply test prevents further damage to the receiver or the dynamotor from certain possible short circuits. Since this test gives an indication of the operation of the dynamotor and filter circuits, its function is not merely preventive.

The operational test is important as it frequently indicates the general location of the trouble. In many instances the information gained will determine the exact nature of the fault. To utilize this information fully, interpret all symptoms in relation to each other.

The principal advantage of the signal tracing method is that it usually enables you to localize a trouble accurately and quickly to a given stage when the general location of this trouble is not immediately evident from the above tests.

In all these tests the possibility of intermitents should not be overlooked. If present, this type of trouble may be made to appear in most cases by tapping or jarring the set. It is possible that no trouble will be found in the receiver itself but that the trouble is in the installation (mounting, interphone system, or vehicle), or, possibly, is due to external conditions. In this event, test the installation, if possible.

b. General Precautions. Whenever a receiver is to be serviced, observe the following general precautions very carefully.

(1) With the cover removed, dangerous voltages are exposed when the set is operating.

(2) Whenever a receiver is suspected of being in trouble, make the inspection and power supply test. Be sure to remedy the cause of any abnormal heating before continuing the procedure.

(3) Don't allow the dynamotor to run for any appreciable period of time at the start of the inspection until you are sure there are no short circuits which will cause burning of receiver parts.

(4) When making resistance and continuity measurements, first remove the power plug and dynamotor.

(5) Don't remove the shield can of the tuned units (LCU or FL) from any unit unless you definitely know that trouble exists within that unit. Whenever one part of the tuned circuit is replaced, realign the unit.

(6) Whenever you suspect intermittent trouble, make a thorough check of wiring and parts. In many cases you can make intermittent troubles appear by jarring the receiver.

(7) Take care, when inspecting wiring and soldered connections, not to damage the insulation. Don't leave the insulation in a broken or frayed condition. Don't pull or bend wires unnecessarily, nor pry cable open to trace wiring.

(8) Don't remove more than one vacuum tube from a receiver at one time. Remember to return each tube to the socket from which it was removed, unless it is defective.

c. Inspection. When a receiver is brought in from the field for check or repair, remove the cover and make the following inspection.

(1) Examine for burnt insulation and resistances. Examine for wax leakage and any discoloration of apparatus and wire. Notice any odor caused by overheated apparatus.

Note: These symptoms may have been caused by a trouble previously repaired and serve only as a guide. In general, confine examination to

parts readily visible with the cover removed. Usually more harm than good will be caused by the removal of the front panel, the FL or LCU can covers, and other enclosed parts. Trouble in these parts should be localized by signal tracing and voltage and resistance measurements.

(2) Inspect for broken connections to tube sockets, plugs, and other apparatus as well as for defective soldered connections. Examine for bare wires touching the chassis or other wires.

(3) Be sure that the labels on the tubes in the various sockets correspond to the correct tube numbers given in the technical manual for these positions. Replace any tubes which have the wrong numbers. Inspect for loose tube sockets.

(4) Inspect the active and spare fuses. Check carefully for short circuits whenever a receiver with a blown fuse is encountered.

(5) Inspect the selector mechanism for loose or bent parts. Be sure that the dial turns smoothly and that the push buttons operate satisfactorily.

(6) Inspect the power plug and replace or repair it if there are any bent or broken prongs.

(7) Inspect for loose or missing screws, especially those which fasten the tube sockets in place.

d. Power Supply Test. This test assumes that a voltmeter of at least 1000-ohms-per-volt with a range of at least 250 volts, and an ohmmeter, are available.

Throw all switches to OFF, or downward. Remove the cover from the receiver for the following procedure.

(1) The dynamotor marking must agree with the battery voltage available.

(2) Remove the dynamotor and examine it for loose or badly worn brushes and worn or dirty commutators. Test the continuity of the dynamotor plug. Clean and replace the dynamotor in the set.

(3) Connect the appropriate battery to the

receiver, using Mounting FT-237-(*) or Cord CD-786.

(4) Throw the **SPEAKER** switch to **ON**.

(5) Place the voltmeter across C25 (the positive side should go to the terminal to which the wire with the red tracer is attached). Turn the power switch to **ON**. Note that the meter rises immediately to approximately 200 volts when the switch is turned on. If it does not, turn the set off quickly and check C25 and C16 for a possible short circuit. Also, check the voltage divider, the dynamotor, and the associated equipment. A low reading of the voltmeter may indicate a faulty dynamotor or a short circuit in the system.

(6) If the dynamotor fails to start or if the fuse blows, turn the set off, and inspect the dynamotor and the associated equipment, as well as the fuse, plug PG2, the filament wiring, etc.

(7) Assuming that the dynamotor starts correctly and that the voltage is satisfactory, inspect the inside of the receiver with the dynamotor running. See that no sparks occur and that nothing smokes. Stop the dynamotor immediately and repair the fault if trouble is indicated.

(8) After the dynamotor has been running for a few moments, feel the tubes cautiously to see if they are all warm. No other tube should be as hot as V8, which is a VT-107-A (6V6-GT) tube. No tube should remain cold. If a tube remains cold after the others have warmed up, examine the wiring associated with the tube socket in question and examine the socket contacts. If there is no wiring trouble and the tube does not warm up, test it (or replace it if no vacuum-tube test set is available).

e. Vacuum Tube Testing Procedure. As the space around a vacuum tube is often small it is desirable either to use a tube extractor or to rock the tube with the fingers at the top while pushing it up gently from the bottom. To test a vacuum tube, use a test set if available. If not, try the tube in a receiver which is operating satisfactorily. If another receiver is not available, try replacing the tube by another one.

f. Operational Test. To make an operational test, you will need a headset and a weak signal between 27 and 39 megacycles. A signal generator, or a transmitter with its **RECEIVER TUNE-OPERATE** switch at **RECEIVER TUNE**, is a good signal source. The transmitter requires no metallic connection with the receiver. A second receiver with a lead to bring the radio frequency to the **A** (antenna) post of the receiver under test is satisfactory. See Paragraph 39g(6) (c).

Serious distortion and abnormally low output are trouble indications. Compare with a good receiver for output, if the condition of the trouble receiver permits. Irregularities of operation help to localize the trouble. Operating personnel may supply useful supplementary data.

(1) Turn the trouble receiver to **ON** and allow it sufficient time to warm up. All other switches should be at **OFF** (down).

(2) **CALL SIGNAL Lamp.** With the **SQUELCH** switch at **OFF**, the **CALL SIGNAL** lamp should be lighted.

(3) **Noise from Loudspeaker.** Turn the **SPEAKER** switch to **ON**, and with the **VOLUME** control turned to the extreme right, listen for a rushing noise from the loudspeaker.

(4) **VOLUME Control.** The speaker output should vary smoothly from maximum until the noise has vanished at the extreme left position of the control.

(5) **Headset Sidetone.** With the **OUTPUT TO PHONES** switch at **OFF**, plug the headset into one of the **PHONES** jacks. There should be no sound in the headset.

(6) **Noise in Headset.** With the **VOLUME** control adjusted for normal output from the speaker, turn the **OUTPUT TO PHONES** switch to **ON**. There should be a rushing noise in the headset.

(7) **Noise in Headset, Second Jack.** Repeat step (6) for the second **PHONES** jack.

(8) **Headset Volume.** Turn the **SPEAKER** switch on and off. The headset volume should remain constant if R30 is intact.

(9) Turn on a source of radio-frequency signal and wait for it to warm up.

(10) *Beat-Note Indication.* Now place the TUNE-OPERATE switch at TUNE. Roughly check the tuning of the receiver, both manual and push-button, against the radio-frequency test signal, using the beat note produced by the intermediate-frequency oscillator as a tuning indication. The dial should turn freely.

(11) *Beat-Note Indication, with Squelch.* With the SQUELCH switch at ON and the SENSITIVITY control adjusted for maximum sensitivity (full right rotation), repeat the beat-note test at one frequency.

(12) *Squelch Operation.* With conditions as in (11), the CALL SIGNAL lamp should light when the signal is tuned in. If it does not go out when the signal is tuned out, turn the SENSITIVITY control to the left to reduce the sensitivity until it does. The noise from the loudspeaker should cease whenever the CALL SIGNAL lamp is extinguished. When the signal is tuned in again the lamp should light.

(13) *Sensitivity Control.* Reduce the signal, with conditions as in (12), just short of the frequency where the CALL SIGNAL lamp would go out. Turn the SENSITIVITY control to the left and the lamp should go out.

(14) *Intermittents.* Test the receiver for intermittents by jarring it while listening to a beat note.

(15) *Tests Involving Transmitter and Receiver.* If the tests are being made in a mounting with a transmitter as a source of radio frequency, the following checks may be made quickly:

(a) *Disabling Action.*—Turn the transmitter RECEIVER TUNE-OPERATE switch to OPERATE. Pressing the microphone button should cut off the rushing noise in the receiver.

(b) *Sidetone.*—Plug into either PHONE jack and set the SIDETONE control on the right end of the transmitter (Fig. 14) to give sufficient headset volume. Sidetone should be heard when someone is speaking into the microphone.

g. Signal Tracing.

(1) *General.* Signal tracing tests require one of the following signal sources, listed in order of preference:

A signal generator.

A good receiver. (See (6) of this paragraph for instructions.)

A good transmitter (provides audio and radio frequencies only). (See (7) of this paragraph for instructions.)

Caution: When connecting or disconnecting these sources, turn the receiver off each time to avoid shock or equipment damage.

You will also need a voltmeter (not less than 1000-ohms-per-volt), an ohmmeter, and a headset. If no vacuum-tube test set is available, check the tubes in a good receiver, or substitute new tubes. (See Paragraph 39e.) This recommended procedure begins at the output and works back. For the location of parts, see Figs. 43, 45, 46, 51, and 72. An output meter plugged into one of the PHONES jacks, as described in Paragraph 33c(3), or an alignment meter bridged across L1 as described in Paragraph 33e(1), helps greatly in judging the performance of the receiver. If a signal generator having a 1.0-volt output at 2.65 megacycles is used, test the discriminator circuits, as described in step (3)(i), as soon as step (3)(b) is completed. In this event, apply the signal generator output to the grid of the limiter (terminal 4 of V6). In all other cases, make this test in the following order:

(a) At the beginning of the test, turn all switches to OFF (downward), and release all push buttons.

(b) *Don't remove the shield can of a tuned unit until the trouble has been traced to that particular unit. Don't remove the front panel of the receiver more often than necessary. Don't damage the wiring by pushing it back and forth during inspection. Do as little damage to the receiver as possible. Take it easy.*

(c) Use a dynamotor known to be in good condition, and of correct voltage, and place it in the set before the test.

(d) Except as otherwise noted, ground

one side of the signal generator and connect the other side to the receiver being tested.

(e) Note the volume, and listen for serious distortion from the loudspeaker at the various points in the signal tracing procedure. Experience helps. If possible, compare with a receiver known to be in good condition.

(f) Check the wiring and soldering in each stage as you proceed.

(g) Misalignment of one or more stages of the receiver will cause reduced output. Misalignment of the radio-frequency oscillator may, however, prevent any output.

(h) In this outline, "no signal" or "no beat note" means either no signal from the loudspeaker, a signal that is weaker than it should be, or a seriously distorted signal.

(i) When trouble is localized in a given stage, first test the tube if such a test is indicated in the procedure, then the voltage, and finally the resistance (Paragraph 39b(4)), at the tube socket of that stage.

(j) Trouble in a circuit or stage may not show in voltage and resistance measurements at the tube socket. Hints included in this section are merely a guide and should suggest other procedures, such as voltage and resistance measurements on individual parts.

(k) Remove only *one tube* at a time when testing. Check the number of the tube, test it, and return it to its proper socket before another tube is removed.

(l) If the receiver appears to be good, test the control circuits of the associated transmitter for short or open circuits. Check the wiring in Mounting FT-237-(*), as well as the remote circuit wiring.

(m) It frequently helps to connect (with a clip lead) terminal 5 of V3 to the negative side of C25 (to which blue-tracer leads are attached) when performing the audio- and intermediate-frequency tests outlined in Paragraphs 39g(2) and (3). This stops the radio-frequency oscillator and reduces interference. *Be sure to remove this clip lead before proceeding with the radio-frequency tests.*

(n) Each step assumes you have satis-

factorily completed all previous steps. Isolate and clear any trouble located before you proceed with the next step.

(o) When you have found all sources of trouble, follow the procedure for routine check of the receiver as described in Paragraph 30.

(2) *A-f Tests.* For reference to audio-frequency-test signal sources, see Paragraph 39g(1).

(a) Secondary of T1 (Speaker Circuit).—Throw the SPEAKER switch to ON and connect an audio signal through a series capacitor to the blue-brown tracer (fifth terminal counting from the front panel) on the output transformer T1. Listen for noise output in the speaker. Notice that it is not necessary to remove the front panel in order to gain access to the terminals of transformer T1.

The volume of noise will be *very low*.

If no output is heard, check the circuit elements such as the SPEAKER switch D3, the output transformer, the loudspeaker, etc.

Note: In replacing the front panel (if it has been removed) be sure that the wires are all pushed down beside the potentiometers P1 and P2 and preferably tied in place.

(b) Secondary of T1 (Phones Circuit).—Throw the OUTPUT TO PHONES switch to ON and connect the signal to the blue-green tracer on the output transformer T1 (third terminal counting from the front panel). Try the headset in both PHONES jacks. Noise should be heard when the headset is plugged into either jack. If no signal is heard, remove the front panel and test (by resistance measurements if possible) such items as resistors R22, R23, and R33, switch D2, the jacks, and terminals 12 and 14 of PG3 and J3. Jacks and headsets may be at fault, or a permanent ground may exist on the receiver disabling lead.

(c) Primary Circuit of T1.—Place the audio signal on the blue-yellow tracer (second terminal counting from the front panel) on the output transformer T1 and listen for the signal from the speaker or headset. If no signal is present, C33 may be shorted or terminals 16 and 17 of plug PG3 may not be making good contact.

(d) Terminal 5 of V8 (Grid of Second Audio Amplifier).—Turn the receiver on. Put the signal on terminal 5 of V8. Listen for output in the speaker. If there is no output, test the tube and the voltages at the socket terminals (see Figs. 57 and 58). C21, R19, or R18 may be faulty. Check continuity to terminals 5, 6, and 10 of PG3 or J3:

(e) Terminal 2 of V10 (Plate of First Audio Amplifier).—Introduce the signal at terminal 2 of V10, and listen for a signal from the loudspeaker. If there is no signal, R18, C19, or C21 may be at fault. Check terminals 5, 6, and 10 of PG3 or J3 for continuity.

(f) Terminal 1 of V10 (Grid of First Audio Amplifier).—Put the signal on terminal 1 of V10. Reduce the signal input. If there is no signal from the loudspeaker, test the tube. Circuit elements such as C11, C12, C13, C26, or R10 may be faulty. Note that when the SQUELCH switch is at OFF it should connect ground to R12—the side away from the tube.

(g) Terminal 5 of V10 (Plate of the I-f Oscillator).—Place the signal on terminal 5 of V10. Throw the TUNE-OPERATE switch to OPERATE. If there is no signal from the loudspeaker, R6, C26, C10, or D5 may be faulty.

(h) Junction of C11 and R10.—Put the signal at the junction of C11 and R10. If the signal is not heard from the speaker, R10 or C11 may be faulty.

(i) Terminal 4 of V7 (Output of the Discriminator).—Place the signal across the output resistance (R81 in series with R83) of the discriminator (terminal 4 of V7). If there is no signal in the loudspeaker, check circuit elements such as V7, C81, C82, R81, R82, R83, or R84.

(3) *I-f Tests.* For reference to intermediate-frequency-test signal sources, see Paragraph 39g (1).

(a) Terminal 8 of V6 (Plate of the Limiter).—With the intermediate-frequency signal applied through a series capacitor to the plate of the limiter (terminal 8 of V6), place the SQUELCH switch at OFF and the TUNE-OPERATE switch at TUNE and listen for a beat note from the loudspeaker. If this beat note is not heard,

note the setting and then vary the slug adjustment in LCU4 to obtain a beat note. If the beat note cannot be obtained, such circuit elements as C10, LCU4, FL4, or D5 may be faulty. Remove the slug in LCU4 for a beat note with the intermediate-frequency source after the trouble has been cleared.

(b) Terminal 4 of V6 (Grid of the Limiter).—Put the signal on terminal 4 of V6. If there is no beat note from the speaker, with the TUNE-OPERATE switch at TUNE, test V6 and other circuit elements. Voltage and resistance measurements at the tube socket terminals may be useful. (See Figs. 57 and 58.)

(c) Terminal 8 of V5 (Plate of the Second I-f Amplifier).—With the signal on terminal 8 of V5 repeat the procedure given for the preceding stage. If there is no signal, FL3A may be misaligned or faulty. If the alignment is not at fault, test such elements as V5, R13, C14, C15 or C7. If the alignment has been altered, re-align FL3A after the trouble has been corrected.

(d) Terminal 4 of V5 (Grid of the Second I-f Amplifier).—Place the signal on terminal 4 of V5. Repeat the procedure which was followed on the limiter stage. If the test of the tube is satisfactory, there may be trouble in circuit elements such as FL2A, C7, or R8.

(e) Terminal 8 of V4 (Plate of the First I-f Amplifier).—Feed the signal to terminal 8 of V4. If no beat note is obtained from the speaker, test the tube. FL2A may be misaligned or may be faulty.

(f) Terminal 4 of V4 (Grid of the First I-f Amplifier).—Introduce a signal on terminal 4 of V4. If no beat note is obtained and the tube is satisfactory, the trouble may be in FL1A, C6, or associated circuit elements.

(g) Terminal 8 of V2 (Plate of the Modulator).—With the signal on terminal 8 of V2, listen for a beat note from the loudspeaker. If none is obtained, test the tube and make voltage and resistance measurements. (See Figs. 57 and 58.) FL1A may be misaligned or faulty. Check the associated circuit elements.

(h) Terminal 4 of V2 (Grid of the Modulator).—Place the signal on terminal 4 of V2.

If a beat note is not obtained, test the tube. The trouble may be in LCU2A. Check for a short circuit of C1.5 or C1.6.

(i) Terminal 4 of V2 (Discriminator Test).—With the intermediate-frequency signal still on the grid of the modulator (terminal 4 of V2), measure the voltage across the series combination of R81 and R83 (between terminals 4 and 8 of V7, or between 3 and 7 of FL4). Turn off the intermediate-frequency oscillator by setting the TUNE-OPERATE switch at OPERATE. Align the secondary of FL4 to obtain a zero reading on the voltmeter. As the alignment is varied either way from this point, the reading of the voltmeter should change polarity. In order to test the primary of FL4, connect the meter between terminals 3 and 8 of FL4. Adjust the primary slug of FL4 for maximum reading on the voltmeter. This is not an alignment but merely a check on the alignment capability of this circuit. Leave the circuit in approximate alignment after clearing any trouble that may have been present in FL4 or associated circuits.

(4) *R-f Tests.* For reference to radio-frequency-test signal sources, see Paragraph 39g (1).

(a) Terminal 4 of V2 (Grid of the Modulator).—Apply a radio-frequency signal through a capacitor to the grid of the modulator (terminal 4 of V2). Set the TUNE-OPERATE switch to TUNE. Manually set the dial of the trouble receiver to approximately the frequency of the radio-frequency source and tune for a beat note. If it is impossible to obtain a beat note, either the source of radio frequency is not providing voltage on the grid of V2 or the radio-frequency oscillator of the trouble receiver is not functioning. In the latter case check V3, LCU3A, R4, R5, C5, and associated circuit elements. C1.7 and C1.8 may be shorted. Make resistance and voltage measurements at the tube socket terminals. (See Figs. 57 and 58.) In order to isolate the trouble in the oscillator stage, put the radio-frequency signal on the suppressor grid of the modulator (terminal 3 of V2). If the characteristic no-signal rushing noise is heard from the loudspeaker with the test signal but is

not heard when the test signal is absent, then the oscillator stage is faulty. However, if the oscillator stage is operating but not properly aligned, the rushing noise may be present, but a weak beat note may appear more than one channel away from the proper setting. A realignment of the oscillator is indicated.

Caution: Any attempt to vary the adjustment of the slug in LCU3A will result in a change in the tracking of the oscillator stage. This stage probably will then require careful alignment. This procedure is described in Paragraphs 34b(5) and 37e. No adjustment of LCU3A and C1.7 should be attempted until the method is fully understood.

(b) Terminal 8 of V1 (Plate of the R-f Amplifier).—Place the signal on terminal 8 of V1. If no beat note is heard in the speaker, test V1. It may be that LCU2A, C1.3, or C1.4 are shorted. Make voltage and resistance measurements.

(c) Terminal 4 of V1 (Grid of the R-f Amplifier).—Place the signal on terminal 4 of V1 and listen for the beat note. If no beat note can be obtained and the tube is not at fault, check LCU1A, C1.1, and C1.2 for short circuits. LCU2A may be misaligned.

(d) Antenna Post.—Put the signal on the A (antenna) post. If there is no beat note, LCU1A may be misaligned or faulty. Test the antenna connections to LCU1A.

(e) Squelch Circuit and Sensitivity Control.—Check these functions as described in Paragraphs f(12) and f(13) preceding. If operation of the squelch circuit and sensitivity control is not normal, test V9. Circuit elements such as R15, R16, R17, C17, C18, C20.2, or C12 may be faulty.

Note: The voltage divider circuits bear an important relation to proper squelch action. See Figs. 57 and 58.

(f) Tuning.—When all troubles have been removed, the tuning for all channels should be checked. If an LCU or an FL unit has been repaired or replaced or if its adjustment has been changed, that unit should be realigned. If several

units have been changed or there is any question of alignment, the whole receiver should be realigned.

(5) *Short Cuts.* Signal tracing procedure may be simplified by determining at the outset, whether the trouble is in the audio-, intermediate-, or radio-frequency circuits. This may be determined in the following order:

(a) *A-f Circuits.*—Put an audio-frequency signal on the output of the discriminator (terminal 4 of V7). If output from the speaker is missing or weak, the trouble is probably located in the audio-frequency circuit.

Caution: Unless you are familiar with these sets, you may fail to recognize a loss of amplification in the set in these tests. It's a good idea to make a comparison with a receiver known to be in good condition.

(b) *I-f Circuits.*—Put an intermediate-frequency signal on the grid of the modulator (terminal 4 of V2). When the TUNE-OPERATE switch is at TUNE, a beat note should be heard. If step (a) gave a beat note but none is heard now, the trouble is probably in the intermediate-frequency part of the circuit.

(c) *R-f Circuits.*—Place a radio-frequency signal on the A (antenna) post. Tune the receiver to the frequency of the test signal. Throw the SQUELCH switch to ON. The squelch circuit should operate satisfactorily with the SENSITIVITY control near its minimum or extreme left position. Throw the SQUELCH switch to OFF; a beat note should be heard from the speaker. The tuning dial setting should agree approximately with the test signal frequency. Test the squelch and sensitivity control operation as described in Paragraphs f(12) and f(13) preceding.

(6) *Use of a Second Receiver as a Signal Generator.* If you have no signal generator, it will help a lot to have a second receiver handy. Keep it in good operating condition at all times to use as a source of test signals. The audio-, intermediate-, and radio-frequency signals may be obtained from the following points in the good receiver, in the following manner:


(a) *Audio Frequency.*—Audio-frequency signals may be obtained from one of the PHONES jacks of the good receiver. The VOLUME control of this receiver may be adjusted to give a satisfactory level of no-signal noise for use in testing the audio stages of the trouble receiver. If the signal strength is too great, the audio stages of the trouble receiver may be overloaded, thereby giving deceptive results. Connect the tip of a plug to a capacitor of 0.001 microfarad or greater capacitance. Insert the plug into one of the PHONES jacks to obtain an audio-frequency source. Connect the chassis of the two receivers together to complete the circuit. Throw the OUTPUT TO PHONES switch to ON.

(b) *Intermediate Frequency.*—You may obtain the intermediate frequencies from the second receiver, with the TUNE-OPERATE switch at TUNE, at terminal 7 of FL4. You can pick up a somewhat higher output on terminal 2 of FL4; use the former (lower level) point for all cases except where the circuits are badly misaligned. In all cases make the connection through a capacitor, preferably 0.001 microfarad or larger, located close to the source of test tone. If you have no capacitor, twist two insulated wires for about 18 inches, making sure that there is no metallic connection between the wires. These two wires (at the far end) form the two ends of the lead which carries the test frequencies. In order to prevent unwanted pickup and singing, combine this lead (in a twisted pair) with the ground wire which forms the circuit return. Mark each wire so it may be identified, equip each end of the pair with clips, and run it directly from the signal source to the point of use, preferably under the bottom of the good receiver (if it is at the left side). Leave the untwisted part as short as possible. This twisted pair for pickup and test frequency will then consist of:

(1) An insulated wire about 3-feet long used for connecting the chassis of the trouble receiver to the chassis of the source.

(2) Another insulated wire about 4-feet long cut in the middle and with the two

CAUTION: DANGEROUS VOLTAGES ARE EXPOSED



LEFT SIDE VIEW OF RECEIVER, COVER REMOVED, SHOWING DC POTENTIALS BETWEEN THE DESIGNATED TERMINALS AND THE RECEIVER CHASSIS ON METER OF 1000 OHMS PER VOLT.

NOTES

1. ALL VOLTAGES SHOULD BE MEASURED BETWEEN THE DESIGNATED TERMINAL - AND THE RECEIVER CHASSIS.
2. ALL SWITCHES EXCEPT THE TUNE-OPERATE AND THE ON-OFF SHOULD BE IN THE DOWNWARD POSITION.
3. VOLTAGES GIVEN ARE AVERAGE READINGS. A RECEIVER WHICH IS OPERATED SATISFACTORILY NEED NOT BE SERVICED JUST BECAUSE CERTAIN READINGS DIFFER FROM THOSE GIVEN AS DIFFERENCES IN MANUFACTURED EQUIPMENT CAUSE VARIATION IN VOLTAGES.
4. FIGURES GIVEN ARE BASED ON 12 OR 24 VOLTS FROM THE BATTERY. FOR OTHER BATTERY VOLTAGES THE READINGS GIVEN SHOULD BE ADJUSTED IN PROPORTION.
5. ACCURACY REQUIRES THAT ON MEASUREMENTS WITH A METER OF 1000 OHMS PER VOLT, FULL-SCALE READINGS MUST BE HIGHER THAN THE EXPECTED VOLTAGE.
6. VACUUM TUBE VOLTMETER MEASUREMENTS ARE BASED ON A VOLT-OMMETER 1-KΩ OR EQUIVALENT.
7. 0 MEANS NOT TO EXCEED 0.5 VOLTS ON METER OF 1000 OHMS PER VOLT.

Fig. 57. Radio Receiver BC-61

STAGE-BY-STAGE GAIN DATA FOR TROUBLE LOCATION

INPUT CONNECTION +	TEST FREQUENCY	INPUT REQUIRED TO OPERATE SQUELCH (CATHODE METER READINGS)	INPUT REQUIRED FOR EQUILIBRIUM (CATHODE METER READINGS)	OUTPUT METER READINGS
TERM. 4 OF V5 AND CHASSIS	2.85 MC		1 VOLT	16 VOLTS (APPROX.) 400 CPS.
TERM. 4 OF V5 AND CHASSIS		2 VOLTS (MAX.)		
TERM. 4 OF V5		0.1 VOLT (APPROX.)	0.05 VOLT (APPROX.)	16 VOLTS (APPROX.) 400 CPS.
TERM. 4 OF V5		500 MICROVOLTS (APPROX.)	50 MICROVOLTS (APPROX.)	16 VOLTS (APPROX.) 400 CPS.
TERM. 4 OF V5		100 MICROVOLTS (APPROX.)	10 MICROVOLTS (APPROX.)	16 VOLTS (APPROX.) 400 CPS.
TERM. 4 OF V5		30 MC	300 MICROVOLTS (APPROX.)	16 VOLTS (APPROX.) 400 CPS.
TERM. 4 OF V5		600 MICROVOLTS (APPROX.)	60 MICROVOLTS (APPROX.)	16 VOLTS (APPROX.) 400 CPS.
TERM. 4 OF V5		100 MICROVOLTS (APPROX.)	10 MICROVOLTS (APPROX.)	16 VOLTS (APPROX.) 400 CPS.
TERM. 4 OF V5		200 MICROVOLTS (APPROX.)	20 MICROVOLTS (APPROX.)	16 VOLTS (APPROX.) 400 CPS.
TERM. 4 OF V5		5.0V (APPROX.)	5.0 MICROVOLTS (APPROX.)	16 VOLTS (APPROX.) 400 CPS.
ANT. AND CHD. TERMINALS	27MC	1.0V (MAX.)		
ANT. AND CHD. TERMINALS	38MC	1.0 MICROVOLT INPUT		16 VOLTS (APPROX.) 150 CPS.
ANT. AND CHD. TERMINALS		2 *		20 * = 400 CPS.
ANT. AND CHD. TERMINALS		2 *		20 * = 1000
ANT. AND CHD. TERMINALS		2 *		11 * = 2500
ANT. AND CHD. TERMINALS		2 *		6 * = 5000
ANT. AND CHD. TERMINALS		2 *		2 * = 1000
ANT. AND CHD. TERMINALS		2 *		16 * = 5000

- THE SIGNAL GENERATOR CONNECTION SHALL ALWAYS BE MADE THROUGH A .005 MF SERIES CONDENSER.
- APPLY 1 VOLT OF 2.85 MEGACYCLES BETWEEN TERMINAL 4 OF V5 AND CHASSIS TO OBTAIN THE EQUIVALENT "CATHODE" METER (750-681) READING. BETWEEN 4 AND 9 MICROAMPERES SHOULD BE SUSTAINED.
- SQUELCH SWITCH OFF AND VOLUME CONTROL IN MAXIMUM CLOCKWISE POSITION. A FREQUENCY MODULATED SIGNAL GENERATOR (A18 KC DEVIATION) IS REQUIRED FOR OUTPUT MEASUREMENTS INVOLVING KC. AND LF. INPUTS. SPEAKER SWITCH SHOULD BE IN OFF POSITION WHEN MEASUREMENTS ARE MADE.
- THIS MEASUREMENT MAY BE MADE IF AN AUDIO FREQUENCY SOURCE IS AVAILABLE.


VOLTAGES AT TERMINALS OF FL AND LCU UNITS					
FL UNITS			LCU UNITS		
TERMINAL	VOLTAGE	TERMINAL	VOLTAGE	TERMINAL	VOLTAGE
1000 OHM RES. VOLTS METER (NOTE 5 & 7)	VACUUM TUBE VOLTMETER (NOTE 6)	1000 OHM RES. VOLTS METER (NOTE 5 & 7)	VACUUM TUBE VOLTMETER (NOTE 6)	1000 OHM RES. VOLTS METER (NOTE 5 & 7)	VACUUM TUBE VOLTMETER (NOTE 6)
FL1A	70	FL1A	70	LCU1A	0
2	70	2	70	2	0
3	0	3	0	3	0
4	0	4	0	4	0
5	180	5	180	5	0
6	0	6	0	6	0
7	0	7	0	7	0
8	0	8	0	8	0
FL2A	175	FL2A	175	LCU2A	0
1	175	1	175	1	0
2	0	2	0	2	0
3	0	3	0	3	0
4	0	4	0	4	0
5	185	5	185	5	0
6	0	6	0	6	0
7	0	7	0	7	0
8	0	8	0	8	0
FL3A	55	FL3A	55	LCU3A	0
1	55	1	55	1	0
2	0	2	0	2	0
3	0	3	0	3	0
4	0	4	0	4	0
5	60	5	60	5	0
6	0	6	0	6	0
7	0	7	0	7	0
8	0	8	0	8	0
FL4	25	FL4	25	LCU4	0
1	25	1	25	1	0
2	0	2	0	2	0
3	0	3	0	3	0
4	0	4	0	4	0
5	60	5	60	5	0
6	0	6	0	6	0
7	0	7	0	7	0
8	0	8	0	8	0

VOLTAGES AT VACUUM TUBE SOCKET TERMINALS										
1000 OHM PER VOLT VOLTMETER MEASUREMENTS (SEE NOTES 5 & 7)										
12 VOLT BATTERY										
TERMINAL NOS.	V1	V2	V3	V4	V5	V6	V7	V8	V9	V10
1	0	0	0	0	0	0	0	0	0	0
2	0	12	0	12	0	0	0	0	0	0
3	0	0	12	0	0	0	0	0	0	0
4	0	0	0	0	0	0	0	0	0	0
5	0	12	0	0	0	0	0	0	0	0
6	185	40	0	115	90	5.5	0	0	0	0
7	5	8	0	0	0	0	0	0	0	0
8	175	70	0	175	55	5.5	0	0	0	0
24 VOLT BATTERY										
1	0	0	0	0	0	0	0	0	0	0
2	0	12	0	12	0	0	0	0	0	0
3	0	0	12	0	0	0	0	0	0	0
4	0	0	0	0	0	0	0	0	0	0
5	0	12	0	0	0	0	0	0	0	0
6	185	40	0	115	90	5.5	0	0	0	0
7	5	8	0	0	0	0	0	0	0	0
8	175	70	0	175	55	5.5	0	0	0	0
VOLTAGES AT VACUUM TUBE SOCKET TERMINALS										
VACUUM TUBE VOLTMETER MEASUREMENTS (SEE NOTE 6)										
12 VOLT BATTERY										
TERMINAL NOS.	V1	V2	V3	V4	V5	V6	V7	V8	V9	V10
1	0	0	0	0	0	0	0	0	0	0
2	0	12	0	12	0	0	0	0	0	0
3	0	0	12	0	0	0	0	0	0	0
4	0	0	0	0	0	0	0	0	0	0
5	0	12	0	0	0	0	0	0	0	0
6	185	40	0	115	90	5.5	0	0	0	0
7	5	8	0	0	0	0	0	0	0	0
8	180	75	0	180	60	25	6	0	0	0
24 VOLT BATTERY										
1	0	0	0	0	0	0	0	0	0	0
2	0	12	0	12	0	0	0	0	0	0
3	0	0	12	0	0	0	0	0	0	0
4	0	0	0	0	0	0	0	0	0	0
5	0	12	0	0	0	0	0	0	0	0
6	185	40	0	115	90	5.5	0	0	0	0
7	5	8	0	0	0	0	0	0	0	0
8	180	75	0	180	60	25	6	0	0	0


RESISTANCE AT TERMINALS OF P2 (OHMS)	
TERMINAL	RESISTANCE VALUES
1	0
2	0
3,4,5,6	OPEN
7	NO
8	OPEN
9	0
10,11	OPEN
12	84
13	18,000
14	OPEN
15	9
16,17,18	OPEN

RESISTANCE AT TERMINALS OF P3 (OHMS)	
TERMINAL	RESISTANCE VALUES
1	OPEN
2	0
3	OPEN
4	800
5,6	OPEN
7	5,500
8	250
9,10	OPEN
11	250,000
12	400,000
13,14,15	OPEN
16	50
17	OPEN
18	250,000
19	OPEN

VIEW OF P260, SIDE OF P-1



VIEW OF TERMINAL SIDE OF P30



LEFT SIDE VIEW OF RECEIVER - COVER REMOVED

NOTES:

1. ALL RESISTANCE VALUES SHOWN ARE MEASURED BETWEEN THE RECEIVER CHASSIS AND DESIGNATED TERMINAL POINT.
2. A VARIATION OF $\pm 20\%$ FROM THE INDICATED VALUES SHOULD NOT BE REGARDED AS AN INDICATION OF A DEFECTIVE RECEIVER.
3. CERTAIN DISCREPANCIES MAY BE OBSERVED BETWEEN THE SCHEMATIC DIAGRAMS CONTAINED IN THESE INSTRUCTIONS AND THE CIRCUIT LAYOUT APPEARING ON THE RECEIVER. THESE DISCREPANCIES ARE DUE TO CHANGES MADE IN MANUFACTURE. IN SUCH CASES THE CIRCUIT LAYOUT APPLIES. NATURALLY, SUCH DISCREPANCIES MAY BE AFFECTED THE RESISTANCE VALUES INDICATED.
4. THE DIAPHRAGM MUST BE REMOVED BEFORE MAKING ANY RESISTANCE MEASUREMENTS.
5. PLACE ALL SWITCHES IN THE "OFF" OR COMMAND POSITION EXCEPT THE TUNE-OPERATE AND THE OUTPUT TO PHONE SWITCHES WHICH SHOULD POINT UP.
6. TURN THE VOLUME AND SENSITIVITY CONTROLS TO THEIR MAXIMUM COUNTERCLOCKWISE POSITION.
7. TO CHECK THE VOLUME CONTROL, CONNECT THE OHMMETER TEST LEAD TO TERMINALS OF J3. WITH THE VOLUME CONTROL AT MAXIMUM THE MEASURED RESISTANCE SHOULD BE APPROX. 18,000 OHMS AND SHOULD DECREASE TO 50 OHMS AS THE VOLUME CONTROL IS TURNED TO ITS EXTREME COUNTERCLOCKWISE POSITION.
8. TO CHECK THE SENSITIVITY CONTROL, MEASURE THE RESISTANCE FROM THE TERMINAL OF C23 TO P80. THE BLUE LEADS ARE ATTACHED TO THE MEASURED RESISTANCE AT THIS POINT SHOULD VARY BETWEEN 50 AND 250 OHMS AS THE SENSITIVITY CONTROL IS ROTATED. WHEN THIS CHECK IS MADE THE SQUELCH SWITCH MUST BE IN THE ON POSITION. ALL OTHER CHECKS ARE MADE WITH THIS SWITCH OFF.

Fig. 58. Radio Receiver BC-683-A: P

ends connected through a capacitor or wrapped together for about 18 inches where they overlap.

(c) **Radio Frequency.**—The radio frequency may be obtained from the good receiver at the suppressor grid of the modulator (terminal 3 of V2). For most alignment purposes, the stray pickup between two receivers placed about 2 feet apart is sufficient. For signal tracing, more pickup may be necessary. In this event, connection may be made by using a capacitor or two wires twisted together as described in (b). This frequency will be about 2.65 megacycles above the frequency indicated by the dial. Therefore, tune the receiver being tested to a frequency which is approximately 2.65 megacycles above that to which the good receiver is tuned.

(7) *Use of a Radio Transmitter BC-684-A as a Signal Generator.* If neither a signal generator nor a good receiver is available, you may use a transmitter in good operating order to provide a tone for tracing signals in the audio- or radio-frequency stages of a trouble receiver.

(a) **Audio Frequency.**—If the transmitter is in a mounting, an audio-frequency tone can be obtained from terminal 1 of the terminal strip TS401. You can see this terminal in the base of

the mounting when the door in the mounting at the left receiver position is opened.

Caution: Use a 0.001 to 1.0-microfarad capacitor in series with the lead, as one side of the audio source is grounded.

If the receiver is placed in a Mounting FT-237-(*) with this transmitter, throw the OUTPUT TO PHONES switch of the receiver to OFF. Turn the transmitter on. Audio frequencies will be available if the operator presses the microphone button of the transmitter and whistles or hums into the microphone. Use a throat microphone if you have it.

(b) **Intermediate Frequency.**—Since no source of 2.65 megacycles is available in the transmitter, no direct method of signal tracing in the intermediate-frequency section is available with the transmitter.

(c) **Radio Frequency.**—In general no direct connection between transmitter and receiver is necessary for picking up test radio frequencies for alignment work. In signal tracing where direct connection may be needed, use a shielded wire, with one end connected to the antenna terminal and the other hung near the transmitter. Connect a capacitor in series with this wire to prevent accidental short circuits.

Chart I. Equipment Required for Servicing of Radio Receiver BC-683-A

1. Schematic Diagram of Circuit

2. Voltage Measurements

Multirange d-c voltmeter of at least 1,000-ohms-per-volt

Maximum range required: 0-250 volts

Intermediate range: 0-30 volts approximately

Low range: 0-3 volts approximately

3. Resistance Measurements

Ohmmeter with a maximum range of 3 megohms

4. Tube Tests

a. Suitable tube tester with short circuit tests, or

b. A second Radio Receiver BC-683-A in good condition, or

c. Complete set of new tubes.


5. Signal Tracing

a. Suitable signal generator, or

b. A second Radio Receiver BC-683-A in good condition, or


c. A Radio Transmitter BC-684-A in good condition.

Chart II. Servicing Procedure for Radio Receivers BC-683-A Not Mounted in a Vehicle



Note: When trouble has been identified and cleared, continue with routine maintenance procedure.

Chart III. Servicing Procedure for Radio Receivers RC-683-A Mounted in a Vehicle



40. Location of Trouble in Radio Transmitter BC-684-A.

a. General. The following procedure is designed to locate trouble quickly and with as little damage as possible to the transmitter. A report from the operating personnel on the trouble experienced will usually aid in making repairs. Refer to the following figures as an additional aid in locating trouble:

- Figs. 47-50. Apparatus Location Diagrams.
- Fig. 52. Location of Alignment and Tuning Controls.
- Fig. 59. Voltage Diagram.
- Fig. 60. Resistance Diagram.
- Fig. 75. Wiring Diagram.

b. Inspection. Remove all covers from the transmitter and inspect for obvious defects. These may include broken parts, burned resistors, bent capacitor plates, bent pins on the connection plugs, or loose pieces of wire or metal. Smell for evidence of overheated parts. There may be broken gears, or the rack connecting the selector to the tuning capacitors may be out of alignment. Check for loose tubes or looseness in the grip of the socket receptacles on the contact pins of the tubes. Check for loose wires and repair any broken leads. Clean the inside, both top and bottom, with compressed air, paying especial attention to the selector mechanism.

Note: If an air hose is used, be sure any water condensed in it is blown out before applying the air stream to the equipment. Use only air intended for cleaning purposes and don't blow hard enough to dislodge or damage any apparatus.

c. Preliminary Precautions.

Caution: When the transmitter is operated with covers removed, dangerous voltages are exposed. *Be careful.*

Never run the dynamotor for long periods in either the RECEIVER TUNE or OPERATE position. The design requirements of the dynamotor are based upon 5 minutes operation with 15 minutes off. In addition to this, prolonged operation of

the set may cause objectionable heating effects within the transmitter. Never start the dynamotor with the transmitter ON-OFF switch (filament switch). Start the dynamotor with the RECEIVER TUNE-OPERATE switch or the microphone switch after the filaments have been heated for about 5 seconds (by closing the ON-OFF switch).


d. Power Supply Check. Lay the transmitter on its side with the panel up so you can read the meter and see the under chassis parts. Don't connect a microphone to the set.

Plug in auxiliary Cord CD-786 to connect the battery to the power receptacle on the transmitter. If the dynamotor starts, look for a stuck dynamotor relay or shorted relay contacts.

Turn the main ON-OFF switch to ON. The green signal lamp should light. If the lamp does not light, check for a burned-out pilot lamp or loose wiring at terminals 1 and 2 of PG101. Watch carefully for other obvious trouble as soon as the switch is turned on.

If desired, a voltmeter may be connected across the power supply during these tests. Operating the filament supply switch (Paragraph 40c) should not cause an appreciable change in the voltage reading if no trouble is present. If the dynamotor is short-circuited, the main fuse will open or there will be a continuous low-voltage reading when the dynamotor starts.

Assuming that the dynamotor does not start when the filament supply switch is operated and that no other trouble is noticed after operating the switch, connect a microphone to the set. Momentarily operate the microphone push button and note that the dynamotor starts. If the dynamotor does not start, inspect relay S102 for breakage, contact failure, or defective wiring. Inspect the dynamotor jacks and wiring. Check the dynamotor and also the microphone cord and jack. The dynamotor may start but may indicate by high-speed whine that it is operating at no load. Inspect for an open high-voltage fuse and other open-circuit trouble on the high-voltage supply leads. If the dynamotor starts but operates at low speed, check for a high-voltage overload. Remove the high-voltage fuse. If the dynamotor still labors, remove the battery cord from the set




CAUTION: DANGEROUS VOLTAGES ARE EXPOSED

NOTES:

1. LAYOUT CORRESPONDS WITH POSITION OF TRANSMITTER. DATA TAKEN WHILE TRANSMITTER IS OPERATING ON CHANNEL 350 INTO A 400 OHM LOAD. VOLTAGES ARE MEASURED FROM DESIGNATED POINTS TO FRAME OF TRANSMITTER.
2. OBSERVED METER READINGS MAY EXCEED THE VALUES SHOWN BECAUSE OF RF VOLTAGE SUPERIMPOSED ON DC VOLTAGE AT SOCKET TERMINALS.
3. MEASUREMENTS TO BE MADE WITH CRYSTAL OVEN THERMOSTAT UNOPERATED.
4. FOR VOLTAGE MEASUREMENTS, USE VOLTMETER SCALES AS FOLLOWS: 0-3 V, 5 VOLT SCALE
3-30 V, 50 VOLT SCALE
30-300 V, 300 VOLT SCALE
300-600 V, 600 VOLT SCALE

APPROXIMATE VOLTAGES AT VACUUM TUBE SOCKET TERMINALS																	
MEASUREMENTS WITH VOLTMETER OF 500 OHMS PER VOLT												MEASUREMENTS WITH VACUUM TUBE VOLTMETER					
TERM. NOS.	V101	V102	V103	V104	V105	V106	V107	V108	V109	V110	V111	TERM. NOS.	V101	V102	V103	V104	V111
1	0	0	0	2.5	0	0	0	0	0	0	0	1	0	0	0	2.5	0
2	10	7.5	2.5	300	2.5	18.5	2.5	7.5	0	0	0	2	10	7.5	2.5	300	2.5
3	400	400	400	40	400	345	100	400	0	0	0	3	400	400	400	40	400
4	130	245	160	—	2.5	380	80	730	0	0	0	4	130	245	160	—	2.5
5	-15	-22	-10	0	0	0	-1.4	-4.5	0	0	0	5	-15	-22	-10	0	0
6	—	—	-33	—	—	—	—	210	—	—	—	6	—	—	-23	—	—
7	7.5	10	5	—	5	10	0	0	—	—	—	7	7.5	10	5	—	5
8	0	0	0	—	0	0	0	0	—	—	—	8	0	0	0	—	0
CAP	—	—	—	600	—	—	—	—	—	—	—	CAP	—	—	—	600	—

Fig. 59. Radio Transmitter BC-684-A: Voltage Diagram



APPROXIMATE VOLTAGES AT PLUS TERMINALS			
12.5 VOLT BATTERY			
TERMINAL NOS.	PG 103	PG 104	
1	0	12.5	
2	0	12.5	
3	0	12.5	
4	-22	12.5	
5	0	0	
6	—	12.5	
7	0	0	
8	500	0	
25.5 VOLT BATTERY			
TERMINAL NOS.	PG 103	PG 104	
1	0	25.5	
2	0	12.5	
3	12.5	25.5	
4	-22	25.5	
5	0	0	
6	—	12.5	
7	12.5	0	
8	500	0	

CAUTION: DANGEROUS VOLTAGES ARE EXPOSED.

DATA TAKEN WHILE TRANSMITTER IS OPERATING ON CHANNEL 350 INTO A 40 OHM ANTENNA. ALL VALUES SHOWN REGARDLESS OF RF VOLTAGE SUPERIMPOSED ON DC VOLTAGE AT SOME TERMINALS. THERMOSTAT UNOPERATED.

SCALES AS FOLLOWS: 0-25V, 5 VOLT SCALE
3-30V, 30 VOLT SCALE
30-300V, 300 VOLT SCALE
300-600V, 600 VOLT SCALE

APPROXIMATE VOLTAGES AT VACUUM TUBE SOCKET TERMINALS									
MEASUREMENTS WITH VACUUM TUBE VOLTMETER (OR VOLTMETER OR EQUIVALENT)									
VOL.	TERM. NOS.	VIO1	VIO2	VIO3	VIO4	VIO5	VIO6	VIO7	VIO8
0	1	0	0	0	2.5	0	0	0	0
2.5	2	10	7.5	2.5	250	2.5	12.5	2.5	7.5
400	3	400	400	400	90	500	270	160	500
270	4	180	270	180	—	40	220	25	250
-4.5	5	-80	-60	-60	0	0	0	-9	-60
12.5	6	—	—	-25	—	—	—	—	400
5	7	2.5	10	2	—	5	30	0	5
2	8	0	0	0	—	0	0	0	0
—	CAP	—	—	—	500	—	—	—	—

Fig. 59. Radio Transmitter BC-684-A: Voltage Diagram

Table VI. Meter Switch Readings*

Switch position	1	2	3	4	5	6
Circuit	Doubler Grid	First R-f Grid	Rectifier Grid	Tripler Grid	Power Amplifier Grid	Total Plate and Screen
Meter reading (27.0 mc)	30	30	20	20	30	30
Meter reading (38.9 mc)	20	25	25	25	30	30

*Transmitter RECEIVER TUNE-OPERATE switch at RECEIVER TUNE.

and determine where the short circuit is and check the dynamotor.

e. Check of R-f Stages. Assuming that the dynamotor starts satisfactorily and that no other trouble is noticed upon operating the microphone push button, proceed to a rough check of the operation of the radio-frequency stages.

Check that all crystals are in place.

Caution: High voltage is present on the crystal pin-jacks when the transmitter is operating. *Don't take chances.*

Operate the push button for the highest frequency channel. Place the RECEIVER TUNE-OPERATE switch on RECEIVER TUNE and the TUNE-ANT CUR switch on TUNE. Turn the METER SWITCH on the right end of the transmitter to position 2 and observe the oscillator output to the first radio-frequency stage. This current will be considerably different for crystals of different activity. Any reading is probably satisfactory. (Note: This current may be high for sets with a 1000-ohm resistor R106; see Paragraph 44.) Operate the METER SWITCH successively to positions 3, 4, 1, and 5, observing the grid current to the rectifier, tripler, doubler, and power amplifier. The current readings given in Table VI may be used as a guide, but it is recommended (on account of possible wide tube and circuit variations) that the normal current readings for each transmitter be recorded for use in locating trouble. (Also see Paragraph 31e.) If you obtain a considerably different reading from that shown in Table VI at one point, your trouble may be near the point of such reading. Voltage and resistance readings in accordance with Figs. 59 and 60 should be made at the stage in which trouble is suspected to be present; if necessary, replace the tube in that stage. Low-voltage readings

indicate short circuits or high series resistance; high-voltage readings in general indicate defective tubes or open circuits or shorted series resistors.

Start the transmitter and check the selector adjustment by depressing the no. 1 push button and observing the maximum meter deflections with the METER SWITCH in positions 3, 4, 1, and 5, as the gang capacitor is varied slightly against the restoring force of the selector springs. *Do not attempt to rotate the capacitor control more than a few degrees.* The meter should indicate a maximum deflection at the capacitor setting determined by the selector. If the selector does not properly position the gang capacitor, it should be reset in accordance with Paragraph 21a. If the transmitter has been incorrectly tuned to the crystal frequency, incorrect peaking with METER SWITCH positions 1 and 3 will probably result. Improper alignment (assuming that the tuning was done properly) will probably result in low meter readings in positions 1 and 5.

Do not operate with the switch on RECEIVER TUNE for more than a few minutes at a time. If no trouble is indicated by the meter readings with the push button for the highest-numbered channel operated, take similar readings on the other channels in sequence.

f. Tuning Check. If your meter readings indicate need for tuning the channels, perform the tuning adjustments in accordance with Paragraph 21a and check as discussed in Paragraph 40e preceding.

g. Power Amplifier Check. To check the operation of the power amplifier, throw the RECEIVER TUNE-OPERATE switch to OPERATE. Throw the TUNE-ANT CUR switch to ANT CUR and see if the power output can be varied by

variation of the antenna trimmer capacitor. An antenna (see Paragraph 386) must be connected for this test. Also read the plate current (METER SWITCH in position 6 and TUNE-ANT CUR switch on TUNE) with the RECEIVER TUNE-OPERATE switch first at RECEIVER TUNE and then at OPERATE (microphone button pressed). The difference in readings should give the normal power amplifier plate current. Watch for sparking and overheating in the power amplifier tube itself. If there is output from the preceding stage and none from the power amplifier, check the voltage and resistance readings for the stage and the tube itself. Also check alignment of the power amplifier stage.

b. Check of Audio Stages. Replace the bottom cover plate and place the transmitter on the mounting for check with the associated receiver. Turn the SIDETONE control to maximum. Speak into a microphone. Sidetone should be heard in the associated receiver. As an over-all check of the audio stages and the transmitter itself, operate the transmitter and listen on the receiver of another set. This should give a satisfactory check for both operation and noise in the transmitter. If there is trouble in the audio stages, make a voltage and resistance check of both stages. Operating the transmitter with its own receiver will also give you a satisfactory check of the operation of the control circuits.

i. Intermittent Trouble. Whenever a complete inspection of a transmitter is made, every effort should be made to locate and clear intermittent trouble. Do this by complete inspection of parts and wiring and by gently shaking or jarring the transmitter.

41. Maintenance of Dynamotors.

a. Service Tools. No special tools are required for the ordinary care of Dynamotors DM-34 (*), DM-35 (*), DM-36 (*), and DM-37 (*). The following tools and material are desirable:

- 1—3½-inch cabinet screwdriver.
- 1—Small pair of pliers.
- 1—Toothbrush.
- 1—Clean cloth.

- 1—Can of light machine oil.
- 1—Can or tube of Type S-58 lubricant, or its equivalent.
- 1—Light hammer.
- 1—Center punch.
- A few sheets of grade 0000 (4/0) sandpaper.

b. Troubles and their Remedy.

(1) Failure to Start, or Dynamotor Stops:

Possible Cause	Correction
No d-c supply; open or loose connection.	Check d-c supply and tighten connections.
Brushes not seating properly; dirty, sticking, or worn brushes.	Remove brushes. Clean thoroughly and rescat or replace as required.
Poor commutation; dirty or rough commutator.	Clean commutator and brushes; if rough, sand with 4/0 sandpaper; turn commutator.
Worn bearings; armature strikes pole faces or connections.	Replace bearings.
Defective armature; short-circuited or open-circuited.	Replace dynamotor.

(2) Excessive Arcing at Brushes:

Possible Cause	Correction
Poor commutation; dirty or rough commutator.	Clean commutator and brushes; if rough, sand with 4/0 sandpaper; turn commutator.
Brushes not seating properly; dirty, sticking, or worn brushes.	Remove brushes. Clean thoroughly and rescat or replace as required.
Defective brush spring.	Replace brush assembly.
Short circuit between bars; dirty commutator.	Clean commutator, or replace dynamotor.
Open-circuited armature coil.	Replace dynamotor.

(3) Rapid Brush Wear:

Possible Cause	Correction
Excessive arcing.	See (2).
High mica.	Replace dynamotor.
Dirty commutator.	Clean commutator and brushes; smooth with 4/0 sandpaper.

(4) *Excessive Noise Picked Up in Radio Receiver BC-683-A:*

Possible Cause	Correction
Sparkling at commutator.	See (2).
Loose connections.	Tighten connections.
Capacitor open- or short-circuited.	Replace capacitor.

(5) *Excessive Noise and Vibration:*

Possible Cause	Correction
Armature striking internal wiring.	Rearrange wiring.
Armature striking pole pieces.	Replace dynamotor.
Worn bearings.	Replace dynamotor.

c. Routine Maintenance. If the radio equipment is operating normally, the dynamotors should need servicing (including lubrication) only about every 300 hours of use. The life of the dynamotor will be extended substantially if the end bells are removed and the dust wiped from the commutators and the brush holders every 100 hours or oftener. Unnecessary dressing of commutators, manipulating of brushes, or excessive greasing is likely to be harmful.

Note: In the following paragraphs, numbers in parentheses correspond to numbers in Figs. 41 and 42, exploded views of the two dynamotors, which are found on pages 67-68.

(1) *Lubrication.* Remove the end covers (13) by cutting the safety wires on the ends of the dynamotor and removing screws (14), washers (16), and lock washers (15). Wipe out loose dust and dirt. Take out the screws (28) holding the bearing bracket end plate (27) and remove the end plate, being careful not to lose any shims from the end of the shaft. With the toothbrush and cloth remove all old and hardened grease. Apply two or three drops of light machine oil to the ball bearings, and repack the outer side of the bearing with a small amount of Type S-58 lubricant as made by the New York and New Jersey Lubricant Company, or the equivalent. Do not get oil or grease on the commutator or brushes.

If there is grit in the bearings, you can clean them temporarily by removing the armature and swishing the bearings back and forth in cleaning fluid, such as petroleum spirits, kerosene, gasoline, or carbon tetrachloride. Be careful not to insert the armature far enough into the fluid to permit the windings to become wet. After cleaning, shake off as much cleaning fluid as possible, then insert the bearings into a bath of light machine oil, remove, and allow to drain before repacking with grease as outlined in Paragraph 41c(1).

(2) *Commutators.* A highly polished commutator surface is very desirable. Don't mistake a dark color for a burned condition. If the surface is smooth and is polished and the commutation satisfactory, leave it alone. Slight sparking does not necessarily mean poor commutation. If the surface of a commutator becomes dirty, wipe with a clean cloth. If necessary, wipe with a cloth moistened with cleaning fluid such as petroleum spirits, kerosene, or gasoline, followed by a dry cloth. Keep bearings and housing clean. Remove the covers and clean out the dust and dirt frequently. This cleaning should include removing the brushes and wiping the inside of the brush holders and the external surfaces of the brushes.

(3) *Brushes.* Each brush has a flexible pigtail and spring designed to limit the rotation of the spring and pigtail to a minimum when replacing a brush cap. Replace brushes when they are less than $\frac{1}{4}$ -inch long as measured from the bearing surface to the spring. Brush pressure is satisfactory if $\frac{1}{4}$ inch or more of the spring extends out of the brush holder when the holder cap is removed and the end of the brush is bearing on the commutator. Run in new or re-dressed brushes for several hours at no load when possible, to obtain proper fit before the dynamotor carries full load. It is desirable that the brushes be so seated that they bear over 100 per cent of their arc and have at least 75 per cent of their area in contact with the commutator. When brushes are replaced after removal, be sure you return them to the same holders from which they were removed. Insert the brushes in their re-

spective holders with the polarity mark facing upwards. When checking or replacing brushes make sure they slide easily in the brush holder; if they do not, the spring cannot force the brush against the commutator.

It is very important to keep brush resistance

as low as possible, so make sure the brush pigtail is in good condition. If a brush pigtail is broken or loose in the brush or end cap, the current has a tendency to go through the brush spring. This causes the spring to overheat, lose its temper, and give low brush pressure.

SECTION V. SUPPLEMENTARY DATA

4. Replacement of Parts.

a. Mounting FT-237-(*).

(1) Method of Removing Coaxial Cables from L and T Connectors.

(a) Remove the covers from the rear and rd channels of the mounting.

(b) Unsolder at the ground clips the ground wires running from the ferrule of the coaxial cable to the ground clips in the channel;

remove the varnished sleeving and bend the wires back from the channel.

(c) Remove the cover clips from the connectors and unsolder the connections inside the connectors.

(d) Loosen the Bristo set screw on the under side of the connectors, cut the tie strings which hold the coaxial cable in position, and pull out the coaxial cable and connectors from the rear channel.




Fig. 61. Mounting FT-237-(*) Schematic Diagram

(e) Cut the tie strings holding the coaxial cable in position in the end channel, unsolder the connection between the coaxial cable and the capacitor, remove the screw and nut from the coaxial cable ground clamp, and pull out the coaxial cable from the end channel.

(f) With the connector held in a pair of gas pliers in the left hand, place the connector against the tip of a 200-watt soldering iron (held stationary), and remove the cable from the connector by pulling with the right hand when the solder in the connector has been heated sufficiently to become fluid. Remove the excess solder from the connector by tapping it while hot against a solid object. (This permits ready re-use of the connector). The ground clip at the end of the coaxial cable may be removed and prepared for re-use in the same manner as for connectors.

(2) Method of Soldering Coaxial Cables to L and T Connectors.

(a) Assemble the ground wire to the ferrule by wrapping bare, tinned 22-gauge wire approximately three quarters of a turn around the cable close to the ferrule and approximately three turns around the ferrule as close to the end of the ferrule as practicable. (The wire should be twisted around the open, or flat, bead end of the cable.) Spot solder the wire to the ferrule (one spot) and cut off the wire end wrapped around the cable. The other end of the wire should be left approximately 3 inches long. Do not heat the coaxial any more than is absolutely necessary to solder it, otherwise the beads in the coaxial cable will soften.

(b) Insert the cable into the connector (L or T) far enough so that the bead is approximately $\frac{1}{8}$ -inch inside of the milled-out portion of the connector. Hold the connector and the cable in a vertical position; solder the ferrule of the cable and the ground wire to the connector, using a 200-watt soldering iron. Avoid unnecessary heating of the cable.

(c) With the cable in a horizontal position, solder the ground clamp to the ferrule at the end of the cable. To avoid twisting the cable, solder the ground clamp at approximately 90

degrees to the long axis of the portion of the connector having the Bristo set screw.

(d) Place the cable in a position adjacent to and approximately parallel with the rear channel. Assemble the varnished tubing on the ferrule ground wires and connect and solder the ground wires to the ground clip at the J401 and J402 receptacles.

(e) Place the coaxial cable in the channel, push the connectors into position on the radio-frequency terminals of the J401 and J402 receptacles, and tighten the Bristo set screws with a $\frac{1}{8}$ -inch Bristo hexagonal wrench. Assemble the ground clamp in the end channel with the screw and nut.

(f) Inside the connectors, twist together, solder, and clip the coaxial cable wires and the wires from the radio-frequency terminal on the J401 and J402 receptacles.

Note: Be sure the beads are in position on the wire from the radio-frequency terminals on the receptacles before twisting the wires together. If necessary, replace the beads.

Twist together, solder, and clip the coaxial wire and the capacitor terminal in the end channel.

(g) Tie the coaxial cable to the hexagonal nut of the plunger pin assembly and to the local cable (approximately seven ties).

(h) Replace the channel covers.

b. Radio Receiver BC-683-A.

(1) *Replacement of a Channel Selector Unit.* To replace a channel selector (tuner) unit in a receiver, perform the following operations.

(a) *Connections to be Unsoldered.*—Unsolder seven (sometimes eight) electrical connections at the tuner unit (channel selector) to release it from other receiver apparatus.

(b) *Screws to be Removed.*

(1) Remove the four screws releasing the front guard of the receiver.

(2) Remove the eight screws releasing the front panel.

(3) Loosen the five screws in the rear

of the tuner, releasing the tuner unit from the receiver chassis.

(c) Method of Replacing Channel Selector.

(1) With the front panel guard and front panel removed from the receiver, insert the tuner unit through the front panel opening into the chassis.

(2) Loosely fasten the unit to the chassis by five screws. *Do not tighten these screws.* See operation (5) for tightening.

(3) With the tuner loosely in place add the front panel with its apparatus, and fasten securely to the chassis (six screws) and the tuner unit (two screws).

(4) Add the front panel guard to the receiver, secure it firmly with four screws.

(5) Supplement operation (2) by securing the tuner firmly to the chassis with the five screws in the rear of the tuner. Be sure to follow this procedure of fastening the five rear screws as it avoids setting up a strain while tightening the two front screws which hold the tuner in position. (The six other screws which hold the front panel do not affect the tuner.) Such possible strain might permanently impair the accuracy of the tuner. Check to see that all push buttons operate smoothly and do not bind on the receiver panel.

(6) Resolder the seven (sometimes eight) electrical connections at the tuner unit.

(2) Replacement of a Push-button (Plunger) Assembly in a Channel Selector.

(a) Release the push button setting as described in Paragraph 21b. Release all push buttons.

(b) Screw Removal Operation.

(1) Remove four screws to release the front panel guard.

(2) Remove eight screws to release the front panel.

(3) Remove four flathead screws to release the tuner front plate and the latch-plate assembly.

(c) Removal of Latch-plate and Push-button Assembly.—Pull the lower end of the latch-plate assembly outward slightly. Grasp the

edges of the latch plate just behind the face plate and pull the latch plate downward. Pull the entire assembly outward gently to prevent jamming, and nurse the top end of the latch plate past the edge of the mounting bracket. Pull the assembly further until it separates from the connecting rods.

(d) Substitution of Push Button.—With the push buttons hanging downward, pull the latch plate back against its spring. Remove the faulty button and replace it with a new button making sure that the notch is in line with the notch on other buttons. Allow the latch plate to return to normal.

(e) Replacement of Latch-plate and Push-button Assembly.—Line up the latch-plate assembly with the connecting rods. Release the latch plate and mesh each button separately, starting at the top. When all are properly meshed, pull all buttons forward so that the latch plate can release and hold them. Push the assembly into place carefully by nursing the latch plate past the mounting bracket while the latch plate is pulled down. When it is in position, release the latch plate and replace the flathead screws to hold it in place. Replace the front panel and the front panel guard. Set the push buttons for the desired channels as described in Paragraph 21b.

c. Radio Transmitter BC-684-A.

(1) Replacement of a Channel Selector Unit. To replace a channel selector (tuner) unit in a transmitter, perform the following operations.

(a) Connections to be Unsoldered.

(1) Unsolder the short and long coaxial cables at antenna post A on the rear of the front panel. Also unsolder R155 from this post.

(2) Unsolder the short coaxial cable at the antenna relay S101.

(3) Unsolder at the relay (S101) the capacitor (C161) which connects a long coaxial cable to this relay.

(4) Unsolder, at the relay, the bare wire which connects the top of the L111 coil to the antenna relay.

(5) Unsolder, at the bottom of the L110 output coil, the bare wire (covered with varnished tubing) which leads to the power amplifier screen resistor (R114) located in the bottom compartment of the chassis. Also unsolder the black-red wire leading from the coil to the local cable of the transmitter.

(6) Unsolder, at the insulated stud *v*, the bare wire leading to the bottom of the left-hand tuner contact spring assembly.

(7) Unsolder, at the crystal oven, the ten electrical connections to the tuner spring contact assembly.

(b) Screws to be Removed.

(1) Remove the screw on top of the selector to release the ground terminal lug and wire leading to ground post G on the rear of the front panel.

(2) Remove six screws from the thermocouple, releasing it from its electrical connections and mounting.

(3) Remove the screw which secures the ground lug to the top of the tuner,—the lug to which the ground wires leading to the short and long coaxial cables ferrules are connected.

(4) Remove the screw from the top of the tuner, releasing the clamp that holds the long coaxial cable in place across the top of the unit. Carefully bend this cable to the left so that it will not interfere with vertical movement of the tuner.

(5) Remove four screws, releasing the antenna relay (S101) from its location. Rotate the relay upward and to the right.

(6) Remove the gear from the bottom end of the tuner shaft by loosening the set screws with the Bristo wrench, and remove the rack connecting the tuner to the six-gang capacitor.

(7) Remove the three screws at the base of the tuner, releasing it from the chassis.

(8) Remove the four screws in the panel guard and remove the guard; unscrew the seven front panel screws and rotate the panel about its right-hand edge (where cables are located) to remove the panel apparatus from the panel opening. Lift the channel selector unit out through the top opening of the transmitter.

(c) Method of Replacing Channel Selector.

(1) With the front panel guard removed and the front panel swung out of the way, insert the selector unit into the chassis through the top opening of the transmitter.

(2) Loosely fasten the unit to the chassis by the three screws applied into the base of the selector through the bottom opening of the transmitter.

(3) Repeat, in reverse order, the remaining steps of (a) and (b) preceding with the exception of (b)(6).

Caution: When fastening the tuner firmly in position (after the front panel and its apparatus have been secured to the transmitter), observe that the tuner shaft rotates freely; if it does not, loosen the three mounting screws and shift the tuner until the tuner shaft is free to rotate without binding action. When locating the front panel and the tuner in position, be sure the push buttons do not rub in the panel openings.

(4) With the six-gang capacitor fully engaged and the pin (on the disk by which this capacitor is manually rotated) resting against the front stop in the semicircular opening in the right end of the chassis, and with the single-section tuning capacitor at the top of the tuner also fully closed (maximum capacitance), insert the gear on the tuner shaft, assemble the rack in place, and securely tighten the set screw on the gear. Note that the rack is centrally located and that it moves freely back and forth over its total travel.

(2) Replacement of Capacitor Assembly (Including Six-gang Capacitor and Trimmer Capacitors). To replace a capacitor assembly in a transmitter, perform the following operations.

(a) Connections to be Unsoldered.—Unsolder, through the bottom opening of the transmitter, all wires connecting to the six-gang capacitors.

(b) Screws to be Removed.

(1) Remove, at the left-hand end of the gang capacitor, the screw which holds a bracket and insulated terminal in place.

(2) Through the bottom of the transmitter remove four screws from the trimmer capacitor assembly bracket, releasing the entire capacitor assembly from the chassis.

(c) *Replacement of Capacitor Assembly.*—Remove the capacitor assembly, replace with a new unit, and reassemble in reverse order from (a) and (b).

(3) *Replacement of Gang Capacitor in the Gang-capacitor Assembly.*

(a) Repeat operations of (2) (a) and (2) (b) preceding to release the entire capacitor assembly from the transmitter chassis.

(b) Unsolder all electrical connections between the six-gang capacitor assembly and the trimmer capacitors.

(c) Remove four elastic stop nuts on the six-gang capacitor assembly to release the bracket on which the associated trimmer capacitors are mounted.

(d) Separate the six-gang capacitor from the trimmer capacitor assembly bracket released by the stop nuts.

(e) Replace the six-gang capacitor with a new unit and reassemble, with the trimmer capacitor assembly, into the transmitter chassis.

(4) *Replacement of Trimmer Capacitor Assembly.*

(a) Repeat the operations of (3) (a) and (3) (d) preceding.

(b) Replace the trimmer capacitor section with a new unit and reassemble, with the six-gang capacitor assembly, into the transmitter chassis.

(5) *Replacement of a Push-button (Plunger) Assembly in a Transmitter Channel Selector.* To replace a channel selector push button in a transmitter, perform the following operations.

(a) Unsolder the long and short coaxial cables at antenna post A on the rear of the front panel.

(b) Remove the screw from the frame at the top of the selector unit to release the ground terminal wire leading to ground post G on the rear of the front panel.

(c) Remove the tie-string which supports the short coaxial cable in the position near the left-hand post of the panel meter.

(d) Remove the four screws holding the front panel guard.

(e) Remove the seven screws holding the front panel and rotate the panel outward about its right-hand edge.

(f) Remove the four screws on the tuner front plate and latch-plate assembly in order to release the push buttons.

(g) Pull the defective plunger (push button) forward to separate it from its associated rod.

(h) Replace plunger and reassemble.

(6) *Removal of Tuning Coils in Low Power Stages.*

(a) Unsolder the leads to the upper and lower terminals of the defective coil winding (L106, L107, L108, L118, or L119).

(b) Break the Glypral seal at the bottom of the cylindrical metal tube in the top compartment.

(c) Unscrew the metal tube from the coil form.

(d) Remove the coil winding assembly from the chassis by withdrawing it from its location hole into the bottom compartment of the transmitter.

(7) *Removal of Coaxial Cable Terminals from Plug PG101.*

(a) Unsolder the ground straps between the coaxial cable ferrules and the chassis.

(b) Remove two screws and hexagonal nuts from each end of the plug to release the two metal plates (clamps) that hold the cable terminals in place.

(c) Remove the metal clamps and pull the cables and terminals from their locations in the plug.

43. Modifications during Manufacture.

a. *General.* The radio equipment described in this manual has been produced in large quantities over a relatively long period of time. Dur-

ing this period the equipments have been under continual study in the manufacturing plants and in the field. Some changes in the equipment have resulted from these studies. By far the greatest number of changes has been due to the necessity of using a different material, or a part from a different manufacturer. In general, you will find that the units which comprise your radio set will differ in some slight respect from other similar units bearing the same order number.

This apparatus has not only been made in large quantities but also has been constructed by a number of different subcontractors, which means that there may be minor differences in construction or parts. Watch for these variations although in most cases they will not affect servicing procedure.

Changes in materials or in the source from which similar parts are obtained do not in general affect the servicing procedure, so this type of change is not described in this manual. Circuit and apparatus changes which should be known to aid the proper servicing of the unit are described in some detail in Paragraph 43b for the receiver and Paragraph 43c for the transmitter.

Figure 70 is a schematic diagram of the receiver showing how it was before these changes were made. The parts that have been changed are crossed out and the new arrangements shown. Figure 73 gives corresponding information for the transmitter.

If you wish to make any of these changes in an earlier equipment and if the change has been authorized, all the items listed under a particular minor heading in the change must be made as a group in order to obtain the desired improvement.

b. Radio Receiver BC-683-A.

(1) *Changes Affecting R17 and R19.* R17 has been changed from 1 megohm to 0.25 megohm. R19 has been changed from 1 megohm to 2 megohms. The purpose of this change was to increase the voltage on the CALL SIGNAL lamp.

(2) *Changes Affecting L72 and L71.* In earlier drawings these two inductors were shown interchanged. L72 should be the primary wind-

ing in the plate circuit of V5. L71 should be the secondary winding in the grid circuit of V6.

(3) *Changes Affecting C11.* C11 has been reduced from 0.01 to 0.006 microfarad. The purpose of this change was to reduce the number of 0.01-microfarad capacitors.

(4) *Changes Affecting C82 and C20.3.* C82 has been reduced from 0.01 to 0.006 microfarad. C20.3 has been connected in parallel with C82. (It was previously in parallel with C20.2.) The purpose of this change was to reduce the number of 0.01-microfarad capacitors. It was found that the audio-frequency impedance of the circuit at the points across which C82 is connected should be reduced to improve circuit operation. This was accomplished by connecting C20.3 across C82 after which C82 could be reduced. It was found, also, that when C20.3 was so connected, the stability of the circuit was better than it had been with C20.3 connected across C20.2.

(5) *Changes Involving R8, R21, R71, R72, R74, and C71 (Limiter Characteristics of V5).*

R8 has been increased from 20,000 to 70,000 ohms ($\frac{1}{2}$ -watt type).

R21, which is a 30,000-ohm (2-watt) type, has been added.

R71 has been increased from 100,000 ohms to 250,000 ohms.

R72 has been decreased from 43,000 ohms to 30,000 ohms.

R74 has been decreased from 10,000 to 1,000 ohms ($\frac{1}{2}$ -watt type).

C71 has been decreased from 100 to 50 micro-microfarads.

These wiring changes were desirable because, on very strong signals, the output of the limiter previously fell off so much as to interfere with the operation of the squelch circuit under some conditions. In addition, the changes improved the reception of weak signals through high noise levels. In general, the changes were:

To make the second intermediate-frequency amplifier, V5, a more effective limiter by lowering screen and plate voltages. This involves R8 and R21 and a change in the plate return of V5. R74, formerly 10,000 ohms, could be reduced to 1000 ohms as drop in this resistor was no longer re-

quired. R71 was increased to improve the limiting action. This necessitated reducing C71 to maintain the proper time constant. R72 was decreased to obtain optimum load cross L71.

To remove the second intermediate-frequency amplifier from the influence of the delayed-automatic-volume-control circuit. This improved reception through strong noise. It involved moving the grid return of V3 from the automatic-volume-control circuit to the negative end of the dynamotor.

These changes are indicated graphically in Fig. 70 which shows the old arrangement crossed out and the new arrangement added.

The actual changes in wiring are as follows:

(a) Move one pigtail of R8 from terminal 5 of FL2A to terminal 2 of FL2A.

(b) Remove a wire (covered with a black sleeve) from terminal 6 of VS5 and terminal 5 of FL3A.

(c) Connect one pigtail of R21 to terminal 5 of FL2A and the other pigtail to terminal 5 of FL3A.

(d) Remove the green (tracer) wire from terminal 4 of VS9 and connect it to that terminal of C25 to which the blue (tracer) leads are connected.

(e) Add a blue-brown (tracer) wire from terminal 5 of FL3A to terminal 5 of FL4.

(6) *Change Involving C44.* This 30-micro-microfarad capacitor in the radio-frequency oscillator circuit was changed from silver mica to an N-080 Ceramicon. The change was made to improve temperature stability.

(7) *Change Involving C26.* C26 has been reduced from 0.001 to 0.0005 microfarad. This was done to permit the use of a ceramic capacitor as an alternate. This change also improved the operation of the beat oscillator by reducing the pull-in at low frequencies.

(8) *Changes in Capacitors of Dynamotors.* In Dynamotors DM-34(*) and DM-36(*), all the filter capacitors in some units have been reduced from 0.005 to 0.003 microfarad. No reduction in circuit performance results from this

change. Where a replacement problem involves a substitution of a filter capacitor, either a 0.003 or a 0.005-microfarad unit may be used in any position in the dynamotor without regard to the capacitance of the remaining units, but the replacements must meet the voltage rating prescribed in Paragraph 45, Table of Replaceable Parts.

(9) *Change in C35.* This unit was reduced from 0.01 to 0.006 microfarad.

(10) *Changes Affecting C53, C54, C55, C56, C63, C64, C65, C66, C73, C74, C75, C76, C84, C85, C86, C87, C88.* These changes are tabulated as follows:

Filter	Original Unit	Capacitance Value	
		Original	Replacing
FL1A	C53 and C54	*50 + †10	‡60
FL1A	C55 and C56	†10 + *50	‡60
FL2A	C63 and C64	*50 + †10	‡60
FL2A	C65 and C66	†10 + *50	‡60
FL3A	C73 and C74	*50 + †10	‡60
FL3A	C75 and C76	†10 + *50	‡60
FL4	C84, C85, and C86	†5, *50, and *50	‡60 and ‡60
FL4	C87 and C88	*25 + †10	‡35

*Silver-mica.

†Ceramic N-680.

‡Ceramic N-080.

In filter units FL1A, FL2A, FL3A, and FL4 of the receiver, small ceramic capacitors were used originally in combination with silver-mica capacitors to provide temperature-compensated tuning capacitances. In later equipments these combinations of two capacitors have been replaced by single ceramic units each having capacitance and temperature compensation equal to those of the combination which it replaced. This is possible because a ceramic capacitor can be provided with any desired temperature coefficient (over a substantial range of positive and negative values). The single ceramic capacitor may be used as a direct replacement for the combination or vice versa. All the changes listed here fall in this class. Most of them are combinations where two units were in parallel and the changes involved a single ceramic with capacitance equal to the sum of the two and a temperature coefficient equivalent to their combination. In FL4, however, C85 and C86 (each a 50-micro-micro-

farad silver-mica capacitor) were in series and C84 (a 5-micromicrofarad Ceramicon) was in parallel with the combination, making a total of 30 micromicrofarads. C85 and C86 have been changed to 60-micromicrofarad Ceramicons with the desired temperature coefficient which makes C84 unnecessary.

(11) *Change in Designation of Switch D2.* Switch D2 on the receiver was originally designated RADIO & EXT-EXT ONLY. This designation was changed to OUTPUT TO PHONES ON-OFF to provide a better conception of the function of this switch.

(12) *Change to Sealed Unit LCU3-C.* LCU3-C units are sometimes supplied as spare parts in place of LCU3-A units to replace the LCU3-A oscillator unit. The LCU3-C unit is essentially the same as the LCU3-A unit, except that it has been sealed to exclude moisture, thereby improving frequency stability of the receiver under high humidity conditions. The terminal numbers molded in the bakelite seals of the LCU3-C unit correspond to the terminal numbers of the unsealed LCU3-A unit.

If difficulty is encountered with frequency stability of a receiver under high humidity conditions, replace the LCU3-A unit with an LCU3-C sealed unit as follows:

Wire the LCU3-C unit in place without disturbing the cap. The adjustable slug of the LCU3-C unit has been preset at the factory and should seldom require adjustment during the alignment procedure. The capacity trimmer C1.7 should be adjusted for dial tracking at 38 megacycles and the dial tracking checked at 28, 32, and 35 megacycles. In many instances a slight readjustment of C1.7 will improve alignment.

A maximum dial tracking error at any frequency of three-fourths channel division is considered quite satisfactory providing the maximum error at the other two check frequencies is less than one-half dial division. When dial errors somewhat in excess of these values are found, they can frequently be tolerated; in such cases, it is preferable to avoid tampering with the seal of the unit, even though the tracking is not all that might be desired.

Caution: This unit is sealed against moisture. Do not remove the cap unless absolutely necessary.

Should a slug adjustment at 28 megacycles be found necessary, use the following procedure:

- (a) Find as dry a place as possible.
- (b) Run the receiver about an hour with the dust cover in place to warm the unit.
- (c) To remove the cap, heat the single point solder seal of the cap with a soldering iron while exerting a turning motion on the cap.
- (d) Complete the alignment as quickly as possible.
- (e) Replace the cap and re-solder in place.
- (f) If the cap was off for more than five minutes, run the receiver at least an hour with the dust cover in place and the cap off the unit.
- (g) Remove dust cover, replace cap, and re-solder.

c. Radio Transmitter BC-684-A.

(1) *A Change that Should be Made in Existing Equipment: Fuse F101.* Fuse F101 should be of 1/2-ampere rating. Some of the early equipment had 1-ampere fuses which do not always give adequate protection. One-half ampere fuses (as supplied in the spare parts groups) should be substituted for any 1-ampere fuses in this position.

(2) Changes in Parts.

(a) *Change in C147.*—The unit used in later production is a ceramic-type capacitor of cylindrical form covered with a black bakelite finish. This is the preferred replacement part. It is specified with plus or minus 2 per cent tolerance and rated at 800 volts, working. If it cannot be obtained it is satisfactory to use the single 175-micromicrofarad unit of the C-D Type 1R capacitor or four 175-micromicrofarad units of the C-D Type 5R capacitor in series-parallel. It is not satisfactory to use a single C-D Type 5R unit.

(b) *Changes in Dynamotor Relay S102.*—This relay has been changed from a Type AO to a Type BO relay with increased contact pres-

are in the operated position. The latter unit is preferable but either can be used as available.

(c) Change in R107.—R107 was changed from 1/2-watt to 1-watt rating at 30,000 ohms in order to care for the higher current taken by some vacuum tubes.

(d) Changes in Resistors R119 and R155.—Two resistors R119 and R155 were originally specified as IRC Type F resistors. The IRC BT or BW types are just as satisfactory at these places and are or may be used interchangeably with Type F. The BT and BW types are preferred, however, because they mount in the transmitter more easily and with less chance of short-circuiting to adjacent parts or the chassis.

(e) Changes in Capacitors C138 and C142.—Capacitors C138 and C142 have been obtained from a number of different manufacturers and therefore it will be found that the "common" terminal (marked c on the capacitor can and in the wiring diagrams) will be located at one end of some capacitors and on the other end of other capacitors. Be careful in replacing a capacitor of this type to see that the c terminal is connected to the proper wires as shown in the wiring diagram of the transmitter.

(f) Changes in Transformers T101 and T102.—Some of these transformers were wound in the reverse direction from the majority. In many instances this will not cause poor operation but in some transmitters a reverse-wound transformer will be indicated by a high noise level on the radio carrier or on the interphone output. This can be cured by reversing (interchanging) the leads (red and blue) to terminals 5 and 6 on transformer T102. Transmitters using reversed transformers will have the wires interchanged at these terminals. Replacement transformers should be checked in this respect.

(3) Changes in Arrangement.

(a) Change in Connections of C122 and C123 and Addition of L123.—C122 was connected previously from the screen of V104 (power amplifier) to ground. Its ground terminal has been moved to the ungrounded side of the filament of V104. C123 was connected previously

from the ungrounded side of the filament of V104 to ground. It has been changed to connect between ground and the filament of V103. L123 has been added in the filament lead between V103 and V104. The purpose of these changes was to eliminate a tendency to spurious oscillation at very high frequency, which occurred in tube V104 of a few transmitters if a selector button was not depressed.

(b) Change in R118 and Addition of R162 and R163.—R118 has been changed to decrease the power dissipated in it. It was a 30,000-ohm, 2-watt unit, but has been changed to a 100,000-ohm, 2-watt unit, shunted by two other similar units (R162 and R163) mounted in the same resistance group. Thus the total resistance of the combination is not greatly changed but the power capacity is substantially increased. If a field replacement becomes necessary, it is desirable to use three 100,000-ohm, 2-watt units if possible. If they are not available a single 30,000-ohm, 2-watt unit may be used until the 100,000-ohm, 2-watt units can be obtained.

(c) Change in R102 and R107 and Addition of R160.—Some manufacturing variations caused the total current through dropping resistors R102 and R147 to exceed the allowable dissipation in these resistors. The later production units, therefore, were changed to add another resistor, R160, so that the three resistors could reliably dissipate the maximum heat. The total resistance of the three units was kept the same by reducing R102 and R147 from 1000 ohms each to 667 ohms each. R160 is 667 ohms.

(d) Change in R111 and Addition of R161.—R111 was changed from 15,000 ohms to 30,000 ohms, and R161 (30,000 ohms, 1 watt) was added in parallel to care for the increased grid current occurring with some tubes.

(e) Change in L106, L107, C111, C112, and Addition of C164.—During production it was found that some variations in wiring caused the coupling between L106 and L107 to be decreased below a suitable value. This was corrected by interchanging the coils and adding C164. The wiring changes are shown in the wiring diagram, Fig. 75. In the revised circuit some

of the coupling is obtained by mutual inductance between the two coils and additional coupling is obtained by the capacitor network C164, C111, and C112. It will be noted in the wiring diagram that in order to assure satisfactory operation, the leads to C111, C112, and C164 must be held to the length indicated. The tolerances of these capacitors must be held to those shown in Paragraph 45, Table of Replaceable Parts. If these capacitors are properly placed as shown by the wiring diagram and the leads correctly dimensioned, there should be no trouble in making this change in the field. This change need not be made in transmitters which are operating satisfactorily.

(f) Change in Wiring of R109.—One end of R109 was formerly connected to the bottom terminal of L106. This connection was moved in later transmitters to terminal 6 of VS108 in order to reduce the current through resistor R157.

(g) Shortening of Studs E and F and Relocation of L117-R149.—In the early production these studs were longer than necessary. This excess length produced coupling which caused poor oscillator operation in a few cases. Along with the shortening of the studs there were some wiring changes which are discussed in paragraph (3) following. The arrangements can be visualized by reference to Figs. 50 and 75. If this change is found necessary it will be facilitated by inspection of a late model transmitter as a guide. The steps in making the change are as follows:

(1) On stud F, interchange the top and bottom halves of the stud insulator and clip off the unnecessary part of the stud at the under side.

(2) On stud E, interchange the top and bottom halves of the stud insulator and clip off the unnecessary part of the stud at the under side.

(3) The coil-resistor combination (L117-R149) was previously connected from the end of stud E to R101 (the end away from the chassis). It crossed L102 on the side away from the chassis. This unit should be reconnected from the shortened stud E to R101—the end

nearest to the chassis. The wire previously connected to that end of R101 should be removed and reconnected to R101 at the end away from the chassis. With this rearrangement the coil-resistor combination passes between the chassis and coil L102.

(4) The two wires coming to L102 should be interchanged.

(h) Arrangement of Thermocouple Connections.—In order to permit adjusting the antenna current (TUNE-ANT CUR) meter reading over a wider range, the slide-wire adjustment was removed from between the terminals of the thermocouple and placed between the ends of the short coaxial transmission line connecting the antenna relay and the antenna binding post (A) on the front panel of the transmitter. This change cannot be made unless the replacement metering length of coaxial line is available. In installations where the antenna current reading on M101 is too low for convenient use, the reading may be raised by unsoldering the thermocouple slider tap and moving the tap to increase the reading. Take care that the antenna current reading will not go off scale under the highest voltage conditions. If the antenna current reading is too high, the direction of change should be reversed. This adjustment is most effective with the newer type arrangement of the thermocouple circuit.

(i) Meters and Thermocouples.—Meters from three manufacturers and thermocouples from two manufacturers have been used in the transmitters in order to maintain production when the meter or thermocouple from any one manufacturer became temporarily unavailable. Any of the meters and thermocouples will operate satisfactorily in a transmitter although there may be an inconsequential difference in meter readings when different meters are substituted, and the slide-wire tap may need slight adjustment when different thermocouples are substituted. The Weston thermocouples are somewhat faster in operation than the vacuum type marked with a number (ES-680241-7). The Weston meter originally had three connection studs, the two top ones going to the meter movement, the lower one going to the scale plate and magnet.

The lower stud is not and should not be used (see the wiring diagram, Fig. 75). In later meters this third stud has been eliminated. During the change-over from three to two studs, a number of the meters (about 1000) were incorrectly constructed to include a strap connection from the moving coil to the magnet and scale plate. This does not affect its operation at the TUNE position of D121 nor its operation with vacuum thermocouples for ANT CUR position of D121. However, in some transmitters a Weston meter having the incorrect connection may not operate properly with a Weston thermocouple. This will be indicated by very sluggish action of the meter when the antenna trimmer (usually at the highest frequency) is tuned. The meter reading will not drop to low values as it should when the antenna circuit is detuned by the trimmer. The approximately 1000 transmitters which have the incorrectly wired meter are satisfactory because they are equipped with vacuum thermocouples. When a Weston thermocouple is to be substituted for a vacuum thermocouple, tests as mentioned should be made to check the operation of the thermocouple-meter combination. If the trouble appears to be present, three methods of correction are available.

(1) Use a vacuum thermocouple if available; or

(2) Use a Hickok or Triplett meter if available; or

(3) Remove the Weston meter and unscrew and lift off the front portion of the case; open-circuit the connection between the scale plate and moving coil by clipping the strap which runs from the left screw and nut on the moving coil support and under the scale plate to the scale plate screw. Do not remove the nut on the moving coil support as that might cause the moving coil to become incorrectly positioned in its bearings and cause unsatisfactory operation of the meter.

(4) Changes in Values.

(a) Reduction in the Capacitance of C501, C502, C601, and C602.—C501 and C502 in the 12-volt dynamotor have been reduced from

0.003 to 0.002 microfarad. The same is true for C601 and C602 in the 24-volt dynamotor. Either value (0.002 or 0.003 microfarad) is satisfactory, however.

(b) Change in the Voltage Rating of the Postage-stamp Capacitors.—Some of the postage-stamp type of mica capacitors were changed to ones having a higher voltage rating. Capacitors having the voltage ratings shown in Paragraph 43, Table of Replaceable Parts, should be used for replacement purposes. Many capacitors of this type used in sets of early production did not show a designation as to voltage rating. More recently the voltage rating has been color coded, as shown in Paragraph 44. The sixth dot on the capacitor indicates the voltage rating—green for 500 volts, gray for 800 volts, and gold for 1000 volts.

(c) Change in Resistor R106.—R106 has been decreased from 1000 ohms to 100 ohms. The purpose was to keep the meter reading from going off scale when the battery voltage is high and switch D125 is in position 2. The resistor furnished in the spare parts has a resistance of 100 ohms. Replacement of a good existing 1000-ohm unit is not necessary unless the meter reading goes off scale when the battery voltage is high. Since this affects the meter reading you should allow for this when checking the operation of different transmitters.

(5) Elimination and Addition of Parts.

(a) Addition of R159.—R159 was added in later transmitters from the screen of the doubler V103 to ground, in order to make this tube operate more uniformly with wide variations of input voltage.

(b) Elimination of Capacitors C102 and C110.—C102, formerly connected to the filament of V101, and C110, formerly connected to the filament of V102, have been eliminated from the later transmitters. The purpose of this change was to reduce the use of mica capacitors. Either or both of these units may be omitted or removed without impairing the operation of the transmitter.

(c) Elimination of C160.—Capacitor C160 (across the primary of T102) has been

omitted from most transmitters. Some of these capacitors have failed due to surges occurring in the carbon microphone circuit. The omission of this unit in new equipment or removal of it from the existing equipment does not impair the performance of the transmitter. Its removal may cause a slight increase in response at the higher audio frequencies.

(d) Elimination of C107.—This capacitor has been found unnecessary because the units with which it was associated can be held to close tolerances during manufacture.

(e) Elimination of C503 and C603.—These capacitors across the low-voltage end of the 12- and 24-volt dynamotors, respectively, can be eliminated without causing trouble.

d. *Changes Affecting All Units.* All units of Radio Sets SCR-608-A and SCR-628-A use fasteners to hold covers in place. Most of the units employ Dzus fasteners but a number employ a Shakeproof fastener. Spare Shakeproof fasteners should not be used as replacements on units that have Dzus fasteners and vice versa.

e. *Relative Characteristics of Various Types of Capacitors and Resistors.* It has been necessary to substitute other types of capacitors in some places where mica units were specified. This has been done where such substitutions do not interfere with satisfactory operation of the radio equipment. In many cases the replacing units differ from the original units in size or




Fig. 63. Types of Capacitors and Resistors

shape or both. The relative appearance of the various capacitors and resistors used in these radio sets is shown in Fig. 63. The first column (A-D) shows ceramic capacitors. The second (E-H) shows mica capacitors and the third (I-J) shows oiled paper capacitors. In the fourth column (K-O) are various kinds of resistors. The general characteristics of such units are given in Table VII and discussed in more detail later. While Fig. 63 covers the range of types, it does not necessarily include all the variations produced by different manufacturers.

The units listed in Paragraph 45, Table of Replaceable Parts, have been selected because

they are the most suitable for the use for which they are specified. Other units, particularly ceramic capacitors, should not be used indiscriminately as replacements.

There are two general types of dielectric (insulation) which are often used in capacitors in place of mica. They are (1) ceramic material and (2) oiled paper. The ceramic capacitor consists of silver fired on ceramic insulation, the composition of the ceramic being varied to obtain different temperature coefficients. These are extremely stable and can be made to cover a wide range of values of temperature coefficients (from plus 120 to minus 750 parts per million

Table VII. Capacitor Characteristics

Table VII. Capacitors						
Group Letter (Fig. 63)	Type	Maximum as Used in This Equipment		Advantages	Disadvantages	Typical Use
		D-C Volts, Working Rating	μpf Capacitance			
First Column						
A	Insulated Ceramicon (trade name)	800	200	Stability and choice of temperature compensation	Size limitation for large capacitance; also B, C, and D must not touch metal	Temperature compensation and replacement for small silver- mica units
B	Uninsulated ceramic	800	500			
C	Uninsulated Ceramicon	800	500			
D	Uninsulated ceramic	800	500			
*Second Column						
E (red)	Insulated silver-mica	800	700	Stability		Tuned circuits
E (brown)	Insulated mica	800	500	Ease of manu- facture		By-pass
F (red)	Insulated silver-mica	1000	1000	Stability		Tuned circuits
F (brown)	Insulated mica	1000	10,000	Ease of manu- facture		By-pass
G (brown)	Insulated mica	1000	10,000	Ease of manu- facture		By-pass
H (brown)	Insulated mica	1200	10,000	Ease of manu- facture		By-pass
*Third Column						
I	Insulated oiled paper	800	10,000	Does not require mica, a critical war material	Not suitable for tuned circuits or large c-f currents	By-pass, replacing F and G
J	oiled paper	800	10,000			

*These capacitors are not obtainable with controlled temperature coefficients.

per degree Centigrade.) For a given size of unit, the capacitance increases as the temperature coefficient becomes more negative. Therefore, no range of capacitance values can be assigned to a particular size without specifying the temperature coefficient. For a given temperature coefficient, the capacitance of a ceramic unit can be increased only by increasing the length or diameter of the tube.

The three sizes shown under group A (Fig. 63) cover the range of physical sizes in which these insulated ceramic capacitors are manufactured. These units were supplied originally in small sizes to provide temperature compensation for the combination of coil and mica capacitor in a tuned circuit. More recently, they have been specified in larger sizes in some tuned circuits to eliminate the need for a mica capacitor and provide temperature compensation for the coil. Since ceramic units with equal capacitance may differ greatly in temperature coefficient, it is not safe to use a ceramic unit for a replacement (where stability is needed) unless the temperature coefficient is known to be correct for that use.

The units illustrated under A and C have the value, tolerance, and temperature coefficient stamped on the unit. The black units shown under D are stamped with the capacitance and a letter signifying the temperature coefficient. Those shown under B are marked with dots in accordance with the color code described in Paragraph 44. Of all these ceramics, the A items are the only ones having adequate insulation to permit installing them where they might touch metal parts. Groups B and C are merely enameled. Group D has a black bakelite coating for moistureproofing but this is not sufficient insulation to permit contact with metal.

Five sizes of ceramic capacitors are shown in Fig. 63. The two smallest are those in B. The next two are those in C, and the largest is the lower unit in D. Except for insulation the largest unit in group A corresponds in characteristics to the small unit in group C.

It will be noticed that with uninsulated ceramic capacitors, the leads are sometimes at

unequal distances from the ends of the unit. The lead which is farther from the end is connected to the outer surface of the capacitor. Whenever possible, this lead should be connected to the ground, or low potential, side of the circuit.

In the conventional type of mica capacitor, strips of metal foil are interleaved between sheets of mica dielectric (insulation). Changes in temperature cause an undesirable amount of variation in the capacitance of such units. The silver-mica unit gives a much more stable capacitor which is suitable for tuned circuits. It consists of sheets of mica with electrodes of silver bonded to each surface.

Groups E and F illustrate the two types of color code discussed in Paragraph 44. Groups E, F, and G are made in both foil-mica and silver-mica units. Group H is used in the transmitter. It is a larger capacitor with higher voltage rating and has a more rigid mounting arrangement.

All the mica capacitors shown in the second column of Fig. 63 are insulated by a molded bakelite jacket and can be allowed to rest against metal. In general, the foil-mica units have a brown jacket, and the silver-mica units have a red jacket. Capacitors with a straw-colored bakelite jacket, as used in this equipment, may be either foil-mica, silver-mica, or paper units.

Ceramic capacitors are used where high stability is necessary and paper capacitors elsewhere whenever possible.

The capacitors shown in the third column of Fig. 63 use oil-impregnated paper for insulation. For stability, they do not compare with silver-mica types but they can be used as replacements for foil-mica types for screen grid and filament positions of vacuum tubes where they do not need to pass much radio-frequency current. In general, they are good substitutes for mica units for most by-pass purposes. The voltage rating decreases as the capacitance increases as follows:

Capacitance (microfarads)	0.003	0.006	0.01
Rating (d-c volts, working)	800	600	400

Group I shows a molded bakelite case which is adequate insulation. In general, such units will be black though they may be straw-colored.

Group J shows tubular-shaped units. The top unit has a thin bakelite cover and may be allowed to touch metal. The second unit in this group has a metal case and may have either one or both leads insulated from this case. If one lead is not insulated, it should be connected to ground or the lower voltage connection. The bottom unit in group J is identical with the second except for a cover which gives some insulating protection but is not sufficient to permit resting the unit against metal.

In summary, the unit specified in the Table of Replaceable Parts for a particular circuit symbol may be different in appearance from the one which it replaces and may require some ingenuity in mounting. Groups I and J are intended to take the place of F and G in some applications. Groups A, B, C, and D replace silver-mica units of groups E, F, and G where stability is required but must be used only as specified because of the wide range of temperature coefficients which they cover. As described in Paragraph 43b(10), sometimes a single ceramic unit is used to replace a silver-mica plus a small ceramic.

The fourth column (groups K-O) shows various small resistors. They vary considerably in size and shape for the same wattage ratings due to differences in manufacture. The units shown in group K are $\frac{1}{2}$ watt, 1 watt, and 2 watts, respectively. They are bakelite-insulated and may touch metal. The unit shown under L is a 1-watt unit. The unit shown at M with side leads is a high-frequency resistor. This has metal ends and is not insulated. This unit is used only in a few places in the transmitter. It is rated at $\frac{1}{2}$ watt. The units shown at group N (brown body) are bakelite-insulated resistors of the $\frac{1}{2}$ - and 1-watt sizes made by another manufacturer. (This manufacturer also makes a similar uninsulated resistor with a black body.) These are directly interchangeable with the upper two units in group K, above. The units shown at O are $\frac{1}{2}$ - and 1-watt sizes from still another manufacturer and are interchangeable with corresponding units already mentioned.

Similar units of other manufacture not shown may be used to replace those illustrated.

44. Color Codes on Components. The various types of capacitors and resistors used in Radio Sets SCR-608-A and SCR-628-A are illustrated in Fig. 63 and discussed in Paragraph 43e. Some capacitors and resistors have their values stamped on the unit, but in many cases colored dots and bands are used instead. The various color codes used for capacitors and resistors are shown in Figs. 64 to 68 inclusive, and are discussed in the following paragraphs.

a. Molded Mica Dielectric Capacitors. Capacitors of this type are illustrated in groups E, F, G, and H of Fig. 63. Three different color codes are used on these units:

The three-dot code.

The RMA (Radio Manufacturers Association) six-dot code.

The AWS (American War Standard) six-dot code.

(1) *Three-dot Code for Molded Mica Capacitors.* This code, which was widely used for a number of years, is gradually being replaced by the other two codes. However, many components so marked are used in Radio Sets SCR-608-A and SCR-628-A. Also, this code is likely to be encountered in parts stocks. As indicated in Fig. 64, the basis of the code is a series of three colored dots which indicate the capacitance, in micromicrofarads, of the unit. Two auxiliary colored dots indicating, respectively, the voltage rating and the capacitance tolerance, are sometimes, but not always, added. There is usually a molded or stamped arrow to show the sequence in which the dots are to be read. Dots one and two indicate the first two digits, while dot three tells the decimal multiplier to be used. Take, for example, a 0.006-microfarad capacitor. Its capacitance in micromicrofarads is 6000; the three dots, in sequence, are: blue (6), black (0), red (100).

The dot indicating the tolerance, when used, is usually located above or below the third (decimal multiplier) dot. As shown in Fig. 64, the various colors correspond to tolerances between plus or minus 1 per cent and plus or minus 20 per cent.


The voltage dot, when used, is ordinarily located above or below the first (first digit) dot. The various colors tell, according to the code of Fig. 64, the d-c working voltage.

When either or both of the auxiliary dots are omitted, it indicates that the capacitance tolerance is plus or minus 20 per cent and that the d-c working voltage is the lowest rating for the particular type and size of capacitor.

(2) *RMA Code for Molded Mica Capacitors.* The RMA (Radio Manufacturers Association) code illustrated in Fig. 65 is used to a limited extent. It uses six colored dots with an arrow to show the sequence. The first three dots give the first three digits of the capacitance in micromicrofarads; the fourth dot (directly below the third) gives the decimal multiplier. The fifth indicates the tolerance in capacitance, and

the sixth, the d-c working voltage. For example: a capacitor of 0.006 microfarad (6000 micromicrofarads) plus or minus 10 per cent, 800 volts d-c, working, would be marked with dots in the following order: blue (6); black (0); black (0); brown (multiplier 10); silver (plus or minus 10 per cent); gray (800 volts).

(3) *AWS Code for Molded Mica Capacitors.* The AWS (American War Standard) code for molded mica capacitors is shown in Fig. 66a. Like the RMA code, it uses six colored dots, but with somewhat different significance. The first four dots give the capacitance in micromicrofarads, as follows: first significant figure; second significant figure; third significant figure; decimal multiplier. It will be noted that this scheme makes provision for marking units in three significant figures. For example, consider a capaci-



Color	First Dot First Digit	Second Dot Second Digit	Third Dot Decimal Multiplier	Tolerance	Voltage Rating
Black	0	0	1	±20%	
Brown	1	1	10	±1%	100
Red	2	2	100	±2%	200
Orange	3	3	1,000	±3%	300
Yellow	4	4	10,000	±4%	400
Green	5	5	100,000	±5%	500
Blue	6	6	1,000,000	±6%	600
Violet	7	7	10,000,000	±7%	700
Gray	8	8	100,000,000	±8%	800
White	9	9	1,000,000,000	±9%	900
Gold	—	—	0.1	±5%	1,000
Silver	—	—	0.01	±10%	2,000
Body	—	—	—	±20%	*

*When no color is indicated, the voltage rating may be as low as 300 volts.

Fig. 64. Molded Mica Capacitors: Three-dot Color Code

tor of 1,250 micromicrofarads. With the AWS code, the 1,250-micromicrofarad capacitor would be marked: brown (1), red (2), green (5), brown (10); the precise value of 1,250 micromicrofarads would thus be shown by the color code.

In practice, the precision markings just described are seldom necessary. In fact, none of the capacitors standardized under the AWS code requires more than two significant digits to specify its capacitance. For example, molded-mica-dielectric capacitors of the size known as "CM30" are standard in capacitances of 1000, 1100, 1200, 1300, 1500, 1600, etc., micromicrofarads. Intermediate values, such as 1,250 or 1,530, are not at present incorporated in the code. This is taken advantage of, as follows: The first dot on all capacitors now standard is black (0), and the two necessary significant figures are given by the second and third dots. The black first dot thus becomes a distinguishing feature or identification symbol, as it were, for a capacitor marked according to the AWS code. A couple of examples may serve to make this clear. Take, first, a 120-micromicrofarad capacitor; it is marked: black (0); brown (1); red (2); brown (10)—0120 micromicrofarads.

Or, consider a 9,100-micromicrofarad capacitor: black (0); white (9); brown (1); red (100)—09100 micromicrofarads. It will be noticed that in both these instances the first dot is black.

The fifth dot in the AWS code indicates the capacitance tolerance in per cent of nominal capacitance. The sixth dot indicates the design characteristics. The principal design characteristic, as indicated in Fig. 66a, is the temperature coefficient. For example a 0.006-micromicrofarad (6000 micromicrofarads) plus or minus 10 per cent mica by-pass capacitor would be marked: black (0); blue (6); black (0); red (100); silver (plus or minus 10 per cent); black (mica by-pass, with no temperature coefficient specified).

It will be noted that this color code does not include the voltage rating. This is considered



Color	First Dot First Digit	Second Dot Second Digit	Third Dot Third Digit	Fourth Dot Decimal Multiplier	Fifth Dot Tolerance	Sixth Dot Voltage
Black	0	0	0	1	—	—
Brown	1	1	1	10	1%	100
Red	2	2	2	100	2%	200
Orange	3	3	3	1,000	3%	300
Yellow	4	4	4	10,000	4%	400
Green	5	5	5	100,000	5%	500
Blue	6	6	6	1,000,000	6%	600
Violet	7	7	7	10,000,000	7%	700
Gray	8	8	8	100,000,000	8%	800
White	9	9	9	1,000,000,000	9%	900
Gold	—	—	—	0.1	5%	1,000
Silver	—	—	—	0.01	10%	2,000
Body	—	—	—	—	20%	500

Fig. 65. Molded Mica Capacitors: RMA Six-dot Color Code

unnecessary, since with few exceptions, all capacitors marked with this color code are rated at 500 d-c working volts. The exceptions, all of which are rated at 300 volts, are:

Type CM35 capacitors (53/64-inch maximum length) with capacitances of 6,800, 7,500, and 8,200 micromicrofarads.

Type CM40 capacitors (1-1/32 inch maximum length) with capacitances of 9,100 and 10,000 micromicrofarads.

Further details of the American War Standard for fixed-mica-dielectric capacitors will be found in Standard C75.3 of the American Standards Association.



b. Molded Paper Dielectric Capacitors. A new AWS color code for small molded paper dielectric capacitors is shown in Fig. 66b. Although this code has found little application to date, it is possible that some units so marked may be encountered in future equipment or stocks. Like the code for mica capacitors just discussed, it employs six colored dots, together with an arrow to indicate the sequence. Units marked according to this system can readily be identified by the fact that both the first and fifth dots are always silver. The other dots are used as follows: the second dot gives the first digit of the capacitance in micromicrofarads; the third dot gives the second significant figure; the fourth dot indicates the decimal multiplier; the sixth tells whether the unit has a maximum operating temperature of 167 degrees or 185 degrees Fahrenheit.

No indication of the working voltage is given by the color code. In general, it can be said that molded paper dielectric capacitors meeting the AWS specification have d-c working voltages be-

Color	First Dot First Digit	Second Dot Second Digit	Third Dot Third Digit	Fourth Dot Decimal Multiplier	Fifth Dot Tolerance	*Sixth Dot Characteristics
Black	0	0	0	1	±20%	A
Brown	1	1	1	10	—	B
Red	2	2	2	100	± 2%	C
Orange	3	3	3	1,000	—	D
Yellow	4	4	4	—	—	E
Green	5	5	5	—	—	F
Blue	6	6	6	—	—	G
Violet	7	7	7	—	—	—
Gray	8	8	8	—	—	—
White	9	9	9	—	—	—
Gold	—	—	—	0.1	± 5%	—
Silver	—	—	—	0.01	±10%	—

*A. Ordinary mica by-pass.

B. Same as A, low-loss case.

C. By-pass or silver-mica capacitor (temperature coefficient: ± 200 parts/million/°C).

D. Silver-mica capacitor (temperature coefficient: ± 100 parts/million/°C).

E. Silver-mica capacitor (temperature coefficient: 0 to + 100 parts/million/°C).

F. Silver-mica capacitor (temperature coefficient: 0 to + 50 parts/million/°C).

G. Silver-mica capacitor (temperature coefficient: 0 to -50 parts/million/°C).

Fig. 66a. Molded Mica Capacitors: AWS Six-dot Color Code

Color	First Dot	Second Dot	Third Dot	Fourth Dot	Fifth Dot	Sixth Dot
	First Digit	Second Digit	Decimal Multiplier			Characteristics
Black	0	0	1			*A
Brown	1	1	10			†B
Red	2	2	100			—
Orange	3	3	1,000			—
Yellow	4	4	—			—
Green	5	5	—			—
Blue	6	6	—			—
Violet	7	7	—			—
Gray	8	8	—			—
White	9	9	—			—
Gold	—	—	—			—
Silver	—	—	—			—

First dot silver to indicate
AWS paper capacitor

Fifth dot silver to indicate
AWS paper capacitor

*A. Operating temperature range, -67 to +185 F.
†B. Operating temperature range, -67 to +167 F.




Fig. 66b. Molded Paper Capacitors:
AWS Six-dot Color Code

Color	Tip *Temperature Coefficient	First Dot First Digit	Second Dot Second Digit	Third Dot Decimal Multiplier	Fourth Dot †Tolerance
Black	0	0	0	1	±20
Brown	0.00003 neg.	1	1	10	±1
Red	0.00008 neg.	2	2	100	±2
Orange	0.00015 neg.	3	3	1,000	±3
Yellow	0.00022 neg.	4	4	10,000	±4
Green	0.00033 neg.	5	5	100,000	±5
Blue	0.00047 neg.	6	6	1,000,000	±6
Violet	0.00075 neg.	7	7	0.001	±7
Gray	—	8	8	0.01	±2.5
White	—	9	9	0.1	±10

*The temperature coefficient is expressed in micromicrofarads per micromicrofarad per degree Centigrade. Some capacitors are marked with a numeral instead of a color code; for example, N-050 represents 0.00005 neg.


†Tolerances for capacitors of 10 micromicrofarads or less are expressed in terms of a micromicrofarad instead of percentages.

Fig. 67. Tubular Ceramic Capacitors: RMA Color Code

tween 300 and 800 volts. The lower voltage applies to units with high-capacitance ratings; the higher voltage applies to units with low-capacitance ratings. Further details will be found in Standard C75/221 of the American Standards Association.

c. Tubular Ceramic Dielectric Capacitors.

Tubular ceramic dielectric capacitors, which are widely used for temperature compensation, are sometimes marked according to the RMA color code shown in Fig. 67. As will be seen from the figure, the negative temperature coefficient is in-



Color	First Significant Figure	Second Significant Figure	Decimal Multiplier	Tolerance
Black	0	0	1	—
Brown	1	1	10	± 1%
Red	2	2	100	± 2%
Orange	3	3	1,000	± 3%
Yellow	4	4	10,000	± 4%
Green	5	5	100,000	± 5%
Blue	6	6	1,000,000	± 6%
Violet	7	7	10,000,000	± 7%
Gray	8	8	100,000,000	± 8%
White	9	9	1,000,000,000	± 9%
Gold	—	—	0.1	± 5%
Silver	—	—	0.01	± 10%
No color	—	—	—	± 20%

Fig. 68. Fixed Resistors: RMA and AWS Standard Color Codes

dictated by the color of the band or tip at one end of the unit; the capacitance in micromicrofarads is shown by the first three dots; the capacitance tolerance, either in per cent or tenths of a micromicrofarad, depending upon the size of the unit, is indicated by the fourth and last dot. Example: a 30-micromicrofarad plus or minus 5-per-cent capacitor with a negative temperature coefficient of 80 parts per million per degree Centigrade would be marked as follows: tip, red (-80); first dot, orange (3); second dot, black (0); third dot, black (1); fourth dot, green (plus or minus 5 per cent).

d. Fixed Resistors. Small fixed resistors, both composition-type and wire-wound, are frequently marked with colored bands and dots to indicate the resistance and tolerance. Two color codes are widely used: the RMA and the AWS. The two codes are not identical in all particulars, but they are similar in many respects. One chart, applicable to both, is shown in Fig. 68. It will be seen that in all cases the various combinations of body color, bands, and dots indicate the resistance to two significant figures (the first two digits), the decimal multiplier, and the per cent tolerance in resistance.

As illustrated by Fig. 68, two basic methods are used for indicating the resistance and tolerance:

Method A. This uses four colored bands, starting at one end of the unit, to show resistance and tolerance. The bands, reading from left to right, indicate: first significant figure; second significant figure; decimal multiplier; per cent tolerance. (The significance of

the body color under this method will be explained later.)

Method B. Several variations of this method are in use (B1, B2, B3 of Fig. 68). With all of these, however, the interpretation of the code is practically the same: left end, tolerance; body, first significant figure; right end, second significant figure; central dot or band, decimal multiplier.

To illustrate the basic schemes, consider a 5,600-ohm \pm 10-per-cent fixed resistor. It would be marked:

Method A. First band, green (5); second band, blue (6); third band, red (100); fourth band, silver (\pm 10 per cent).

Method B. Left end, silver (\pm 10 per cent); body, green (5); right end, blue (6); central band or dot, red (100).

In Method A, where the body color plays no part in indicating resistance or tolerance, it may be used to indicate the type of resistor unit. Under the RMA code, a black body is frequently used to indicate an uninsulated composition unit; a tan, olive, or white body, an insulated composition unit; and a dark brown body, an insulated wire-wound unit. The AWS code requires that an uninsulated unit using Method A have a black body; the body of an insulated unit may be any color, although a natural tan is preferred.

When there is doubt as to whether a particular resistor is composition or wire-wound, it is well to remember that any resistor of 100 ohms or less is very likely to be wire-wound—also, to remember that it may be wound inductively.

45 TABLE OF REPLACEABLE PARTS (TABLE 11).

NOTE: The list of stock numbers is intended to supplement the Signal Corps drawing catalog until such time as the catalog is revised to include the stock numbers in this table. Under replacement part by stock number and designation.

Reference Number	Signal Corps Stock Number	Name and Description of Part	Function	Mr.'s. Code and Type Number	Contractor's Drawing Number
<u>a. Radio Receiver RC-607-A:</u>					
	204462-683A	Radio Receiver RC-607-A		WE	
101-2, 101-4		Variable air capacitor, 60 muf, part of push-button tuner assembly	Tuning Control	WE	
101-5, 101-6				WE	
101-1, 101-3		Trimmer capacitor, 16 muf, part of push-button tuner assembly	Trimming	WE	
101-5, 101-7				O-D Type 1M	
102	30A6-10	Capacitor, 0.006 mfd, 300 volts dc	R-F Screen By-pass	O-D Type 1M	
103	30A6-10	Capacitor, 0.006 mfd, 300 volts dc	Modulator Cathode By-pass	O-D Type 1M	
104	30A6-10	Capacitor, 0.006 mfd, 300 volts dc	Modulator Screen By-pass	O-D Type 1M	
105	30A6-10	Capacitor, 0.006 mfd, 300 volts dc	Heating Oscillator Plate Filter	O-D Type 1M	
106	30A6-10	Oscillator, 0.006 mfd, 300 volts dc	First I-F Screen By-pass	O-D Type 1M	
107	30A6-10	Capacitor, 0.006 mfd, 300 volts dc	Second I-F Screen By-pass	O-D Type 1M	
108	30S500-18	Capacitor, 500 muf, 500 volts dc	Limiter Cathode By-pass	O-D Type 1M	
109	30A6-10	Capacitor, 0.006 mfd, 300 volts dc	Limiter Screen By-pass	O-D Type 1M	
1010	30B975	Capacitor, 0.75 \pm 0.25 muf, 500 volts dc	I-F Oscillator Coupling	Reids Type 1000M	
1011	30A6-10	Capacitor, 0.006 mfd, 300 volts dc	First Audio Grid Coupling	O-D Type 1M	
1012	30A10-48	Capacitor, 0.01 mfd, 300 volts dc	First Audio Grid Mesh Filter	O-D Type 1D	

1012
1013
1014
1015
1016
1017
1018
1019
1020
1021
1022
1023
1024
1025
1026
1027
1028
1029
1030
1031
1032
1033
1034
1035
1036
1037
1038
1039
1040
1041
1042
1043
1044
1045
1046
1047
1048
1049
1050
1051
1052
1053
1054
1055
1056
1057
1058
1059
1060
1061
1062
1063
1064
1065
1066
1067
1068
1069
1070
1071
1072
1073
1074
1075
1076
1077
1078
1079
1080
1081
1082
1083
1084
1085
1086
1087
1088
1089
1090
1091
1092
1093
1094
1095
1096
1097
1098
1099
1100
1101
1102
1103
1104
1105
1106
1107
1108
1109
1110
1111
1112
1113
1114
1115
1116
1117
1118
1119
1120
1121
1122
1123
1124
1125
1126
1127
1128
1129
1130
1131
1132
1133
1134
1135
1136
1137
1138
1139
1140
1141
1142
1143
1144
1145
1146
1147
1148
1149
1150
1151
1152
1153
1154
1155
1156
1157
1158
1159
1160
1161
1162
1163
1164
1165
1166
1167
1168
1169
1170
1171
1172
1173
1174
1175
1176
1177
1178
1179
1180
1181
1182
1183
1184
1185
1186
1187
1188
1189
1190
1191
1192
1193
1194
1195
1196
1197
1198
1199
1200
1201
1202
1203
1204
1205
1206
1207
1208
1209
1210
1211
1212
1213
1214
1215
1216
1217
1218
1219
1220
1221
1222
1223
1224
1225
1226
1227
1228
1229
1230
1231
1232
1233
1234
1235
1236
1237
1238
1239
1240
1241
1242
1243
1244
1245
1246
1247
1248
1249
1250
1251
1252
1253
1254
1255
1256
1257
1258
1259
1260
1261
1262
1263
1264
1265
1266
1267
1268
1269
1270
1271
1272
1273
1274
1275
1276
1277
1278
1279
1280
1281
1282
1283
1284
1285
1286
1287
1288
1289
1290
1291
1292
1293
1294
1295
1296
1297
1298
1299
1300
1301
1302
1303
1304
1305
1306
1307
1308
1309
1310
1311
1312
1313
1314
1315
1316
1317
1318
1319
1320
1321
1322
1323
1324
1325
1326
1327
1328
1329
1330
1331
1332
1333
1334
1335
1336
1337
1338
1339
1340
1341
1342
1343
1344
1345
1346
1347
1348
1349
1350
1351
1352
1353
1354
1355
1356
1357
1358
1359
1360
1361
1362
1363
1364
1365
1366
1367
1368
1369
1370
1371
1372
1373
1374
1375
1376
1377
1378
1379
1380
1381
1382
1383
1384
1385
1386
1387
1388
1389
1390
1391
1392
1393
1394
1395
1396
1397
1398
1399
1400
1401
1402
1403
1404
1405
1406
1407
1408
1409
1410
1411
1412
1413
1414
1415
1416
1417
1418
1419
1420
1421
1422
1423
1424
1425
1426
1427
1428
1429
1430
1431
1432
1433
1434
1435
1436
1437
1438
1439
1440
1441
1442
1443
1444
1445
1446
1447
1448
1449
1450
1451
1452
1453
1454
1455
1456
1457
1458
1459
1460
1461
1462
1463
1464
1465
1466
1467
1468
1469
1470
1471
1472
1473
1474
1475
1476
1477
1478
1479
1480
1481
1482
1483
1484
1485
1486
1487
1488
1489
1490
1491
1492
1493
1494
1495
1496
1497
1498
1499
1500
1501
1502
1503
1504
1505
1506
1507
1508
1509
1510
1511
1512
1513
1514
1515
1516
1517
1518
1519
1520
1521
1522
1523
1524
1525
1526
1527
1528
1529
1530
1531
1532
1533
1534
1535
1536
1537
1538
1539
1540
1541
1542
1543
1544
1545
1546
1547
1548
1549
1550
1551
1552
1553
1554
1555
1556
1557
1558
1559
1560
1561
1562
1563
1564
1565
1566
1567
1568
1569
1570
1571
1572
1573
1574
1575
1576
1577
1578
1579
1580
1581
1582
1583
1584
1585
1586
1587
1588
1589
1590
1591
1592
1593
1594
1595
1596
1597
1598
1599
1600
1601
1602
1603
1604
1605
1606
1607
1608
1609
1610
1611
1612
1613
1614
1615
1616
1617
1618
1619
1620
1621
1622
1623
1624
1625
1626
1627
1628
1629
1630
1631
1632
1633
1634
1635
1636
1637
1638
1639
1640
1641
1642
1643
1644
1645
1646
1647
1648
1649
1650
1651
1652
1653
1654
1655
1656
1657
1658
1659
1660
1661
1662
1663
1664
1665
1666
1667
1668
1669
1670
1671
1672
1673
1674
1675
1676
1677
1678
1679
1680
1681
1682
1683
1684
1685
1686
1687
1688
1689
1690
1691
1692
1693
1694
1695
1696
1697
1698
1699
1700
1701
1702
1703
1704
1705
1706
1707
1708
1709
1710
1711
1712
1713
1714
1715
1716
1717
1718
1719
1720
1721
1722
1723
1724
1725
1726
1727
1728
1729
1730
1731
1732
1733
1734
1735
1736
1737
1738
1739
1740
1741
1742
1743
1744
1745
1746
1747
1748
1749
1750
1751
1752
1753
1754
1755
1756
1757
1758
1759
1760
1761
1762
1763
1764
1765
1766
1767
1768
1769
1770
1771
1772
1773
1774
1775
1776
1777
1778
1779
1780
1781
1782
1783
1784
1785
1786
1787
1788
1789
1790
1791
1792
1793
1794
1795
1796
1797
1798
1799
1800
1801
1802
1803
1804
1805
1806
1807
1808
1809
1810
1811
1812
1813
1814
1815
1816
1817
1818
1819
1820
1821
1822
1823
1824
1825
1826
1827
1828
1829
1830
1831
1832
1833
1834
1835
1836
1837
1838
1839
1840
1841
1842
1843
1844
1845
1846
1847
1848
1849
1850
1851
1852
1853
1854
1855
1856
1857
1858
1859
1860
1861
1862
1863
1864
1865
1866
1867
1868
1869
1870
1871
1872
1873
1874
1875
1876
1877
1878
1879
1880
1881
1882
1883
1884
1885
1886
1887
1888
1889
1890
1891
1892
1893
1894
1895
1896
1897
1898
1899
1900
1901
1902
1903
1904
1905
1906
1907
1908
1909
1910
1911
1912
1913
1914
1915
1916
1917
1918
1919
1920
1921
1922
1923
1924
1925
1926
1927
1928
1929
1930
1931
1932
1933
1934
1935
1936
1937
1938
1939
1940
1941
1942
1943
1944
1945
1946
1947
1948
1949
1950
1951
1952
1953
1954
1955
1956
1957
1958
1959
1960
1961
1962
1963
1964
1965
1966
1967
1968
1969
1970
1971
1972
1973
1974
1975
1976
1977
1978
1979
1980
1981
1982
1983
1984
1985
1986
1987
1988
1989
1990
1991
1992
1993
1994
1995
1996
1997
1998
1999
2000
2001
2002
2003
2004
2005
2006
2007
2008
2009
2010
2011
2012
2013
2014
2015
2016
2017
2018
2019
2020
2021
2022
2023
2024
2025
2026
2027
2028
2029
2030
2031
2032
2033
2034
2035
2036
2037
2038
2039
2040
2041
2042
2043
2044
2045
2046
2047
2048
2049
2050
2051
2052
2053
2054
2055
2056
2057
2058
2059
2060
2061
2062
2063
2064
2065
2066
2067
2068
2069
2070
2071
2072
2073
2074
2075
2076
2077
2078
2079
2080
2081
2082
2083
2084
2085
2086
2087
2088
2089
2090
2091
2092
2093
2094
2095
2096
2097
2098
2099
2100
2101
2102
2103
2104
2105
2106
2107
2108
2109
2110
2111
2112
2113
2114
2115
2116
2117
2118
2119
2120
2121
2122
2123
2124
2125
2126
2127
2128
2129
2130
2131
2132
2133
2134
2135
2136
2137
2138
2139
2140
2141
2142
2143
2144
2145
2146
2147
2148
2149
2150
2151
2152
2153
2154
2155
2156
2157
2158
2159
2160
2161
2162
2163
2164
2165
2166
2167
2168
2169
2170
2171
2172
2173
2174
2175
2176
2177
2178
2179
2180
2181
2182
2183
2184
2185
2186
2187
2188
2189
2190
2191
2192
2193
2194
2195
2196
2197
2198
2199
2200
2201
2202
2203
2204
2205
2206
2207
2208
2209
2210
2211
2212
2213
2214
2215
2216
2217
2218
2219
2220
2221
2222
2223
2224
2225
2226
2227
2228
2229
2230
2231
2232
2233
2234
2235
2236
2237
2238
2239
2240
2241
2242
2243
2244
2245
2246
2247
2248
2249
2250
2251
2252
2253
2254
2255
2256
2257
2258
2259
2260
2261
2262
2263
2264
2265
2266
2267
2268
2269
2270
2271
2272
2273
2274
2275
2276
2277
2278
2279
2280
2281
2282
2283
2284
2285
2286
2287
2288
2289
2290
2291
2292
2293
2294
2295
2296
2297
2298
2299
2300
2301
2302
2303
2304
2305
2306
2307
2308
2309
2310
2311
2312
2313
2314
2315
2316
2317
2318
2319
2320
2321
2322
2323
2324
2325
2326
2327
2328
2329
2330
2331
2332
2333
2334
2335
2336
2337
2338
2339
2340
2341
2342
2343
2344
2345
2346
2347
2348
2349
2350
2351
2352
2353
2354
2355
2356
2357
2358
2359
2360
2361
2362
2363
2364
2365
2366
2367
2368
2369
2370
2371
2372
2373
2374
2375
2376
2377
2378
2379
2380
2381
2382
2383
2384
2385
2386
2387
2388
2389
2390
2391
2392
2393
2394
2395
2396
2397
2398
2399
2400
2401
2402
2403
2404
2405
2406
2407
2408
2409
2410
2411
2412
2413
2414
2415
2416
2417
2418
2419
2420
2421
2422
2423
2424
2425
2426
2427
2428
2429
2430
2431
2432
2433
2434
2435
2436
2437
2438
2439
2440
2441
2442
2443
2444
2445
2446
2447
2448
2449
2450
2451
2452
2453
2454
2455
2456
2457
2458
2459
2460
2461
2462
2463
2464
2465
2466
2467
2468
2469
2470
2471
2472
2473
2474
2475
2476
2477
2478
2479
2480
2481
2482
2483
2484
2485
2486
2487
2488
2489
2490
2491
2492
2493
2494
2495
2496
2497
2498
2499
2500
2501
2502
2503
2504
2505
2506
2507
2508
2509
2510
2511
2512
2513
2514
2515
2516
2517
2518
2519
2520
2521
2522
2523
2524
2525
2526
2527
2528
2529
2530
2531
2532
2533
2534
2535
2536
2537
2538
2539
2540
2541
2542
2543
2544
2545
2546
2547
2548
2549
2550
2551
2552
2553
2554
2555
2556
2557
2558
2559
2560
2561
2562
2563
2564
2565
2566
2567
2568
2569
2570
2571
2572
2573
2574
2575
2576
2577
2578
2579
2580
2581
2582
2583
2584
2585
2586
2587
2588
2589
2590
2591
2592
2593
2594
2595
2596
2597
2598
2599
2600
2601
2602
2603
2604
2605
2606
2607
2608
2609
2610
2611
2612
2613
2614
2615
2616
2617
2618
2619
2620
2621
2622
2623
2624
2625
2626
2627
2628
2629
2630
2631
2632
2633
2634
2635
2636
2637
2638
2639
2640
2641
2642
2643
2644
2645
2646
2647
2648
2649
2650
2651
2652
2653
2654
2655
2656
2657
2658
2659
2660
2661
2662
2663
2664
2665
2666
2667
2668
2669
2670
2671
2672
2673
2674
2675
2676
2677
2678
2679
2680
2681
2682
2683
2684
2685
2686
2687
2688
2689
2690
2691
2692
2693
2694
2695
2696
2697
2698
2699
2700
2701
2702
2703
2704
2705
2706
2707
2708
2709
2710
2711
2712
2713
2714
2715
2716
2717
2718
2719
2720
2721
2722
2723
2724
2725
2726
2727
2728
2729
2730
2731
2732
2733
2734
2735
2736
2737
2738
2739
2740
2741
2742
2743
2744
2745
2746
2747
2748
2749
2750
2751
2752
2753
2754
2755
2756
2757
2758
2759
2760
2761
2762
2763
2764
2765
2766
2767
2768
2769
2770
2771
2772
2773
2774
2775
2776
2777
2778
2779
2780
2781
2782
2783
2784
2785
2786
2787
2788
2789
2790
2791
2792
2793
2794
2795
2796
2797
2798
2799
2800
2801
2802
2803
2804
2805
2806
2807
2808
2809
2810
2811
2812
2813
2814
2815
2816
281

1013	309500-18	Capacitor, 500 pF, 500 volts dc	R-F Cutoff, First Audio Grid	O-D Type 5W	
1014	3046-10	Capacitor, 0.005 μ F, 500 volts dc	I-F AGC Filter	O-D Type 1N	
1015	304500-20	Capacitor, 0.5 pF, 500 volts dc	AVC Filter	O-D Type 12X-6050	830-65034-2
1016	3082-6020	Capacitor, 2 pF, 600 volts dc	Plate Supply Filter	O-D Type 71A-6020	830-65034-5
1017	30410-48	Capacitor, 0.01 μ F, 500 volts dc	Squelch Timing	O-D Type 1D	
1018	30410-48	Capacitor, 0.01 μ F, 500 volts dc	Squelch Timing	O-D Type 1D	
1019	3042-16	Capacitor, 0.002 μ F, 500 volts dc	H-F Cutoff, Second Audio Grid	O-D Type 1N	
1020.1	304100-27	Capacitor (3 x 0.1 μ F), 500 volts dc	Heater By-pass	O-D Type VC-63A	830-65034-4
1020.2			Squelching Voltage Filter		
1020.3			First Audio Plate Filter		
1021	30410-48	Capacitor, 0.01 μ F, 500 volts dc	Second Audio Grid Coupling	O-D Type 1D	
1022	3045-8	Capacitor, 0.005 μ F, 500 volts dc	R-F Detector Second Audio Plate	O-D Type 1W	
1023	30400-1	Special capacitor, 40 pF, 25 volts dc	Second Audio Cathode By-pass	O-D Per drawing	830-65034-1 830-65034-5
1024	3081-6100A	Capacitor, 1 μ F, 600 volts dc	Second Audio Screen By-pass	O-D Type DI-6100	
1025	3082-88A	Capacitor, 2 μ F, 600 volts dc	Plate Supply Filter	IN 288A	
096	3041-13	Capacitor, 0.001 μ F, 500 volts dc	I-F Oscillator Coupling	O-D Type 1W	
*1026	309500-60	Capacitor, 0.0035 μ F, 500 volts dc	I-F Oscillator Coupling	O-D Type 1W	
101	304550	Resistor, 20,000 ohms \pm 10%	R-F Screen Filter	IND EF-1/2	
102	304562	Resistor, 0.25 megohm \pm 10%	Modulator Screen Filter	EC EC-1/2	
103	304724	Resistor, 500 ohms \pm 10%	Modulator Cathode Bias	IND IN-1/2	

Resistors in depot stock.

*Modification during manufacture; see Paragraph 43.

Reference Number	Signal Corps Stock Number	Name and Description of Part	Function	Mr's. Code and Type Number	Contractor's Drawing Number
A. Radio Receiver BG-652-A (continued).					
184	324531	Resistor, 50,000 ohms $\pm 10\%$	Heating Coil Grid Leak	IRC RF-1/2	
185	324500-8	Resistor, 5000 ohms $\pm 10\%$	Heating Coil Plate Filter	IRC RF-1	
186	324550	Resistor, 0.1 megohm $\pm 10\%$	1-P Coupling	IRC RF-1/2	
187	326635-8	Resistor, 30,000 ohms $\pm 10\%$	First 1-P Screen Filter	IRC RF-1	
188	326680-12	Resistor, 30,000 ohms $\pm 10\%$	Second 1-P Screen Filter	IRC RF-2	
189	326690-1	Resistor, 70,000 ohms $\pm 10\%$	Second 1-P Screen Filter	IRC RF-1/2	
189	324525	Resistor, 1,000 ohms $\pm 10\%$	Indicator Screen Filter	IRC RF-1/2	
1910	324532	Resistor, 0.25 megohm $\pm 10\%$	First Audio Grid Coupling	IRC RF-1/2	
1911	324534	Resistor, 1 megohm $\pm 10\%$	First Audio Grid Leak	IRC RF-1/2	
1912	326630-17	Resistor, 2000 ohms $\pm 10\%$	First Audio Cathode Bias	IRC RF-1/2	
1913	324529	Resistor, 10,000 ohms $\pm 10\%$	AVC Filter	IRC RF-1/2	
1914	324568	Resistor, 0.25 megohm $\pm 10\%$	AVC Bias	IRC RF-1/2	
1915	324534	Resistor, 2 megohm $\pm 10\%$	Screening	IRC RF-1/2	
1916	324534	Resistor, 1 megohm $\pm 10\%$	Screening	IRC RF-1/2	
1917	324562	Resistor, 0.25 megohm $\pm 10\%$	Screening Plate Lead	IRC RF-1/2	
1918	324550	Resistor, 0.1 megohm $\pm 10\%$	First Audio Plate	IRC RF-1/2	
1919	324512	Resistor, 2 megohm $\pm 10\%$	Indicator Lamp Screen	IRC RF-1/2	
1920	326630-11	Resistor, 300 ohms $\pm 10\%$	Second Audio Cathode Bias	IRC RF-1	

*Modification during manufacture; see paragraph A5.
 †Available in depot stock.

*1121	326650-7	Resistor, 50,000 ohms $\pm 10\%$	Voltage Divider Shunt	IRC RT-2
1122	326540	Resistor, 50,000 ohms $\pm 10\%$	Phase Series	IRC RT-1/2
1123	326526	Resistor, 5,000 ohms $\pm 10\%$	Second Audio Server Filter	IRC RT-1/2
1124	326605-13	Resistor, 50 ohms $\pm 5\%$	Voltage Dividing Network	IRC RT-1/2
1125	326230-5	Resistor, 2,500 ohms $\pm 5\%$	Voltage Dividing Network	IRC RT-1/2
1126	326120	Resistor, 1,200 ohms $\pm 5\%$	Voltage Dividing Network	IRC RT-1/2
1127	326250-6	Resistor, 2,500 ohms $\pm 5\%$	Voltage Dividing Network	IRC RT-1/2
1128	326250-6	Resistor, 2,500 ohms $\pm 5\%$	Voltage Dividing Network	IRC RT-1/2
1129	326613	Resistor, 15,000 ohms $\pm 5\%$	Voltage Dividing Network	IRC RT-2
1130	324895	Resistor, 5 ohms $\pm 5\%$, 1 in.	Audio Output Dummy Load	W-L Type Z
1131	326568-1	Resistor, 6,800 ohms $\pm 5\%$	Voltage Dividing Network	IRC RT-1
1132	324540	Resistor, 30,000 ohms $\pm 10\%$	Phase Series	IRC RT-1/2
1133	324540	Resistor, 30,000 ohms $\pm 10\%$	Phase Series	IRC RT-1/2
114	2244034/07	Choke (50-1002)	Limiter Cathode Choke	W-3 KS-8712
1151A	224460-6334/71	Filter	First I-P Input	W-E For drawing REL-684032-3
151	329100-194	Capacitor, 100 pF $\pm 5\%$, 500 volts dc Part of Fila	First I-P Grid Coupling	C-D Type 3B
152	5041-22	Capacitor, 0.021 μ F, 500 volts dc Part of Fila	First I-P Grid Filter	C-D Type 1X
153	509450-13	Capacitor, 50 pF $\pm 5\%$, 500 volts dc Part of Fila	Kommutator Plate Filed Tuning	C-D Type 5B
154	509410-5	Capacitor, 10 ± 1 pF, 500 volts dc Part of Fila	Temperature Compensation For 553	Radio Type H550K

*Modification during manufacture: see Paragraph 43.
*Available in depot stock.

Reference Number	Signal Corps Stock Number	Name And Description of Part	Function	Mfr's. Code and Type Number	Contractor's Drawing Number
a. Radio Receiver RS-605-A (continued).					
C25	359010-5	Capacitor, 10 \pm 1 μ mf, 500 volts dc Part of P1A1	Temperature Compensator for C56	Resis Type 6800K	
C56	309050-13	Capacitor, 50 μ mf \pm 5%, 500 volts dc Part of P1A1	First I-F Grid Plate Tuning	C-D Type 52	
C57	3046-10	Capacitor, 0.005 μ f, 500 volts dc Part of P1A1	Modulator Plate Filter	C-D Type 1W	
P51	304950	Resistor, 5.1 megohms \pm 10% Part of P1A1	First I-F Grid Leak	INC SR-1/2	
P52	305643	Resistor, 15,000 ohms \pm 10% Part of P1A1	First I-F Input Filter Termination	INC SR-1/2	
R53	304350	Resistor, 0.1 megohm \pm 10% Part of P1A1	First I-F Grid Filter	INC SR-1/2	
R54	304950	Resistor, 0.1 megohm \pm 10% Part of P1A1	Modulator Plate Filter	INC SR-1/2	
R55	304950	Resistor, 0.1 megohm \pm 10% Part of P1A1	Modulator Plate Filter	INC SR-1/2	
L51	2044-03A/09	Coil Part of P1A1	First I-F Grid Tuning Coupling	WE Per drawing	RS3-68025-1
L52	2044-03A/09	Coil Part of P1A1	Modulator Plate Tuned Coupling	WE Per drawing	RS3-68025-1
4P12A	204450-683A/92	Filter	Second I-F Input	WE Per drawing	RS3-68062-1
C61	309100-12A	Capacitor, 100 μ mf \pm 5%, 500 volts dc Part of P2A1	Second I-F Grid Coupling	C-D Type 52	
C62	3041-22	Capacitor, 0.001 μ f, 500 volts dc Part of P2A1	Second I-F Grid Filter	C-D Type 1W	
C63	309050-13	Capacitor, 50 μ mf \pm 5%, 500 volts dc Part of P2A1	First I-F Plate Fixed Tuning	C-D Type 52	
C64	359010-5	Capacitor, 10 \pm 1 μ mf, 500 volts dc Part of P2A1	Temperature Compensator for C63	Resis Type 6800K	
C65	359010-5	Capacitor, 10 \pm 1 μ mf, 500 volts dc Part of P2A1	Temperature Compensator for C65	Resis Type 6800K	
C66	309050-13	Capacitor, 50 μ mf \pm 5%, 500 volts dc Part of P2A1	Second I-F Grid Fixed Tuning	C-D Type 52	

Available in depot stock.

657	3046-10	Capacitor, 0.006 μ f, 500 volts dc Part of PL2A	First I-P Plate Filter	O-D Type 1W	
861	304550	Resistor, 0.1 megohm \pm 10% Part of PL2A	Second I-P Grid Leak	IRC RT-1/2	
862	305633	Resistor, 47,000 ohms \pm 10% Part of PL2A	Second I-P Input Filter Termination	IRC RT-1/2	
863	304529	Resistor, 10,000 ohms \pm 10% Part of PL2A	Second I-P Grid Filter	IRC RT-1/2	
864	304525	Resistor, 1,000 ohms \pm 10% Part of PL2A	First I-P Plate Filter	IRC RT-1/2	ESL-650055-1
L61	204403A/79	Coil Part of PL2A	Second I-P Grid Tuned Coupling	WE Per Drawing	
L62	204403A/79	Coil Part of PL2A	First I-P Plate Tuned Coupling	WE Per Drawing	ESL-650055-1
PL2A	204460-653A/F3	Filter	Limiter Input Filter	WE Per Drawing	ESL-650082-2
*C71	309100-13	Capacitor, 50 μ af \pm 5% Part of PL3A	Limiter Input Filter	O-D Type 5R	ESL-650082-2
C71	309100-19A	Capacitor, 100 μ af \pm 5%, 500 volts dc Part of PL3A	Limiter Grid Coupling	O-D Type 5R	
C72	3041-22	Capacitor, 0.001 μ f, 500 volts dc Part of PL3A	Limiter Grid Filter	O-D Type 1W	
C73	309050-13	Capacitor, 50 μ af \pm 5%, 500 volts dc Part of PL3A	Second I-P Plate Fixed Tuning	O-D Type 5R	
C74	309010-5	Capacitor, 10 \pm 1 μ af, 500 volts dc Part of PL3A	Temperature Compensator for C73	Grid Type N680K	
C75	309010-5	Capacitor, 10 \pm 1 μ af, 500 volts dc Part of PL3A	Temperature Compensator for C76	Grid Type N680K	
C76	309050-13	Capacitor, 50 μ af \pm 5%, 500 volts dc Part of PL3A	Limiter Grid Fixed Tuning	O-D Type 5R	
C77	3046-10	Capacitor, 0.006 μ f, 300 volts dc Part of PL3A	Second I-P Plate Filter	O-D Type 1W	
*771	304550	Resistor, 0.1 megohm \pm 10% Part of PL3A	Limiter Grid Leak	IRC RT-1/2	
*371	304562	Resistor, 250,000 ohms \pm 10% Part of PL3A	Limiter Grid Leak	IRC RT-1/2	
RT2	305633	Resistor, 47,000 ohms \pm 10% Part of PL3A	Limiter Input Filter Termination	IRC RT-1/2	

*Modification during manufacture; see Paragraph 43.
*Available in depot stock.

Reference Number	Signal Design Stock Number	Name and Designation of Part	Function	Mfr.'s Code and Title Number	Contractor's Drawing Number
8. Radio Receiver SCR-608-A (continued).					
*872	304540	Resistor, 50,000 ohms $\pm 10\%$ Part of FL3A	Limiter Input Filter Termination	INC 22-1/2	
873	324529	Resistor, 10,000 ohms $\pm 10\%$ Part of FL3A	Limiter Grid Filter	INC 22-1/2	
874	324528	Resistor, 10,000 ohms $\pm 10\%$ Part of FL3A	Second I-F Plate Filter	INC 22-1/2	
*874	324528	Resistor, 1,000 ohms $\pm 10\%$ Part of FL3A	Second I-P Plate Filter	INC 22-1/2	
L71	204403A/09	Coil Part of FL3A	Limiter Grid Tuned Coupling	INC For drawing	E80-680855-1
L72	204403A/09	Coil Part of FL3A	Second I-F Plate Tuned Coupling	VE Per drawing	E80-680855-1
*874	204403A/29	Filter	Discriminator Filter Network	VE Per drawing	E80-680850-1
081	309050-9	Capacitor, 250 pF $\pm 10\%$, 500 volts dc Part of FL4	Detector H-F By-pass	C-D Type 3W	
082	3046-10	Capacitor, 0.006 pF, 500 volts dc Part of FL4	Detector Cathode Filter	C-D Type 1V	
083	3046-10	Capacitor, 0.006 pF, 500 volts dc Part of FL4	Limiter Plate Filter	C-D Type 1V	
084	309050-13	Capacitor, 5 ± 0.5 pF, 500 volts dc Part of FL4	Temperature Compensation for Slope Circuit Secondary	Bias Type N660K	
085	309050-13	Capacitor, 50 pF $\pm 5\%$, 500 volts dc Part of FL4	Half of Higgs Circuit Secondary Tuning	C-D Type 5B	
086	309050-13	Capacitor, 50 pF $\pm 5\%$, 500 volts dc Part of FL4	Half of Slope Circuit Secondary Tuning	C-D Type 5B	
087	309025-4	Capacitor, 25 pF $\pm 5\%$, 500 volts dc Part of FL4	Limiter Plate Fixed Tuning	C-D Type 5B	
088	309010-5	Capacitor, 10 ± 1 pF, 500 volts dc Part of FL4	Temperature Compensation for OSF	Bias Type N660K	
881	324670-1	Resistor, 70,000 ohms $\pm 10\%$ Part of FL4	Detector Load	INC 22-1/2	
882	324502	Resistor, 0.25 megohm $\pm 10\%$ Part of FL4	Detector Cathode Bias	INC 22-1/2	

*Modification during manufacture; see Paragraph 43.
 †Available in depot stock.

863	326670-1	Resistor, 70,000 ohms \pm 10% Part of PL4	Detector Load	IRC ST-1/2	830-680634-1
864	324562	Resistor, 0.25 megohm \pm 10% Part of PL4	Detector Cathode Bias	IRC ST-1/2	830-680634-4
865	324525	Resistor, 1,000 ohms \pm 10% Part of PL4	Limiter Plate Filter	IRC ST-1/2	830-680634-1
121	2C4403A/C10	Coil Part of PL4	Detector Input Tuned Coupling	WE Per drawing	
122	2C4403A/C9	Coil Part of PL4	Limiter Plate Tuned Coupling	WE Per drawing	
1402A	2C4450-683A/P4	Coupling Unit	Antenna Coupling	WE Per drawing	
035	32A6-10	Capacitor, 0.006 μ f 500 volts dc Part of L021A	R-F Grid Filter	C-D Type 1M	
837	324562	Resistor, 0.25 megohm \pm 10% Part of L021A	R-F Grid Filter	IRC ST-1/2	
132	2C4450-683A/C11	Coil Part of L021A	Antenna Coupling	WE Per drawing	830-684083-5
1402A	2C4450-683A/P5	Coupling unit	Modulator Input Tuning	WE Per drawing	830-684083-1
036	329010-5	Capacitor, 10 \pm 1 μ f, 500 volts dc Part of L022A	R-F Plate Tuning and Compensation	Erie Type 56HX	
038	329005-13	Capacitor, 5 \pm 0.5 μ f, 500 volts dc Part of L022A	Modulator Grid Tuning and Compensation	Erie Type 56HX	
039	32A6-10	Capacitor, 0.006 μ f, 300 volts dc Part of L022A	R-F Plate Filter	C-D Type 1M	
838	324525	Resistor, 1000 ohms \pm 10% Part of L022A	R-F Plate Filter	IRC ST-1/2	
133	2C4450-683A/C2	Coil Part of L022A	R-F Plate Tuned Coupling	WE Per drawing	830-684083-1
134	2C4450-683A/C2	Coil	Modulator Grid Tuned Coupling	WE Per drawing	830-684083-1
1402A	2C4450-683A/P6	Tuned unit (unswaled)	R-F Oscillator Tuning Unit	WE Per drawing	830-684079-1
*14030	2C4450-683A/P6	Tuned unit (swaled)	R-F Oscillator Tuning Unit	WE Per drawing	830-684079-1
041	305700	Capacitor, 700 μ f \pm 5%, 500 volts dc Part of L023A	Beating Oscillator Series Resistor	C-D Type 2R	

*Available in depot stock.

Reference Number	Signal Corps Stock Number	Name and Description of Part	Function	MF's, Code and Type Number	Contractor's Drawing Number
B. Radio Receiver NO-651-A (continued).					
042	309680-6	Capacitor, 200 \pm 10 μ f, 500 volts dc Part of LC35A	Temperature Compensator for 041	5-15 Type H50M	
043	309100-19A	Capacitor, 100 μ f \pm 5%, 500 volts dc Part of LC35A	Heating Oscillator Grid Blocking	0-2 Type 5A	
*044	—	Capacitor, 80 \pm 1.5 μ f, 500 volts dc Part of LC35A		5-15 Type H150L	
044	309630-3	Capacitor, 30 \pm 1.5 μ f, 500 volts dc Part of LC35A	Heating Oscillator Plate coupling	5-15 Type H080L	
*044	—	Capacitor, 30 \pm 1.5 μ f, 500 volts dc Part of LC35A		Motor Type 5200L	
045	309100-19A	Capacitor, 100 μ f \pm 5%, 500 volts dc Part of LC35A	Oscillator-Modulator Coupling	0-2 Type 5A	
046	309080-1	Capacitor, 20 \pm 1 μ f, 500 volts dc Part of LC35A	Heating Oscillator Plate Temperature Compensator	5-15 Type H600K	
341	324590	Resistor, 0.1 megohm \pm 10%	Modulator Suppressor Grid Leak	IRC RT-1/2	
141	304460-685A/03	Coil Part of LC35A	Heating Oscillator Tuning and Feedback	ME Per drawing	RSC-68408A-1
LC39	304403A/21	Tuned unit	1-P Oscillator Tuning	VE Per drawing	RML-680247-1
091	309050-13	Capacitor, 50 μ f \pm 5%, 500 volts dc Part of LC39	1-P Oscillator Grid Coupling	0-2 Type 5A	
092	30370	Capacitor, 50 \pm 2 μ f, 500 volts dc Part of LC39	1-P Oscillator Plate Mount	5-15 Type H63K	
093	309100-19A	Capacitor, 100 μ f \pm 5%, 500 volts dc Part of LC39	1-P Oscillator Fixed Tuning	0-2 Type 5A	
094	309050-13	Capacitor, 50 μ f \pm 5%, 500 volts dc Part of LC39	1-P Oscillator Plate Coupling	0-2 Type 5A	
R91	324590	Resistor, 0.1 megohm \pm 10%	1-P Oscillator Grid Leak	IRC RT-1/2	
R92	324549	Resistor, 40,000 ohms \pm 10%	1-P Oscillator Plate Load	IRC RT-1/2	
R93	324549	Resistor, 40,000 ohms \pm 10%	1-P Oscillator Plate Load	IRC RT-1/2	

*Modification during manufacture; see Paragraph 43.
Available in depot stock.

101	204403A/114	Coil Part of L004	I-P Oscillator Inductance	VE Per drawing	XSO-680251-2
101	204403A/52	Switch (S757)	Power	RAE Per drawing	XSO-676800-6
102	204403A/52	Switch (S752)	Headset	RAE Per drawing	XSO-676800-6
103	204403A/54	Switch (S752)	Loudspeaker	RAE Per drawing	XSO-676800-23
104	204403A/53	Switch (S757 and S752)	Squatch	RAE Per drawing	XSO-680257-1
105	204403A/52	Switch (S757)	Tuning Oscillator	RAE Per drawing	XSO-676800-6
106	225803-1	Neon lamp	Indicator Lamp	OE Per drawing	XSO-680193-7
107	225900-3	Socket, lamp-mounting	Socket for H1	Deke Per drawing	XSO-680506-1
108	331504	Fuse, 15 amperes	Power Supply	Littell Type 403	
109	33302	Fuse holder	Fuse Holder	Littell No. 1212	
110	33302	Fuse holder	Spare	Littell No. 1212	
111	204403A/75	Part of Jack assembly	Headset	VE Per drawing	XSO-680358-1
112	204403A/73	Part of Jack assembly	Headset	VE Per drawing	XSO-680258-1
113	204403A/72	Jack, socket assembly	Front Pistol Socket Assembly	VE Per drawing	XSO-680352-3
114	6C35	Loudspeaker	Loudspeaker	Jensen Type PM 373 Per drawing	XSO-578545-1
115	227200-1	Potentiometer, 100,000 ohms, taper C	Volume Control	INC Type 05	XSO-680193-1
116	227209	Potentiometer, 200 ohms	Squatch Control	INC Type W	XSO-680193-2
117	204403A/71	Special plug	External Connections	Cannon Per drawing	XSO-677409-25
118	227205	Plug	Dynamotor Plug	Jones Type F-318-A8	

1. Available in depot stock.

Reference Number	Signal Corps Stock Number	Name and Description of Part	Function	Kit's, Code and Type Number	Contractor's Drawing Number
A. Radio Receiver RC-621-A (continued).					
1703	204403A/73	Plug, part of jack assembly	Front Panel Connections	VE Per drawing	ESD-600958-1
171	204403A/73	Audio output transformer (50-1005)	Audio Output	VE	K3-8714
1711	27112	Vacuum tube VT-112	R-F Amplifier	90A (54C7)	
172	27112	Vacuum tube VT-112	Mixer	90A (54C7)	
173	2794	Vacuum tube VT-94	Oscillator	90A (54C5)	
174	27209	Vacuum tube VT-209	I-F Amplifier	90A (12A07)	
175	27209	Vacuum tube VT-209	I-F Amplifier	90A (12A07)	
176	27112	Vacuum tube VT-112	Detector	90A (54C7)	
177	2790	Vacuum tube VT-90	Detector	90A (54C6)	
178	27107A	Vacuum tube VT-107-A	Second Audio Amplifier	90A (64N-37)	
179	27209	Vacuum tube VT-209	AVC and Squelch	90A (6217-07)	
1710	27209	Vacuum tube VT-209	First Audio and Oscillator	90A (6217-07)	
1731- V010	204403A/51	Socket	Socket	United Per drawings	ESL-67815-6 ESL-67815-10
1	204403A/25-1	Push-button tuner assembly (includes 21.4, 21.5, 21.6, 21.7 and 21.8)	Tuning	WT	ES-10059, List 2
1	205494/56/2	Locking assembly, part of push-button tuner assembly, consisting of: Retainer yoke assembly Ods	Tuning	WT	ES-684095-1 ES-684095-2 ES-684095-3 ES-684095-4

Available in drop stock.
Screw tubes furnished as separate item on contract.

†	204403A/25/1	Push button, part of push-button tuner assembly	Tuning	WE	KS-10099 List 2
†	204403A/01	Front panel guard	Front Panel Protection	WE	ESG-678546-2
†	204403A/01	Binding post A	Antenna Connection	WE	ESG-678764-16
†	204403A/02	Binding post B	Ground Connection	WE	ESG-678764-20
†	204403A/23	Bracket, hold-down	Securing Receiver	WE	ESG-680129-2
†	204403A/41	Shielded wire assembly	Antenna Jack Connections	WE	ESG-680492-1
†	204403A/42	Shielded wire assembly	Antenna Post Connections	WE	ESG-680492-2
†	204460-683A/11	Knob	Volume Control Knob	WE	ESG-680582-3
†	204460-683A/02	Dust cover	Cover	WE	ESG-678348-10
†	205604A/02	Shakeproof fastener	Securing Cover	WE	ESG-677334-11
†	204403A/21/1	Special screw	Mounting PSI	WE	ESG-680841-2
†	204403A/03	Insulator	Mounting Binding Posts A and B	WE	ESG-678672-1
†	204403A/01	Beadle	Front Panel	WE	ESG-685720-1
†	204403A/01	Warning strip	Mounting Small Parts	WE	ESG-673251-1
†	205005/01	Hardware for Radio Receiver RC-683-A		WE	ESG-685506-1
†	28506/1	Wire for Radio Receiver RC-683-A			
b. Radio Transmitter RC-683-A.					
†	20659C-683A	Radio Transmitter RC-683-A			
†	20A3-6	Capacitor, 0.003 μ f, 800 volts dc	First R-P Screen By-pass	C-E Type 1WPS	
†	20A100-21	Capacitor, 0.0001 μ f \pm 5%, 800 volts dc	First R-P Plate Coupling	C-B Type 1WPS	

† Available in depot stock.

Reference Number	Signal Corps Stock Number	Name and Description of Part	Function	Contractor's Drawing Number
10104	309500-20	Capacitor, 0.0005 μ f, 800 volts dc	Oscillator Plate By-pass	C-D Type 1W38
10105	309015-2	Capacitor, 15 μ af, 500 volts dc	Oscillator Plate Tuning	WE Type 5500K
01106	See Note	Variable air capacitor, 350 μ af, Part of push-button tuner capacitor assembly	Rectifier Grid Tuning	WE
10108	309500-20	Capacitor, 0.0005 μ f, 800 volts dc	Rectifier Grid Coupling	C-D Type 1W38
10109	30A3-6	Capacitor, 0.003 μ f, 800 volts dc	Rectifier Screen By-pass	C-D Type 1W38
10111	30A3-6	Capacitor, 0.003 μ f, 800 volts dc	Tripler Plate By-pass	C-D Type 1W38
10112	30A3-6	Capacitor, 0.003 μ f, 800 volts dc	Doubler Grid By-pass	C-D Type 1W38
01113	See Note	Variable air capacitor, 60 μ af, Part of push-button tuner capacitor assembly	Tripler Plate Tuning	WE
10114	See Note	Variable air capacitor, 80 μ af, Part of push-button tuner capacitor assembly	Tripler Plate Trimmer	WE
01115	See Note	Variable air capacitor, 60 μ af, Part of push-button tuner capacitor assembly	Doubler Grid Tuning	WE
10116	See Note	Variable air capacitor, 80 μ af, Part of push-button tuner capacitor assembly	Doubler Grid Trimmer	WE
10117	30A3-6	Capacitor, 0.003 μ f, 800 volts dc	Doubler Screen By-pass	C-D Type 1W38
10118	30A3-6	Capacitor, 0.003 μ f, 800 volts dc	Doubler Plate By-pass	C-D Type 1W38
01119	See Note	Variable air capacitor, 80 μ af, Part of push-button tuner capacitor assembly	Doubler Plate Tuning	WE
10120	See Note	Variable air capacitor, 80 μ af, Part of push-button tuner capacitor assembly	Doubler Plate Trimmer	WE

NOTE: Connections C106, C117, C118, C119, C120, C121, C122, C123, C124, C125, C126, C127, C128-C129 inclusive, furnished as part of tumor assembly, page 177.
Available in decont stock.

10121	30A3-6	Capacitor, 0.003 μ f, 500 volts dc	Doubler Plate Coupling	C-D Type 1W5	330-680242-2
10122	30A3-6	Capacitor, 0.003 μ f, 500 volts dc	Power Amplifier Screen By-pass	C-D Type 1W5	330-680242-3
10123	30A10-10	Capacitor, 0.01 μ f, 350 volts dc	Doubler Filament By-pass	C-D Type 1D	330-680242-2
10124	30A2-34	Capacitor, 0.008 μ f, 1,200 volts dc	Power Amplifier Plate	C-D Type A	330-680242-2
10125	See Note, page 168	Variable air capacitor, 60 μ f Part of push-button tuner assembly	Power Amplifier Tuning	VE	330-680242-2
10126	See Note, page 168	Variable air capacitor, 20 μ f Part of push-button tuner assembly	Power Amplifier Trimmer	VE	330-680242-2
10127 to 10130 incl.	See Note, page 168	Variable air capacitor, 100 μ f Part of push-button tuner assembly	Antenna Tuning	VE	330-680242-2
10137	30A50C-27	Capacitor, 0.5 μ f, 600 volts dc	First Audio Grid By-pass	C-D Type DNR-6050	330-680242-3
10138.1 } 10138.2 }	30A10C-29	Capacitor, 600 volts dc Two sections, each 0.1 μ f	Carbon Microphone Coupling	C-D Type DNR-6011	330-680242-3
10139	30A50C-27	Capacitor, 0.5 μ f, 600 volts dc	First Audio Screen By-pass	C-D Type DNR-6050	330-680242-2
10140	30C194A/06	Electrolytic capacitors, 30 μ f 500 volts dc	Carbon Microphone Filter	Mallory Type 8F	330-680242-2
10141	30A50C-27	Capacitor, 0.5 μ f, 600 volts dc	First Audio Plate Coupling	C-D Type DNR-6050	330-680242-2
10142.1 } 10142.2 }	30A10C-28	Capacitor, 600 volts dc Two sections, each 0.1 μ f	Second Audio Grid By-pass	C-D Type DNR-6011	330-680242-3
10143	30A50C-27	Capacitor, 0.5 μ f, 600 volts dc	First Audio Plate By-pass	C-D Type DNR-6011	330-680242-3
10145	30B2-21	Capacitor, 2 μ f, 1,000 volts dc	Second Audio Screen By-pass	C-D Type DNR-6050	330-680242-2
10146	30A3-6	Capacitor, 0.003 μ f, 250 volts dc	Plate Supply Filter	C-D Type 1A 10020	330-680242-2
10147	30A175	Capacitor, 175 μ f \pm 3%, 500 volts dc	Oscillator Screen By-pass	C-D Type 1W5	330-680242-2
*10147	30A175-5	Capacitor, 175 μ f \pm 3%, 500 volts dc	First R-F Plate Padding	C-D Type 1A	330-680242-2
			First R-P Plate Padding	Autar Type K100	330-680242-2

*Modification during manufacture; see Paragraph 45.
Unavailable in depot stock.

Reference Number	Signal Corps Stock Number	Name and Description of Part	Function	Mfr's. Code and Type Number	Contractor's Drawing Number
b. Radio Transmitter RC-691-A (continued).					
†0118	30A3-6	Capacitor, 0.003 μ f, 800 volts dc	Power Amplifier Grid By-pass	C-D Type 1WPS	
†0119	30A1-21	Capacitor, 0.001 μ f, 1,200 volts dc	Power Amplifier Plate Coupling	C-D Type 4	
†0150	30A1-72	Capacitor, 0.001 μ f, 800 volts dc	Oscillator Plate Coupling	C-D Type 1WPS	
†0151	309050-53	Capacitor, 0.00005 μ f \pm 5%, 800 volts dc	Oscillator Grid	C-D Type 5WPS	
†0152	See Note, page 168	Variable air capacitor, 60 μ f Part of push-button tuner capacitor assembly	Rectifier Plate Tuning	WE	
†0153	See Note, page 168	Variable air capacitor, 20 μ f Part of push-button tuner capacitor assembly	Rectifier Plate Trimmer	WE	
†0154	30A3-6	Capacitor, 0.003 μ f, 800 volts dc	Rectifier Plate By-pass	C-D Type 1WPS	
†0155	30A3-6	Capacitor, 0.003 μ f, 800 volts dc	Tripler Grid By-pass	C-D Type 1WPS	
†0156	See Note, page 168	Variable air capacitor, 60 μ f Part of push-button tuner capacitor assembly	Tripler Grid Tuning	WE	
†0157	See Note, page 168	Variable air capacitor, 20 μ f Part of push-button tuner capacitor assembly	Tripler Grid Trimmer	WE	
†0158	30A3-6	Capacitor, 0.003 μ f, 800 volts dc	Tripler Screen By-pass	C-D Type 1WPS	
†0159	30A10-48	Capacitor, 0.01 μ f, 300 volts dc	Tripler Filament By-pass	C-D Type 1D	
†0161	309100-70	Capacitor, 0.0001 μ f, 800 volts dc	Transmission Line Series	C-D Type 5WPS	
†0162	306494A/05	Electrolytic capacitor, 4 μ f, 50 volts dc	Dynamometer Relay Filter	C-D Type AVL	ESG-6/8067-5
†0164	30A3-6	Capacitor, 0.003 μ f, 1,000 volts dc	Tripler Plate By-pass	C-D Type 1WPS	
†0101	304550	Resistor, 100,000 ohms \pm 10%	Oscillator Grid	IND RT-1/2	

*Modification during manufacture; see Paragraph 43
available in depot stock.

R102	305410-2	Resistor, 2 in., 1,000 ohms \pm 10%	High Voltage Reducing	W-1 Type 1
R102	305566A7	Resistor, 2 in., 667 ohms \pm 10%	High Voltage Reducing	W-1 Type A
R103	306785-5	Resistor, 250,000 ohms \pm 10%	First R-F Screen	IRC ST-1
R104	306670-1	Resistor, 70,000 ohms \pm 10%	Rectifier Grid	IRC ST-1/2
R105	306431	Resistor, 50,000 ohms \pm 10%	Rectifier Screen	IRC ST-1/2
R106	306010-2	Resistor, 100 ohms \pm 10%	First R-F Grid Metering	IRC ST-1/2
R107	309340	Resistor, 30,000 ohms \pm 10%	Doubler Grid	IRC ST-1/2
R107	306630-21	Resistor, 30,000 ohms \pm 10%	Doubler Grid	A-8 CS-1
R108	306003-13	Resistor, 30 ohms \pm 5%	Doubler Grid Metering	IRC ST-1/2
R109	306675-10	Resistor, 75,000 ohms \pm 10%	Doubler Screen	IRC ST-2
R110	304525	Resistor, 1,000 ohms \pm 10%	Rectifier Grid Metering	IRC ST-1/2
R111	306615-14	Resistor, 15,000 ohms \pm 10%	Amplifier Grid	IRC ST-1
R111	306630-6	Resistor, 30,000 ohms \pm 10%	Amplifier Grid	IRC ST-1
R112	306001-2	Resistor, 10 ohms \pm 10%	Amplifier Grid Metering	IRC ST-1/2
R113	304801-1	Resistor, 1-3/4 in., 1.0 ohm \pm 5%	Filament	W-1 Type 2
R114	306630-7	Resistor, 30,000 ohms \pm 10%	Amplifier Screen	IRC ST-2
R115	304550	Resistor, 100,000 ohms \pm 10%	First Audio Grid Loading	IRC ST-1/2
R116	306630-7	Resistor, 30,000 ohms \pm 10%	Amplifier Screen	IRC ST-2
R117	304531	Resistor, 50,000 ohms \pm 10%	First Audio Grid Filter	IRC ST-1/2

*Modification during manufacture; see Paragraph 43.
 *Available in depot stock.

Reference Number	Signal Corps Stock Number	Name and Description of Parts	Function	Mfr.'s. Code and Type Number	Contractor's Drawing Number
b. Radio Transmitter RC-684-A (continued).					
R118	325630-7	Resistor, 36,000 ohms $\pm 10\%$	Oscillator Plate	INC R7-2	
*R118	325700-12	Resistor, 100,000 ohms $\pm 10\%$	Oscillator Plate	INC R7-2	
R119	325130-1	Resistor, 1,200 ohms $\pm 10\%$	Rectifier Plate	INC P-1/2	
*R119	325130-8	Resistor, 1,200 ohms $\pm 10\%$	Rectifier Plate	INC R7-1/2	
R120	325020-9	Resistor, 200 ohms $\pm 10\%$	Carbon Microphone Service	INC SM-1	
R121	325010-18	Resistor, 100 ohms $\pm 10\%$	Carbon Microphone Filter	INC SM-1/2	
R122	325725-5	Resistor, 250,000 ohms $\pm 10\%$	First Audio Screen	INC ES-1	
R123	325610-11	Resistor, 10,000 ohms $\pm 10\%$	First Audio Plate Filter	INC R6-1	
R124	325593	Resistor, 10,000 ohms $\pm 10\%$	Second Audio Grid Filter	INC R6-1/2	
R125	325528	Resistor, 5,000 ohms $\pm 10\%$	Second Audio Grid	INC R6-1/2	
R126	325675-10	Resistor, 75,000 ohms $\pm 10\%$	Second Audio Screen	INC R6-2	
R127	323801-1	Resistor, 1-3/4 in., 1.0 ohms $\pm 5\%$	Filament	V-L Type X	
R128	323590	Resistor, 10,000 ohms $\pm 10\%$	Slidegate Fixed	INC R6-1/2	
R129	323450-4	Resistor, 2 in., 5,000 ohms $\pm 10\%$	Bias	V-L Type A	
R130	323900-1	Resistor, 2-3/4 in., 100 ohms $\pm 10\%$	Bias	V-L Type X	
R131	323812	Resistor, 2 in., 12 ohms $\pm 5\%$	Filament Supply Series	V-L Type A	
R132	323812	Resistor, 2 in., 12 ohms $\pm 5\%$	Filament Supply Series	V-L Type A	

*Modification during manufacture; see Paragraph 43, available in depot stock.

TR133	324880	Resistor, 1-3/4 in., 50 ohms $\pm 10\%$	Dynamotor Relay Series	V-L Type E
TR134	324940	Resistor, 30,000 ohms $\pm 10\%$	Plate Current Metering	INC ST-1/2
TR135	324890	Resistor, 1-3/4 in., 30 ohms $\pm 10\%$	Antenna and Disabling Relays Series	V-L Type E
TR136	324940	Resistor, 30,000 ohms $\pm 10\%$	First Audio Screen Shunt	INC ST-1/2
TR137	326010-8	Resistor, 100 ohms $\pm 10\%$	Motor Series	A-2 ST-1/2
TR138	324931	Resistor, 50,000 ohms $\pm 10\%$	Oscillator Screen	INC ST-1/2
TR139	324950	Resistor, 100,000 ohms $\pm 10\%$	First R-P Grid	INC ST-1/2
TR140	324812	Resistor, 2 in., 12 ohms $\pm 5\%$	Pilament Supply Series	V-L Type A
TR141	324812	Resistor, 2 in., 12 ohms $\pm 5\%$	Pilament Supply Series	V-L Type A
TR142	326718-1	Resistor, 100,000 ohms $\pm 10\%$	Rectifier Screen Shunt	INC ST-1
TR143	326010-18	Resistor, 100 ohms $\pm 10\%$	Tripler Grid Metering	INC ST-1/2
TR144	324950	Resistor, 100,000 ohms $\pm 10\%$	Tripler Grid Leak	INC ST-1/2
TR145	326650-7	Resistor, 30,000 ohms $\pm 10\%$	Tripler Screen	INC ST-2
TR147	3259647	Resistor, 2 in., 667 ohms $\pm 10\%$	High Voltage Reducing	V-L Type A
TR149	326005-9	Resistor, 50 ohms $\pm 10\%$ with L117	Oscillator Grid Anti-Drag	INC ST-1/2 Per Drawing
TR151	326608	Resistor, 100,000 ohms $\pm 10\%$	First Audio Plate	INC ST-1
TR153	325998-1	Resistor, 8.3 ohms $\pm 10\%$	Heater for Crystal Oven	INC MX-5
TR154	325998-1	Resistor, 8.3 ohms $\pm 10\%$	Heater for Crystal Oven	INC MX-5

Available in depot stock.

Reference Number	Signal Corps Stock Number	Name and Description of Part	Function	Mfr's. Code and Type Number	Contractor's Drawing Number
b. Radio Transmitter SC-608-A (continued).					
†R155	384950	Resistor, 100,000 ohms ± 10%	Antenna Station Leak	IRC RT-1/2	
†R156	386003-4	Resistor, 30 ohms ± 10%	A-F Load	IRC RM-1	
†R157	386030-5	Resistor, 300 ohms ± 10%	Tripler Plate Filter	IRC RW-1	
*†R157	386030-11	Resistor, 300 ohms ± 10%	Tripler Plate Filter	IRC RM-1	
†R158	386005-9	Resistor, 50 ohms ± 10% with L122	Power Amplifier Grid Anti-Slug	IRC P-1/2	E50-680330-2
				Per Drawing	
†R159	324608	Resistor, 100,000 ohms ± 10%	Doubler Screen Shunt	IRC RC-1	
†R160	385365-7	Resistor, 2 in., 667 ohms ± 10%	High Voltage Reducing	M-L Type A	
†R161	386630-8	Resistor, 50,000 ohms ± 10%	Amplifier Grid	IRC RT-1	
†R162	386700-12	Resistor, 100,000 ohms ± 10%	Oscillator Plate	IRC RT-2	
†R163	386700-12	Resistor, 100,000 ohms ± 10%	Oscillator Plate	IRC RT-2	
†P101	22208-3	Potentiometer, 50,000 ohms	Slidecose Control	IRC ST-2	E50-680243-6
†L101	266494A/08	Coil, 3 millihenries, dualateral	First R-F Plate Choke	IRC Type CP	
†L102	266494A/09	Coil, 1 millihenry, dualateral	Oscillator Plate	Per Drawing	E50-680243-3
†L103A	266530-684A/010	Coil, 0.36 millihenry, dualateral	First R-F Plate Tuning	Per Drawing	E50-680243-4
†L104	266494A/011	Retardation coil (SC-1203)	Modulation	Per Drawing	E50-690077-2
†L105A	266530-684A/012	Coil, 0.36 millihenry, dualateral	Second Audio R-F Choke	Per Drawing	E50-690077-3

*Modification during manufacture; see Paragraph 43.
 †Available in depot stock.

†1106	206530-684A/013	Coil, close-wound solenoid	Tripier Plate Tuning	VE Per drawing	E80-684453-1
†1107	206530-684A/013	Coil, close-wound solenoid	Doubler Grid Tuning	VE Per drawing	E80-684453-1
†1108	206530-684A/014	Coil, close-wound solenoid	Doubler Plate Tuning	VE Per drawing	E80-684453-2
†1110	206530-684A/015	Coil, space-wound solenoid	Amplifier Output Tuning	VE Per drawing	E80-684455-1
†1111	206530-684A/015	Coil, space-wound solenoid	Antenna Coupling	VE Per drawing	E80-684455-1
†1117	206494A/016	Coil, wound on R149	Oscillator Grid Anti-Sing	VE Per drawing	E80-680730-2
†1118	206530-684A/017	Coil, close-wound solenoid	Tripier Grid Tuning	VE Per drawing	E80-684453-3
†1119	206530-684A/017	Coil, close-wound solenoid	Rectifier Plate Tuning	VE Per drawing	E80-684453-3
†1120	206530-684A/01	Coil, 21 chokes	Power Amplifier Plate Choke	Omalle	
†1121	206530-684A/01	Coil, 21 chokes	Power Amplifier Grid Choke	Omalle	
†1122	206494A/016	Coil, wound on R158	Power Amplifier Grid Anti-Sing	VE Per drawing	E80-680390-2
†1201	206494A/02	Audio input transformer (31-1005)	Microphone Input	VE E8-8715	
†1202	206494A/03	Audio output transformer (30-1006)	Audio Output	VE E8-8715	
†1203	206494A/02	Relay (coil resistance, 44 ohms \pm 5%)	Antenna Switching	Allied Per drawing	E80-681226-1
†1204	206494A/03	Relay (coil resistance, 37 ohms; min. 75 ohms, max. 84 ohms)	Dynamotor Starting	Allied Per drawing	E80-680390-1
†1205	206494A/05	Relay (coil resistance, 90 ohms)	Receiver Flashing	Allied Per drawing	E80-677080-3
†1201 to †1210 incl.	—	Switch (†1277), part of push-button tuner assembly	Quartz Plate Selector		
†1211 to †1280 incl.	—	Switch (†1277), part of push-button tuner assembly	Antenna Capacitor Selector		
†1212	206494A/03	Toggle switch (†1277)	Panel Meter	HAE Per drawing	E80-676800-10
†1222	206494A/03	Toggle switch (†1277)	Receiver Tune	HAE Per drawing	E80-676800-10
†1224	206494A/04	Toggle switch (†1277)	Power Supply	HAE Per drawing	E80-676800-21
†1225	206494A/05	Switch, with slotted shaft 1/2 in. long	Circuit Test	Malloy Type 12867	E80-680390-3

†Available in depot stock.

‡See tuner assembly, page 177.

Reference Number	Signal Corps Stock Number	Name and Description of Part	Function	Mfr's. Code and Type Number	Contractor's Drawing Number
b. Radio Transmitter SC-684-A (continued).					
1F101	32595-2	Fuse, 1/2 ampere	High Voltage	Littell Type 440	
1F101	32582	Fuse post	Fuse Holder	Littell Catalog No. 1212	
1F102	32582	Fuse post	Spare Fuse Holder	Littell Catalog No. 1212	
1J101	206494A/81	Jack, 4-contact connector	Dynaflex Microphone	Asphenoil Per drawing	ES0-68035-3
1J102	225575	Jack, with nickel-plated sleeve	Carbon Microphone	VE 2492	
1P0103	206494A/72	Plug, 1/16, eight-contact plug	Dynamotor Plug	Form P-468-AB	
1P0104	206494A/72	Plug, 1/16, eight-contact plug	Dynamotor	Form P-468-AB	
1E101	225895	Lamp bulb, 28 volts, 0.17 ampere	Pilot Light	GE Mazda T 1-3/4 651 Base	ES0-68033-7
1E101	225990-2	Lamp mounting	Socket for Pilot Lamp	Deke Per drawing	ES0-68033-5
1M101	3P531-7	Meter	Tuning and Antenna Current	Weston Model No. 507 Per drawing	ES0-680241-1
1T101	3P910-7/1	Thermocouple, 120 ma. radio frequency	Antenna Current	Weston Per drawing	ES0-680241-7
1T101	229189	Thermostat	Oven Control	Spencer Per drawing	ES0-680302-7
1P0101	206494A/91	Plug	External Connections	Cannon Per drawing	ES0-677459-19
1Y101	2T154	Vacuum tube, VT-154	First R-F Amplifier	SGA (1519)	
1Y102	2T154	Vacuum tube, VT-154	R-F Rectifier	MCA (1619)	
1Y103	2T154	Vacuum tube, VT-154	Doubler	MCA (1619)	

Available in depot stock.
Spare tubes furnished as separate item on contract.

Reference Number	Part Name	Base and Description of Part	Function	Mfg.'s Code and Type Number	Contractor's Drawing Number
1	205494B2	Binding post C	Ground Connection	VE	200-670754-19
1	205494B3	Hold-down screw (incl. hold-down cap and spring)	Securing Radio Transmitter	VE	200-678574-1
1	205494B13	Hold-down spacer	Securing Radio Transmitter	VE	200-678574-3
1	205494B22	Cable assembly	Coaxial Cable from P2101 to Binding Post A and B101	VE	200-680532-2
1	205494B23	Cable assembly	Coaxial Cable from B101 to Binding Post A	VE	200-680741-12
1	205494B1	Handle	Handle	VE	200-678672-7
1	205530-684/P3	Mounting plate	Restoration and Separator Mounting	VE	200-688838-3
1	205530-684/P4	Mounting plate	Mounting B114 and B116	VE	200-690077-4
1	205530-684/P5	Mounting plate	Mounting B112	VE	200-686573-1
1	205494B5	Mounting plate	Mounting B110 and B113	VE	200-680240-6
1	205494B7	Plate	Cover Plate (B111-B120 Incl.)	VE	200-680077-1
1	205494B24	Cover	Crystal Compartment Cover	VE	200-680353-1
1	205494B25	Cover	Bottom Cover	VE	200-680662-1
1	205530-684/P3	Cover	Top Cover	VE	200-679429-2
1	205494B127	Cover	Back Cover	VE	200-680274-1
1	205494B110	Crystal socket strip	Socket	VE	200-680741-2
1	205494B1	Fastener	Crystal Drawer	DEMS	
1	205494B2	Fastener	Top, Bottom and Back Cover	DEMS	

Available in demt stock.

†	20619AA/821	Tube lock spacer assembly	Spacer	VE Per drawing	200-5725A-B
†	20619AA/830	Tube clamp	Tube clamp	VE Per drawing	200-00056-3
†	20619AA/839	Crystal driver assembly	Crystal storage	WE Per drawing	200-680370-1
†	20619AA/871/1	Mounting screw	Mounting P0101	WE Per drawing	200-680306-3
†	20619AA/88	Insulator	Crystal Socket Stud (short insulator)	WE Per drawing	200-680323-3
†	20619AA/83	Insulator	Crystal Socket Stud (long insulator)	WE Per drawing	200-680323-9
†	20619AA/84	Insulator	Antenna Binding Post	WE Per drawing	200-675721-6
†	20619AA/85	Insulator	Ground Binding Post	WE Per drawing	200-680381-2
†	20619AA/838	Cable clamp	Securing Cable Wiring	Insulated box	
†	20619AA/839	Clamp assembly	Tube Clamp Assembly	VE Per drawing	200-680306-3
†	20619AA/831	Radio connector	Plate of V104	VE Per drawing	200-680347-1
†	20619AA/812	Spring	Crystal driver	VE Per drawing	200-680363-1
†	20619AA/83	Thermal plug bracket		Thermal A2.1.03	
†	20619AA/81	Hardware for Radio Transmitter BC-654-A			
†	20619AA/82	Wire for Radio Transmitter BC-654-A			
†	20619AA/83	Frequency Control	Frequency Control	VE	200-680130

6. Crystal Units.

2-150243 crystal units
W.A. Signal Corps (soldiers PC-241-A,
for channels 210-299 in the 27.0 to
30.9-mc range)

† Available in depot stock.

Reference Number	Signal Corps Stock Number	Name and Description of Part	Function	Mfr's. Code and Type Number	Contractor's Drawing Number
d. Mounting PT-237-(*).					
1401	226721-2370	Mounting PT-237-(*)		C-2	
	304100-20	Capacitor, 0.0001 pf, 500 volts dc	Radio Receiver Transmission-Line Compensator	Type 5V	
1401	226721-237A/81	Receptacle	Radio Receiver A Connection	Common	330-677409-8
1402	226721-237A/81	Receptacle	Radio Receiver B Connection	Common	330-677409-8
1403	226721-237A/82	Receptacle	Transmitter Connection	Common	330-677409-7
1404	226721-237A/82	Terminal	Transmitter Antenna	MS	330-678764-17
1405	226721-237A/71	Terminal	Radio Receiver Antenna	MS	330-678764-18
1	221880	Burton	Cover for United Cable Openings	United No. 46157	
	228500	Vibro-insulator shock mounting	Shock Absorber	UNR	330-680179-1
1401	323365B	Fuse, 75 amperes	Battery Fuse	MS 608	
1401	226721-237A/71	Fuse mounting (part of plate assembly) (incl. 32401)	Mounting Plate	MS	330-680163-1
1401	226721-237A/71	Terminal strip (part of plate assembly) (incl. 32401)	Mounting Plate	MS	330-680163-1
1	223014	Ground Strap	Flexible Grounding Strap	MS	330-680165-5
	205494/24	Insulator	Antenna Binding Post Bushings	MS	330-678721-6
	614905-9-242	Mounting screw, 5/16-24x9/16 hex. head-iron cap mounting screw	Sensing Mounting to Vehicle		
	614905-22-242	Mounting screw, 5/16-24x1-3/8 hex. head-iron cap mounting screw	Securing Mounting to Vehicle		
	613505-24	Mounting nut, 5/16-24 elastic stop mounting nut	Securing Mounting to Vehicle		

* Available in depot stock.

61495-12.342	5/16-24x3/4 hex. head-iron cap mounting screw	Securing Mounting to Vehicle		
6171005	5/16x9/16x1/8 steel mounting spring lock washer	Securing Mounting to Vehicle		
226400	Cable clamp	Cable Clamp	226400	230-680340-1
226418	Signal Corps Cord CO-278 (8 Feet long)	Battery Connections		
226721-237A/01	Cover	Covers for Mounted Receptacles	VR Per drawing	230-680341-1
226721-237A/05	Coaxial cable	Long Coaxial Cable	VR Per drawing	230-680341-5
226721-237A/06	Coaxial cable	Short Coaxial Cable	VR Per drawing	230-680341-6
226721-237A/08	Cover	Cover for Connector Assembly	VR Per drawing	230-680341-9
226721-237A/011	Connector assembly	T-Shaped Connector	VR Per drawing	230-680341-4
226721-237A/012	Connector assembly	L-Shaped Connector	VR Per drawing	230-680341-2
226721-237A/03	Rear guide and fastener *	Dual Cable Clamp	VR	230-680341-4
226721-237A/02	Front fastener	Interphone Cable	VR Per drawing	230-680341-8
226721-237A/07	Clamp	Cabled Wiring Clamp	VR Per drawing	230-680341-2
226721-237A/08	Clamp	Rear Cover	VR Per drawing	230-680341-1
226721-237A/09	Clamp	End Cover	VR Per drawing	230-680341-3
226721-237A/03	Cover	Door	Data	
226721-237A/04	Cover			
226721-237A/01	Fastener			

*. Remote Control Unit RW-29-D.

For the Table of Replaceable Parts for this unit, see Technical Manual TM 11-308.

*Available in depot stock.

Reference Number	Signal Corps Stock Number	Name and Description of Part	Function	Mfr's. Code and Type Number	Contractor's Drawing Number
C. Dynamotor TM-32-4 (Transmitter, 12-Volt).					
1W501	3H1635D	Dynamotor	High-Voltage Supply, with Jams to Make 12-Volt Circuit Changes	ND Per drawing	KD-5581, List 1
C501	3D9500-2	Capacitor, 0.015 μ f, 800 volts dc	R-P By-pass	C-D Type 1W7	
*C501	3XA3-7	Capacitor, 0.002 μ f, 500 volts dc	R-P By-pass	C-D Type 1W7	
C502	3D9500-2	Capacitor, 0.003 μ f, 800 volts dc	R-P By-pass	C-D Type 1W7	
*C502	3XA3-7	Capacitor, 0.002 μ f, 500 volts dc	R-P By-pass	C-D Type 1W7	
†J501	3H1635A/A1	Receptacle	Dynamotor Connection and 12-Volt Circuit Changes	Jones 38-8-AB	Part of KD-5581, List 1, Item 3
†J502	3H1635A/R1	Receptacle		Jones 38-8-AB	
†	3H1635A/B4	Low-voltage dynamotor brushes	Dynamotor Input	WE	
†	3H1635A/B5	High-voltage dynamotor brushes	Dynamotor Output	WE	
†	3H1635A/A1	Dynamotor armature and bearings		WE	
†	3H1635A/B2	Dynamotor bearings		WE	
†	3H1635A/B27	End bell		WE	
†	3H1635A/G1	Stator		WE Per drawing	KD-5581, List 1 Detail 4
†	50670	Laminant, 1/2-lb. em.			
†	624519	Rubber grommets			

*Modification during manufacture; see Paragraph 43.
 †Available in depot stock.
 ‡These parts formerly furnished as spares. Present spare parts list calls for complete dynamotor unit as a spare instead of these parts.

G. Dynamotor JM-37-1* (Transmitter, 24-Volt) (not furnished on this order; listed for information only).

Nomenclature	Part Number	Description	Quantity	Remarks	Drawing	List
0501	3M1637D	Dynamotor assembly	1	High-voltage supply, with Jack to Make 24-Volt Circuit Changes	Per drawing	KB-27A, List 2
0501	3M9300-2	Capacitor, 0.003 μ f, 800 volts dc	1	R-F By-pass	C-D Type 1MP	
*0501	3M93-7	Capacitor, 0.002 μ f, 800 volts dc	1	R-F By-pass	C-E Type 1MP	
0502	3M9302-2	Capacitor, 0.003 μ f, 800 volts dc	1	R-F By-pass	C-E Type 1VP	
*0502	3M93-7	Capacitor, 0.002 μ f, 800 volts dc	1	R-F By-pass	C-D Type 1VP	
3601	3M1639A/1	Resistor, 100 ohms	1	Dynamotor Connection and 24-Volt Circuit Changes	36-5-AB	
3602	3M1639A/1	Resistor, 100 ohms	1	Dynamotor Connection and 24-Volt Circuit Changes	36-5-AB	
3603	3M1639A/1	Low-voltage dynamotor brushes	1	Dynamotor Input	36-5-AB	
3604	3M1639A/1	High-voltage dynamotor brushes	1	Dynamotor Output	36-5-AB	
3605	3M1639A/1	Dynamotor armature and bearings	1			
3606	3M1639A/1	Dynamotor bearings	1			
3607	3M1639A/1	End bell	1			
3608	3M1639A/1	Screw	1			
3609	3M1639A/1	Lubricant, 1/2-lb. can	1			
3610	3M1639A/1	Rubber grommet	1			
3611	3M1639A/1	Dynamotor assembly	1	High-voltage supply, with Jack to Make 12-Volt Circuit Changes	Per drawing	KB-27A, List 1
0701	3M95-13	Capacitor, 0.005 μ f, 800 volts dc	1	R-F By-pass	C-D Type 3MP	

*Modification during manufacture; see Paragraph 43.

Quantities in depot stock. Parts were recently furnished as spares. The present spare parts list calls for a complete dynamotor unit as a spare instead of these parts.

Reference Number	Signal Corps Stock Number	Mean and Description of Part	Function	Mr.'s. Code and Type Number	Contractor's Drawing Number
B. Dynamotor IM-34-(1), Receiver, 12-Volt (Continued).					
*1701	XMA3-24	Capacitor, 0.003 μ F, 2,000 volts dc	R-F By-pass	C-D Type 3MP	
1702	XMA3-13	Capacitor, 0.005 μ F, 800 volts dc	R-F By-pass	C-D Type 3MP	
*1702	XMA3-24	Capacitor, 0.003 μ F, 1,000 volts dc	R-F By-pass	C-D Type 3MP	
1703	XMA3-13	Capacitor, 0.005 μ F, 800 volts dc	R-F By-pass	C-D Type 3MP	
*1703	XMA3-23	Capacitor, 0.003 μ F, 500 volts dc	R-F By-pass	C-D Type 3M	
1704	XMA3-13	Capacitor, 0.005 μ F, 800 volts dc	R-F By-pass	C-D Type 3MP	
*1704	XMA3-23	Capacitor, 0.003 μ F, 500 volts dc	R-F By-pass	C-D Type 3MP	
1705	XMA3-13	Capacitor, 0.005 μ F, 800 volts dc	R-F By-pass	C-D Type 3MP	
*1705	XMA3-24	Capacitor, 0.003 μ F, 1,000 volts dc	R-F By-pass	C-D Type 3MP	
1706	XMA3-13	Capacitor, 0.005 μ F, 800 volts dc	R-F By-pass	C-D Type 3MP	
*1706	XMA3-24	Capacitor, 0.003 μ F, 1,000 volts dc	R-F By-pass	C-D Type 3MP	
1701	224403A/02	Choke coil (30-100 Ω)	High-Voltage Filter	WZ	MSO-680352-2
1702	224634A/01	Coil	Low-Voltage Filter	WZ Per drawing	
1703	224634A/02	Coil	High-Voltage Filter	WZ Per drawing	MSO-680352-3
1704	224634A/02	Coil	Low-Voltage Filter	WZ Per drawing	MSO-680352-3
1701	224634A/01	Resistor	Dynamotor Connection and 12-Volt Circuit Changes	Jones 3-310-AB	

*Modification during manufacture; see Paragraph 43.
 Available in depot stock.


Reference Number	Signal Corps Stock Number	Name and Description of Part	Function	Mfr.'s Code and Type Number	Contractor's Drawing Number
1. <u>Dynamotor EM-76-1 (Receiver, 24-Volt) (continued).</u>					
CR86	3045-13	Capacitor, 0.005 uF, 800 volts dc	R-P BY-pass	C-D Type 347	
*CR86	3045-24	Capacitor, 0.003 uF, 1,000 volts dc	R-P BY-pass	C-D Type 347	
L801	3044-03A/32	Choke coil (80-100K)	High-Voltage Filter	WS	ESC-60352-2
L802	301634A/31	Coil	Low-Voltage Filter	WS Per Drawing	ESC-60352-3
L803	301634A/32	Coil	High-Voltage Filter	WS Per Drawing	ESC-60352-3
L804	301634A/32	Coil	Low-Voltage Filter	WS Per Drawing	ESC-60352-3
J801	301634A/31	Receptacle	Dynamotor Connection and 24-Volt Circuit Changes	Jones S-310-AB	
	301634A/34	Low-voltage dynamotor brushes	Dynamotor Input	WS	Parts of ES-5586, List 2, Item 2, Fig. 2
	301634A/35	High-voltage dynamotor brushes	Dynamotor Output	WS	
	301634A/41	Dynamotor armature and bearings		WS	
	301634A/32	Dynamotor bearings		WS	
	301634A/327	End bell		WS Per Drawing	ES-5586, List 2, Detail 3
	301634A/31	Screw		WS Per Drawing	
	60670	Lubricant, 1/2-lb. can		B.Y. & N.I. Type S-30	

Modification during manufacture, see Paragraph 13.
 Three lists were formerly prepared as specified. The present spare parts
 list calls for a complete dynamotor unit as a spare instead of these parts.


J. List of Manufacturers (Table 12).

MF's Code	Name	Address
A-B	Allen-Bredley Co.	136 West Greenfield Avenue, Milwaukee, Wis.
Allied	Allied Control Co.	227 Fulton Street, New York, N.Y.
Amphel	American Phosphoric Corporation	1250 Van Buren Street, Chicago, Ill.
Cannon	Cannon Electric Development Co.	420 West Avenue 33, Los Angeles, Calif.
C-D	Cornell-Dubilier Electric Corp.	South Plainfield, N.J.
Diamond	Diamond Expansion Belt Co.	Garwood, N.J.
Drake	Drake Manufacturing Co.	1713 West Hubbard Street, Chicago, Ill.
Edison	Edison Pastener Co., Inc.	Babylon, N.Y.
Erie	Erie Resistor Corporation	Erie, Pa.
G.E.	General Electric Co.	Schenectady, N.Y.
H&S	Arrow-Hart & Wegman Electric Co.	Hartford, Conn.
INS	International Resistance Co.	403 North Broad Street, Philadelphia, Pa.
Isolantite	Isolantite, Incorporated	235 Broadway, New York, N.Y.
Jensen	Jensen Radio Manufacturing Co.	6603 South Laramie Avenue, Chicago, Ill.
Jones	Howard B. Jones	2300 Wabasha Avenue, Chicago, Ill.
Littel	Littellfuse, Inc.	4757 Ravenswood Avenue, Chicago, Ill.
Mallory	F. B. Mallory & Co., Inc.	Indianapolis, Ind.
Muter	Muter Company	1255 South Michigan Avenue, Chicago, Ill.
National	National Company	Walden, Mass.
N.Y. & N.J.	New York and New Jersey Induriant Co.	300 Delancey Street, Newark, N.J.
Oak	Oak Manufacturing Co.	1560 Weymouth Avenue, Chicago, Ill.
Omite	Omite Manufacturing Co.	4837 Plummer Street, Chicago, Ill.
ROC	ROC Manufacturing Co., Inc.	Barrington, N.J.
Spencer	Spencer Thermostat Co.	Attleboro, Mass.
United	United-Carr Pastener Corp.	Cedar Ridge, Mass.
USE	United States Rubber Co.	191 Hudson Street, New York, N.Y.
WE	Western Electric Co., Inc.	120 Broadway, New York, N.Y.
W-J	Ward-Leonard Electric Corp.	32 South Street, Mount Vernon, N.Y.
Weston	Weston Electrical Instrument Corp.	618 Freytaghysman Avenue, Newark, N.J.
Wierick	Wierick Manufacturing Co.	385 Gerard Avenue, New York, N.Y.

"6020 - Phila. - 45 - 02 - 7482 - Dec. - 44."



SCR-608-A: System Schematic Diagram



ITEM	SYMBOL	DESCRIPTION
RESISTORS		
R 54	100,000 Ω 1/2 W	
R 55	100,000 Ω 1/2 W	
R 56	100,000 Ω 1/2 W	
R 57	40,000 Ω 1/2 W	
R 58	40,000 Ω 1/2 W	
R 59	1,000 Ω 1/2 W	
R 60	40,000 Ω 1/2 W	
R 61	40,000 Ω 1/2 W	
R 62	10,000 Ω 1/2 W	
R 63	10,000 Ω 1/2 W	
R 64	10,000 Ω 1/2 W	
R 65	10,000 Ω 1/2 W	
R 66	10,000 Ω 1/2 W	
R 67	10,000 Ω 1/2 W	
R 68	10,000 Ω 1/2 W	
R 69	10,000 Ω 1/2 W	
R 70	10,000 Ω 1/2 W	
R 71	10,000 Ω 1/2 W	
R 72	10,000 Ω 1/2 W	
R 73	10,000 Ω 1/2 W	
R 74	10,000 Ω 1/2 W	
R 75	10,000 Ω 1/2 W	
R 76	10,000 Ω 1/2 W	
R 77	10,000 Ω 1/2 W	
R 78	10,000 Ω 1/2 W	
R 79	10,000 Ω 1/2 W	
R 80	10,000 Ω 1/2 W	
R 81	10,000 Ω 1/2 W	
R 82	10,000 Ω 1/2 W	
R 83	10,000 Ω 1/2 W	
R 84	10,000 Ω 1/2 W	
R 85	10,000 Ω 1/2 W	
R 86	10,000 Ω 1/2 W	
R 87	10,000 Ω 1/2 W	
R 88	10,000 Ω 1/2 W	
R 89	10,000 Ω 1/2 W	
R 90	10,000 Ω 1/2 W	
R 91	10,000 Ω 1/2 W	
R 92	10,000 Ω 1/2 W	
R 93	10,000 Ω 1/2 W	
R 94	10,000 Ω 1/2 W	
R 95	10,000 Ω 1/2 W	
R 96	10,000 Ω 1/2 W	
R 97	10,000 Ω 1/2 W	
R 98	10,000 Ω 1/2 W	
R 99	10,000 Ω 1/2 W	
R 100	10,000 Ω 1/2 W	
SWITCHES		
S 1	REC. ON/OFF	
S 2	REAR-INPUT-EXT. GAIN	
S 3	OUTPUT TO PHONES	
S 4	ON/OFF SPEAKER	
S 5	ON/OFF BATTERY	
S 6	TUNE-ORANGE	
VACUUM TUBES		
V 1	VT-22 (6AC7)	
V 2	VT-22 (6AC7)	
V 3	VT-24 (6AR5)	
V 4	VT-209 (6BE6)	
V 5	VT-209 (6BE6)	
V 6	VT-209 (6BE6)	
V 7	VT-20 (6AR5)	
V 8	VT-209 (6BE6)	
V 9	VT-22 (6AC7)	
V 10	VT-22 (6AC7)	
V 11	VT-22 (6AC7)	
V 12	VT-22 (6AC7)	
V 13	VT-22 (6AC7)	
V 14	VT-22 (6AC7)	
V 15	VT-22 (6AC7)	
V 16	VT-22 (6AC7)	
V 17	VT-22 (6AC7)	
V 18	VT-22 (6AC7)	
V 19	VT-22 (6AC7)	
V 20	VT-22 (6AC7)	
V 21	VT-22 (6AC7)	
V 22	VT-22 (6AC7)	
V 23	VT-22 (6AC7)	
V 24	VT-22 (6AC7)	
V 25	VT-22 (6AC7)	
V 26	VT-22 (6AC7)	
V 27	VT-22 (6AC7)	
V 28	VT-22 (6AC7)	
V 29	VT-22 (6AC7)	
V 30	VT-22 (6AC7)	
V 31	VT-22 (6AC7)	
V 32	VT-22 (6AC7)	
V 33	VT-22 (6AC7)	
V 34	VT-22 (6AC7)	
V 35	VT-22 (6AC7)	
V 36	VT-22 (6AC7)	
V 37	VT-22 (6AC7)	
V 38	VT-22 (6AC7)	
V 39	VT-22 (6AC7)	
V 40	VT-22 (6AC7)	
V 41	VT-22 (6AC7)	
V 42	VT-22 (6AC7)	
V 43	VT-22 (6AC7)	
V 44	VT-22 (6AC7)	
V 45	VT-22 (6AC7)	
V 46	VT-22 (6AC7)	
V 47	VT-22 (6AC7)	
V 48	VT-22 (6AC7)	
V 49	VT-22 (6AC7)	
V 50	VT-22 (6AC7)	
V 51	VT-22 (6AC7)	
V 52	VT-22 (6AC7)	
V 53	VT-22 (6AC7)	
V 54	VT-22 (6AC7)	
V 55	VT-22 (6AC7)	
V 56	VT-22 (6AC7)	
V 57	VT-22 (6AC7)	
V 58	VT-22 (6AC7)	
V 59	VT-22 (6AC7)	
V 60	VT-22 (6AC7)	
V 61	VT-22 (6AC7)	
V 62	VT-22 (6AC7)	
V 63	VT-22 (6AC7)	
V 64	VT-22 (6AC7)	
V 65	VT-22 (6AC7)	
V 66	VT-22 (6AC7)	
V 67	VT-22 (6AC7)	
V 68	VT-22 (6AC7)	
V 69	VT-22 (6AC7)	
V 70	VT-22 (6AC7)	
V 71	VT-22 (6AC7)	
V 72	VT-22 (6AC7)	
V 73	VT-22 (6AC7)	
V 74	VT-22 (6AC7)	
V 75	VT-22 (6AC7)	
V 76	VT-22 (6AC7)	
V 77	VT-22 (6AC7)	
V 78	VT-22 (6AC7)	
V 79	VT-22 (6AC7)	
V 80	VT-22 (6AC7)	
V 81	VT-22 (6AC7)	
V 82	VT-22 (6AC7)	
V 83	VT-22 (6AC7)	
V 84	VT-22 (6AC7)	
V 85	VT-22 (6AC7)	
V 86	VT-22 (6AC7)	
V 87	VT-22 (6AC7)	
V 88	VT-22 (6AC7)	
V 89	VT-22 (6AC7)	
V 90	VT-22 (6AC7)	
V 91	VT-22 (6AC7)	
V 92	VT-22 (6AC7)	
V 93	VT-22 (6AC7)	
V 94	VT-22 (6AC7)	
V 95	VT-22 (6AC7)	
V 96	VT-22 (6AC7)	
V 97	VT-22 (6AC7)	
V 98	VT-22 (6AC7)	
V 99	VT-22 (6AC7)	
V 100	VT-22 (6AC7)	
MISCELLANEOUS		
F 1	CALL NUMBER (MOS)	
F 2	FUSE 5 AMP	
M 1	12V DYAMOTOR	
M 2	24V DYAMOTOR	
L 1	LINE-UP METER	
T 1	OUTPUT TRANSFORMER	

NOTES

1. WHEN CAPACITORS C54 AND C56 ARE SQUARE, CAPACITOR C54 IS OMITTED (OPTIONAL METHOD NOT SHOWN IN DIAGRAM).
2. TWO CAPACITORS REPLACED BY ONE HAVING A CAPACITY EQUAL TO THE TOTAL OF THE REPLACED TWO (OPTIONAL METHOD NOT SHOWN IN DIAGRAM).
3. ELIMINATED IN LATER UNITS.

Fig. 70. Radio Receiver BC-683-A: Schematic Diagram Showing Modifications During Manufacture




Fig. 72. Radio Receiver BC-







Fig. 74. Radio Transmitter BC-684-A: Schematic Diagram







BOTTOM VIEW OF CHASSIS

NOTES


1. WIRES MARKED "A" ARE FURNISHED WITH APPROPRIATE.
2. WIRES MARKED "B" ARE NO. 18 A.W.G. TUNED.
3. WIRES MARKED "C" ARE NO. 18 A.W.G. TUNED.
4. WIRES MARKED "D" ARE NO. 18 A.W.G. STRANDED 1250 VOLT RADIO HOOK-UP WIRE.
5. WIRES MARKED "E" ARE NO. 20 A.W.G. SOLID 1250 VOLT RADIO HOOK-UP WIRE SHIELDED.
6. WIRES MARKED "F" ARE TRANSMISSION LINE.
7. WIRES MARKED "G" ARE NO. 20 A.W.G. STRANDED 1250 VOLT RADIO HOOK-UP WIRE.
8. WIRES MARKED "H" ARE FLEXIBLE (4 IN. COPPER STRIP).
9. WIRES MARKED "I" ARE TINNED COPPER BRASS 1/4 IN. WIDE.
10. WIRES MARKED "J" ARE NO. 22 A.W.G.
11. WIRES MARKED "K" ARE NO. 10 A.W.G. STRANDED 1250 VOLT RADIO HOOK-UP WIRE.
12. WIRES MARKED "L" ARE NO. 22 A.W.G. T WIRE.
13. WIRES MARKED "M" ARE IN CABLE NO. 1.
14. WIRES MARKED "N" ARE IN CABLE NO. 2.
15. ALL OTHER WIRES NOT MARKED ARE NO. 20 A.W.G. SOLID 1250 VOLT AEROSOLAS RADIO HOOK-UP WIRE.
16. ALL WIRE IS WHITE BACKGROUND COLORS SPECIFIED ARE TRACER COLORS.
17. AT P-101 AND J-101 PLACE A 1/8" HIGH LENGTH OF YELLOW FLEXIBLE VARNISHED CAMBRIC TUBING OVER WIRE, SOLDER WIRE TO TERMINAL, AND SLIP THE TUBING OVER SOLDERED JOINT UNTIL IT BEARS AGAINST BACK FACE OF JACK OR RECEPTACLE. USE NO. 11 TUBING FOR SMALL WIRES AND NO. 6 TUBING FOR LARGE WIRES OF WHOM TWO WIRES ARE CONNECTED TO THE SAME TERMINAL.
18. WHERE 3 OR MORE WIRES WHICH ARE NOT SEWN INTO THE CABLE RUN PARALLEL THEY SHALL BE TIED TOGETHER AT APPROXIMATELY ONE INCH INTERVALS IN ORDER TO HOLD THEM NEATLY AND SECURELY IN PLACE.
19. EACH WIRE END SHALL BE WRAPPED AROUND THE TERMINAL TO WHICH IT CONNECTS FOR AT LEAST ONE FULL TURN, WRAPPED TO TERMINAL THEN NEATLY SOLDERED; EXCEPT AT P-101 AND J-101 WHERE THE WIRES MUST ENTER THE END OF THE TERMINALS FOR AT LEAST 1/8" AND THEN NEATLY AND SECURELY SOLDERED. CARE SHALL BE USED TO PREVENT SOLDER FROM RUNNING INTO TUBE SOCKET PIN SLIPS.
20. SAME WIRES, EXCEPT THOSE RUNNING DIRECTLY TO A GROUND LINE, MUST CLEAR ALL ROUGHNESS WIRES AND APPROPRIATE BY AT LEAST 1/8" INCH AND MUST BE SO FORMED AS TO PREVENT CONTACT BEING MADE DURING THE NORMAL MOVEMENT OF ANY ADJACENT ITEM OR PART.
21. INCORPORATE BENDS IN "N" WIRES TO L-101, L-104 AND L-105 TO RELIEVE VIBRATION STRESS ON TERMINALS.

16. TOGETHER




REAR VIEW OF PANEL

CAUTION! REMOVE BATTERIES BEFORE STORING





APPARATUS LEGEND		
PART	TYPE	DESCRIPTION
1	BA-27	BATTERY 4.5 V
2	CA-389	CAPACITOR
3	CA-275	CAPACITOR
4	CA-389	CAPACITOR
5	GN-38	GENERATOR
6	JK-34A	JACK
7	JK-33A	JACK
8	PL-55	PLUG
9	PL-68	PLUG
10	MC-131	RINGER
11	SW-175	SWITCH
12	SW-185	SWITCH
13	C-280	TRANSFORMER

Fig. 76. Remote Control Unit RM-29-D: Schematic and Wiring Diagram



SCH

APPARATUS DESIG.	
R	15 RESISTORS, IRC F3
TM	THERMOAMMETER W
	(8)




ASSEMBL

Fig. 77. Artificial Antenna for Testing Re




SCHEMATIC CIRCUIT DIAGRAM

DESCRIPTION
RESISTORS, IRC F3, EACH 600 OHMS (APPROX. 40 OHMS TOTAL)
DC MILLIAMMETER WESTON MODEL 425 0-1 AMP.
(BAKELITE CASE, FLUSH MOUNTING)



BEND LEADS
APPROX. AS SHOWN

NOTE:
RINGS AND LEADS SHALL
BE NO. 12 A.W.G. TINNED.



ASSEMBLY